

SLOTCHANGER, an Applesoft BASIC program, can be executed directly from BASIC or from the "ProDrive options menu" of the Super Desktop Expander disk. Selecting the "Change ProDrive emulation slot,drive" option from the "ProDrive options menu" of the Super Desktop Expander disk will install a ProDrive (if not already installed) and run the SLOTCHANGER program. If you execute it from BASIC, SLOTCHANGER will not automatically install a ProDrive; SLOTCHANGER will display this prompt:

Change ProDrive to emulate what slot,drive? (1-7), (1-2) S_

Enter the new slot number, 1 through 7 (Do not enter the comma or press the return key!) and then enter the number of the new drive, either 1 or 2. If you make a mistake which results in an error, just reboot and start again.

Using AUTOCOPY

We have included AUTOCOPY, an Applesoft BASIC utility program, on the Super Desktop Expander disk. This program will allow you to copy all of the files on one or more floppy disks to a ProDrive. The authors of AUTOCOPY tried to make the program as simple to use as possible, but it does require some elementary knowledge of ProDOS pathname structure. The ProDOS User's Manual (Apple Computer, Inc) will explain the basics of pathnames, directories, subdirectories, and filenames.

Select the "Autocopy all files to ProDrive" option from the Super Desktop Expander to automatically install a ProDrive (if not already installed) and run the AUTOCOPY program. AUTOCOPY first prompts you with the following line:

Enter name of volume directory to copy (<RETURN> to quit) /

Carefully type the volume name of the floppy disk containing the files you wish to copy. The leading ProDOS slash (/) delimiter is provided; just enter the volume name character string. You don't need to type the ending delimiter. To correct an entry, use the left arrow key to backspace over the error, then enter the correct character(s) before you press the return key. Next, the program prompts you to enter the destination subdirectory:

Enter name of destination subdirectory /RAM/

The program provides the ProDrive volume directory name, /RAM/; type the desired subdirectory name. If you want to copy the source files directly under the /RAM directory, just press the RETURN key. To change the destination volume directory name, use the left-arrow key to backspace over "RAM" and enter the desired volume name or pathname.

Use the equal sign (=) as a wildcard to substitute for the trailing characters of a source filename character string. For example:

Enter name of volume directory to copy
(<RETURN> to quit)/PFS.FILE/FRED=

In this example, AUTOCOPY will copy to the ProDrive only the files with filenames that begin with "FRED" on the /PFS.FILE volume.

If you specify a destination subdirectory which does not already exist, AUTOCOPY will automatically create it. The program copies the contents of any subdirectories encountered under the source pathname to subdirectories created by AUTOCOPY under the