

ATLAS

\$0000~\$FFFF (0~-1) \HB\	ADDRESS RANGE OF APPLE II (\$0000~\$FFFF SIGNED DECIMAL EQUIV IS 0~32767 FOLLOWED BY -32768~-1)
\$0000~\$BFFF (0~-16385) \HB\	RAM ADDRESS RANGE OF APPLE II (NOT INCLUDING RAM IN LANGUAGE CARD IF PRESENT)
\$0000~\$00FF (0~255) \HB\	HARDWARE PAGE ZERO
\$0000~\$001F (0~31) [(R0-R15)] \PB\	'SWEET-16' REGISTERS R0 THRU R15 OF 'SWEET-16' (16-BIT INTERPRETER IN MONITOR)
\$0000~\$0002 (0~2) \SE\	APPLESOFT SOFT REENTRY (OG IS EQUIVALENT TO CTRL-C)
\$0000~\$0001 (0~1) [ROL~ROH] \P2\	'SWEET-16' REGISTER R0 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$0000 (0) [LOC0] \P1\	MONITOR MEMORY LOCATION 'LOC0'. PRESET TO \$4C (JMP) - (JUMP ADDRESS IN \$001~\$002)
\$0001~\$0002 (1~2) [LOC1] \P2\	MONITOR MEMORY LOCATION 'LOC1' - POINTER PRESET TO ADDRESS OF APPLESOFT SOFT ENTRY
\$0002~\$0003 (2~3) [(R1)] \P2\	'SWEET-16' REGISTER R1 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$0003~\$0005 \SE\	APPLESOFT JUMP COMMAND TO \$F128 (HARD ENTRY?)
\$0004~\$0005 (4~5) [(R2)] \P2\	'SWEET-16' REGISTER R2 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$0006~\$0007 (6~7) [(R3)] \P2\	'SWEET-16' REGISTER R3 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$0008~\$0009 (8~9) [(R4)] \P2\	'SWEET-16' REGISTER R4 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$000A~\$0016 (10~22) [(A/S RESVD)] \PB\	APPLESOFT RESERVED BLOCK IN PAGE ZERO
\$000A~\$000C (10~12) \SI\	APPLESOFT LOCN FOR USR FUNCTION'S JUMP INSTRUCTION
\$000A~\$000B (10~11) [(R5)] \P2\	'SWEET-16' REGISTER R5 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$000C~\$000D (12~13) [(R6)] \P2\	'SWEET-16' REGISTER R6 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$000D (13) [CHARAC]	APPLESOFT - USED BY STRLT2 STRING UTILITY
\$000D~\$0016 (13~22) \PB\	GENERAL PURPOSE COUNTERS/FLAGS FOR APPLESOFT
\$000E~\$000F (14~15) [(R7)] \P2\	'SWEET-16' REGISTER R7 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$000E (14) [ENDCHR]	APPLESOFT - USED BY STRLT2 STRING UTILITY
\$0010~\$0011 (16~17) [(R8)] \P2\	'SWEET-16' REGISTER R8 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$0011 (17) [VALTYP]	APPLESOFT FLAG FOR LAST FAC (FLOATING ACCUMULATOR) OPERATION: \$00 = NUMBER; \$FF=STRING
\$0012~\$0013 (18~19) [(R9)] \P2\	'SWEET-16' REGISTER R9 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$0014~\$0015 (20~21) [(R10)] \P2\	'SWEET-16' REGISTER R10 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$0014 (20) [SUBFLG]	APPLESOFT SUBSCRIPT FLAG: \$00= SUBSCRIPTS ALLOWED; \$80= SUBSCRIPTS NOT ALLOWED
\$0016~\$0017 (22~23) [(R11)] \P2\	'SWEET-16' REGISTER R11 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$0016 (22) [(COMPRTP)] \P1\	APPLESOFT- PARAMETER TO CONTROL TYPE OF COMPARISON MADE BY FLOATING POINT COMPARISON ROUTINE AT \$DF6A (1:> ;2:= ;3:>= ;4:< ;5:< ;6:<=)
\$0018~\$0019 (24~25) [(R12)] \P2\	'SWEET-16' REGISTER R12 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$001A~\$001B (26~27) [(R13)] \P2\	'SWEET-16' REGISTER R13 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$001A~\$001B (26~27) [SHAPEL~SHAPEH] \P2\	HI-RES POINTER TO SHAPE LIST (ON-THE-FLY SHAPE POINTER)
\$001C~\$001D (28~29) [(R14)] \P2\	'SWEET-16' REGISTER R14 (IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR)
\$001C (28) [HCOLOR1] \P1\	HI-RES RUNNING COLOR MASK (ON-THE-FLY COLOR BYTE)
\$001D (29) [COUNTH] \P1\	HI-RES GRAPHICS HIGH-ORDER BYTE OF STEP COUNT FOR LINE
\$001E~\$001F (30~31) [R15L~R15H] \P2\	'SWEET-16' REGISTER R15 (USED AS PROGRAM COUNTER IN 16-BIT PSEUDOMACHINE IN APPLE SYSTEM MONITOR) (REG-R15)
\$0020~\$0055 (32~85) [(MONITOR RESVD)] \PB\	APPLE II SYSTEM MONITOR RESERVED LOCATIONS (\$0050~\$0055 USED ONLY BY MULTIPLY-DIVIDE ROUTINES AND THUS AVAILABLE IN MANY SITUATIONS)
\$0020~\$004F (32~79) [(AUTOSTART RESVD)] \PB\	AUTOSTART MONITOR RESERVED LOCATIONS
\$0020 (32) [WNDLFT] \P1\	LEFT COLUMN OF SCROLL WINDOW: RANGE 0-39 OR \$0~\$27. USED ONLY IN VTABZ.
\$0021 (33) [WNDWDTH] \P1\	WIDTH OF THE SCROLL WINDOW: RANGE:1 TO 40-(WNDLFT) OR \$1 TO \$28 - (WNDLFT)
\$0022 (34) [WNDTOP] \P1\	TOP LINE OF SCROLL WINDOW: RANGE 0-22(\$16) FOR FULL TEXT SCREEN 20-22(\$14~\$16) FOR MIXED SCREEN
\$0023 (35) [WNCBTM] \P1\	BOTTOM LINE OF SCROLL WINDOW: RANGE (WNDTOP)+1 TO 24(\$18).
\$0024 (36) [CH] \P1\	CURSOR HORIZONTAL DISPLACEMENT FROM WNDLFT: RANGE 0 TO (WNDWDTH)-1
\$0025 (37) [CV] \P1\	CURSOR VERTICAL POSITION RELATIVE TO TOP OF SCREEN: RANGE 0-23 (\$0~\$17)
\$0026~\$0027 (38~39) \P2\	PAGE ZERO LOCATIONS USED BY DOS
\$0026~\$0027 (38~39) [GBASL~GBASH] \P2\	MEMORY ADDRESS OF LEFT END POINT OF DESIRED LINE FOR LO-RES PLOT (SET BY GBASCALC)
\$0026~\$0027 (38~39) [HBASL~HBASH] \P2\	HI-RES GRAPHICS ON-THE-FLY BASE ADDRESS (LEFT END POINT OF DESIRED LINE FOR HI-RES PLOT)

\$0026~\$0027 (38~39) USED AS SCRATCH BY DOS
 \$0028~\$0029 (40~41) [BASL~BASH] \P2\MEMORY ADDRESS FOR LEFT END CHARACTER POS'N OF CURRENT TEXT LINE
 \$002A~\$002F (42~47) \PB\ PAGE ZERO LOCATIONS USED BY DOS
 \$002A~\$002B (42~43) \P2\ USED AS SCRATCH BY DOS
 \$002A~\$0023 (42~43) [BAS2L~BAS2H] \P2\USED DURING SCROLLING AS DESTINATION LINE POINTER AS EACH LINE IS MOVED TO POSITION ABOVE CURRENT
 \$002C~\$002D (44~45) [RTNL~RTNH] \P2\MONITOR RETURN POINTER (POINTS TO SAVE AREA USED BY INSTRUCTION TRACE ROUTINE)
 \$002C~\$002D (44~45) [LMNEM~RMNEM] \P2\ADDRESS POINTER USED BY DISASSEMBLER FOR INDEX TO MNEMONICS TABLE
 \$002C~\$002D (44~45) [TEMP] \P2\ DOS RWTS (READ-WRITE TRACK-SECTOR) TEMPORARY STORAGE FOR ADDRESS INFORMATION
 \$002C (44) [COUNT - CSUM] \P1\ DOS RWTS (READ-WRITE TRACK-SECTOR) PARAMETER (RETURNS CHECKSUM)
 \$002C (44) [H2] \P1\ RIGHT END POINT OF A HORIZONTAL LINE BEING DRAWN BY HLINE: RANGE 0-39 (\$0~\$27)
 \$002D (45) [V2] \P1\ BOTTOM PT OF LO-RES VERT LINE DRAWN BY VLINE. RANGE: 0-19(\$21) FOR MIXED SCR; 0-23(\$17) FOR FULL SCR
 \$002D (45) [SECT] \P1\ DOS RWTS (READ-WRITE TRACK-SECTOR) PARAMETER FOR CURRENT DISK SECTOR
 \$002E (46) [CHKSUM] \P1\ LOCN WHERE CHECKSUM IS ACCUMULATED DURING CASSETTE TAPE READ
 \$002E (46) [FORMAT] \P1\ USED BY MINIASSEMBLER & DISASSEMBLER TO SPECIFY FORMAT OF INSTRUCTION FOR DISPLAY PURPOSES
 \$002E (46) [MASK] \P1\ LOW-RES COLOR GRAPHICS MASK. \$0F OR \$F0 TO SELECT HIGH OR LOW NIBBLE TO SPECIFY WHICH OF 2 PLOT LINES REP BY GBASL~H POINTER
 \$002E (46) [TRACK - TRKN] \P1\ DOS RWTS (READ-WRITE TRACK-SECTOR) TRACK NUMBER
 \$002F (47) [LASTIN] \P1\ USED IN CASSETTE INPUT BY RDBIT AS WORK AREA TO DETERMINE WHETHER INPUT HAS CHANGED
 \$002F (47) [LENGTH] \P1\ USED BY DISASSEMBLER TO INDICATE LENGTH OF THE INSTRUCTION. ALSO BY TRACE
 \$002F (47) [SIGN] \P1\ \$01 BIT SET AFTER CALL TO MULPM OR DIVPM (SIGNED 16 BIT MULT OR DIV) TO SPECIFY WHETHER COMPLEMENT NEEDED (NOTE MULPM & DIVPM IN OLD MONITOR ONLY - NOT IN AUTOSTART)
 \$002F (47) [VOLUME] \P1\ DOS RWTS (READ-WRITE TRACK-SECTOR) DISK VOLUME NUMBER
 \$0030 (48) [COLOR] \P1\ LOW-RES COLOR GRAPHICS COLOR CODE (FOR PLOT/HLIN/VLIN FUNCTIONS) - CONTAINS SELECTED COLOR VALUES FOR TWO LOW-RES GRAPHICS 'LINES' ONE IN EACH NIBBLE OF BYTE
 \$0030 (48) [HMASK] \P1\ HI-RES GRAPHICS ON-THE-FLY BIT MASK
 \$0031 (49) [MODE] \P1\ USED BY MONITOR COMMAND PROCESSING TO INDICATE DISPOSITION OF HEX INFO IN THE INPUT LINE
 \$0032 (50) [INVFLG] \P1\ VIDEO FORMAT CONTROL: 255(\$FF)=NORMAL;127(\$7F)=FLASHING;63(\$3F)=INVERSE
 \$0033 (51) [PROMPT] \P1\ PROMPT CHARACTER WRITTEN TO SCREEN WHENEVER A LINE OF INPUT IS CALLED FOR BY GETLN ROUTINE
 \$0034 (52) [YSAV] \P1\ USED BY MONITOR COMMAND PROCESSOR TO SAVE CONTENTS OF Y-REGISTER DURING PROCESSOR {Y-REGISTER SAVE LOCN FOR MONITOR}
 \$0035~\$0039 (53~57) \PB\ PAGE ZERO LOCATIONS USED BY DOS FOR INTERFACE (DRIVEN0 CSW & KSW)
 \$0035 (53) [YSAV1] \P1\ USED TO SAVE CONTENTS OF Y-REGISTER ACROSS A CALL TO SCREEV OUTPUT ROUTINES. {Y-REGISTER SAVE LOCN FOR COUT1}
 \$0035 (53) [L] \P1\ MINIASSEMBLER MEMORY LOCATION 'L'
 \$0035 (53) [DRIVEN0] \P1\ DOS DISK DRIVE NO
 \$0036~\$0039 (54~57) [(I/O HOOK TBLS)] \PB\MONITOR OUTPUT & INPUT HOOKS (VECTORS TO DOS OUTPUT & INPUT ROUTINES)
 \$0036~\$0037 (54~55) [CSWL~CSWH] \P2\MONITOR OUTPUT REG & OUTPUT HOOK TO DOS; I.E. ADDRESS OF ROUTINE WHICH IS TO RECEIVE AND DISPOSE OF OUTPUT CHARACTERS. RESET 0 CTRL-P & PR#0 SET THIS LOCN TO \$FDFO (MONITOR OUTPUT TO SCREEN); S CTRL-P & PR#S SET THIS LOCN TO \$CS00 (SLOT S ROM)
 \$0038~\$0039 (56~57) [KSWL~KSWH] \P2\DOS INPUT HOOK; I.E. ADDRESS OF THE USER INPUT ROUTINE. CONTROLLED BY CURRIN PORT IN# & KEYIN. RESET - 0 CTRL-K & IN#0 SET THIS LOCN TO \$FD1B (MONITOR KEYBOARD INPUT ROUTINE); S CTRL-K & IN#S SET THIS LOCN TO \$CS00(SLOT S ROM) (MONITOR INPUT REG)
 \$003A~\$003B (58~59) [PCL~PCH] \P2\SAVE AND CONTROL AREA FOR PROGRAM COUNTER. USED IN BREAK PROCESSING AND MINIASSEMBLER. SET BY MONITOR CMDS L G S & T (PC SAVED HERE BY MONITOR)
 \$003C~\$0043 (60~67) [XQT/XQTN2] \PB\8 BYTE WORK AREA FOR INSTRUCTION STEP/TRACE. NEXT INSTRUCTION SOMETIMES MOVED HERE
 \$003C~\$003D (60~61) [A1L~A1H] \P2\MONITOR GENERAL USAGE SUBROUTINE PARAMETER A1. MANY USES INCLUDE SOURCE POINTER DURING MONITOR MOVE

\$003C~\$003D (60~61) [DEVCTBL] \P2\DOS RWTS DEVICE IN READ-WRITE TRACK-SECTOR PARAMETER POINTING TO DEVICE TABLE. PRESET TO 'PTRSDEST' = POINTER TO DESTINATION DEVICE IN DEVICE TABLE. NOT A SYNONYM FOR BUFPTR

\$003C~\$003D (60~61) [DEVCTBL] DOS RWTS (READ-WRITE TRACK-SECTOR) DEVICE TABLE - SYNONYM FOR BUFPTR

\$003E~\$003F (62~63) [BUFPTR] \P2\DOS RWTS (READ-WRITE TRACK-SECTOR) PARAMETER 'BUFPTR' (POINTS TO DATA BUFFER IN RWTS)

\$003E~\$003F (62~63) [A2L-A2H] \P2\MONITOR GENERAL USAGE SUBROUTINE PARAMETER A2. USED IN CALLING LIST OF MANY MONITOR SUBROUTINES SUCH AS MOVE & CASSETTE ROUTINES

\$0040~\$0048 (64~72) PAGE ZERO LOCATIONS USED BY DOS

\$0040~\$0041 (64~65) [A3L-A3H] \P1\MONITOR GENERAL USAGE SUBROUTINE PARAMETER A3. USED IN CALLING LIST OF MOST MONITOR SUBROUTINES

\$0040~\$0041 (64~65) [FCBFOP ZPGWRK V NPE] DOS - USED AS GENERAL POINTER BY 1ST LEVEL (COMMAND DECODE) ROUTINES IN DOS

\$0041 (65) [TRKCNT] \P1\ DOS DISK SYSTEM FORMATTER SPECIAL TRACK COUNTER

\$0042~\$0043 (66~67) [A4L-A4H] \P2\MONITOR GENERAL USAGE SUBROUTINE PARAMETER A4. USED IN CALLING LIST OF SOME MONITOR SUBROUTINES

\$0043~\$0043 (67~67) [ZPGBM3 ZPGFCB] DOS - USED AS GENERAL PURPOSE POINTER BY SECOND-LEVEL DOS ROUTINES

\$0044~\$0045 (68~69) [A5L-A5H] \P2\MONITOR GENERAL USAGE SUBROUTINE PARAMETER A5. USED MOSTLY BY SINGLE-CYCLE & TRACE

\$0044~\$0045 (68~69) [CNUM] DOS - POINTS TO AVAILABLE BUFFER IN OPEN. ALSO USED AS ARITHMETIC REGISTER BY DOS FIRST & SECOND LEVEL ROUTINES

\$0044 (68) [FMT] \P1\ MINIASSEMBLER MEMORY LOCATION 'FMT'

\$0045 (69) [ACC] \P1\ USER A-REG SAVED HERE ON BRK TO MONITOR & DURING TRACE

\$0046 (70) [XREG] \P1\ USER X-REG SAVED HERE ON BRK TO MONITOR & DURING TRACE

\$0046 (70) [MONTIME] \P1\ DOS RWTS (READ-WRITE TRACK-SECTOR) PARAMETER 'MONTIME'

\$0046 (70) [EXCNT] \P1\ DOS DISK SYSTEM FORMATTER GENERAL COUNTER

\$0047 (71) [YREG] \P1\ USER Y-REG SAVED HERE ON BRK TO MONITOR & DURING TRACE (Y-REG SAVED HERE ON BRK)

\$0047 (71) [YCNT] \P1\ DOS DISK SYSTEM FORMATTER NYBBLE COUNTER (ALSO COUNTER FOR DISK-DRIVE MOTOR-ON TIME?)

\$0048~\$0049 (72~73) [IOBPL~H] \P2\DOS READ-WRITE-TRACK-SECTOR (RWTS) 'IOBPL~H' (INPUT-OUTPUT CONTROL BLOCK POINTER)

\$0048 (72) [STATUS] \P1\ USER STATUS REGISTER (P-REGISTER) SAVED HERE ON BRK TO MONITOR & DURING TRACE. WARNING: INITIALIZE BEFORE G FUNCTION TO AVOID DECIMAL MODE IF DOS HAS BEEN USED

\$0049 (73) [SPNT] \P1\ USER STACK POINTER (S-REGISTER) SAVED HERE BY MONITOR 'SAVE' ROUTINE ON BRK & DURING TRACE

\$004A~\$00DF (74~223) \PB\ PAGE ZERO LOCATIONS USED BY INTEGER BASIC (GAP AT \$004E~\$0054)

\$004A~\$004D (74~77) PAGE ZERO LOCATIONS USED BY DOS

\$004A~\$0043 (74~75) [LOMEM~LOMEMH] \P2\POINTER TO LOMEM (CONTAINS 'START OF BASIC VARIABLES' FOR INTEGER BASIC - START OF PROGRAM FOR APPLESOFT BASIC)

\$004A (74) [A] \P1\ DOS DISK SYSTEM FORMATTER DUMMY LOCATION FOR TIMING PURPOSES AND SCRATCH. DOS WILL REPAIR IN INIT COMMAND; USER MUST REPAIR IF RWTS FORMATTER CALLED DIRECTLY

\$004B (75) [FILLCNT - SCTR] \P1\DOS DISK SYSTEM FORMATTER GENERAL COUNTER & SECTOR NUMBER

\$004C~\$004D (76~77) [HIMEM~HIMEMH] \P2\ADDRESS POINTER TO HIMEM (INTEGER BASIC - END OF BASIC PROGRAM) (APPLESOFT - START OF STRING DATA)

\$004E~\$004F (78~79) [RNDL~RNDH] \P2\16 BIT NO. RANDOMIZED WITH EACH KEY ENTRY DONE BY MONITOR KEYIN ROUTINE (AND BY MANY OTHER ROUTINES SUCH AS SERIAL & COMM CARD WHICH ARE USED TO REPLACE KEYIN). RANDOMIZATION ACCOMPLISHED BY CONTINUOUSLY INCREMENTING WHILE AWAITING KEYBOARD INPUT. HIGH ORDER BYTE \$4F

\$0050~\$00F8 (80~248) APPLESOFT - PAGE ZERO LOCATIONS USED (GAPS AT \$00D7 \$00E3 & \$00EB~\$00EF)

\$0050~\$0061 (80~97) [(A/S POINTERS)] \PB\GENERAL PURPOSE POINTERS FOR APPLESOFT (PB)

\$0050~\$0057 (80~87) [NOUNSTKL] \P8\INTEGER BASIC MEMORY LOCATION 'NOUNSTKL'

\$0050~\$0055 (80~85) \P6\ MONITOR/INTEGER BASIC MULTIPLY-DIVIDE WORKAREA

\$0050~\$0053 (80~83) [AC] \P4\ 32-BIT EXTENDED ACCUMULATOR USED IN MONITOR 16-BIT MULT & DIVIDE

\$0050~\$0051 (80~81) [LINNUM] \P2\APPLESOFT GENERAL PURPOSE 16 BIT NUMBER LOCATION (USES INCLUDED LOCATION FOR LINE NUMBER)

\$0050~\$0051 (80~81) [ACL~ACH] \P2\OLD MONITOR (NOT AUTOSTART). USED BY 16 BIT MULT & DIVIDE ROUTINES AS PSEUDO-ACCUMULATOR

\$0050-\$0051 (80-81) [DXL-DXH] \P2\HI-RES GRAPHICS DELTA-X FOR HLIN SHAPE
 \$0051 (81) [SHAPEX] \P1\ HI-RES GRAPHICS SHAPE TEMP.
 \$0052-\$0053 (82-83) [XTNDL-XTNDH] \P2\OLD MONITOR (NOT AUTOSTART) - USED IN 16-BIT MULT & DIVIDE AS ACCUMULATOR
 EXTENSION (TO 32 BITS)
 \$0052 (82) [TEMPPT] \P1\ APPLESOFT TEMPORARY POINT - LAST USED TEMPORARY STRING DESCRIPTOR (SEE DSCTMP)
 \$0052 (82) [DY] \P1\ HI-RES GRAPHICS DELTA-Y FOR HLIN SHAPE
 \$0053 (83) [LASTPT] \P1\ APPLESOFT LAST USED TEMPORARY STRING POINTER
 \$0053 (83) [QDRNT] \P1\ HI-RES GRAPHICS QDRNT: 2 LSB'S ARE ROTATION QUADRANT FOR DRAW
 \$0054-\$0055 (84-85) [AUXL-AUXH] \P2\OLD MONITOR (NOT AUTOSTART) - USED FOR 16-BIT MULT & DIVIDE AS AUXILLIARY REGISTER
 \$0054-\$0055 (84-85) [EL-EH] \P2\HI-RES GRAPHICS ERROR FOR HLIN
 \$0055 (85) APPLESOFT - START OF STRING SCRATCH AREA (LENGTH UNKNOWN - AT LEAST 3 BYTES)
 \$0058 (88) [SYNSTKH] INTEGER BASIC MEMORY LOCATION 'SYNSTKH'
 \$005E-\$005F (94-95) [INDEX] \P2\APPLESOFT TEMPORARY (STACK) POINTER FOR MOVING STRINGS
 \$0060-\$0061 (96-97) \P2\ APPLESOFT PARAMETER STORAGE SPACE FOR FLOATING POINT COMPARE ROUTINES
 \$0062-\$0066 (98-102) \P5\ RESULT OF LAST MULTIPLY/DIVIDE (APPLESOFT)
 \$0067-\$006A (103-106) \PB\ PAGE ZERO LOCATIONS USED BY DOS
 \$0067-\$0068 (103-104) [TEXTTAB] \P2\APPLESOFT TEXT TABLE POINTER (POINTS TO BEGINNING OF PROGRAM TEXT . DEFAULT
 VALUE \$0801
 \$0069-\$006A (105-106) [VARTAB:] \P2\APPLESOFT VARIABLE TABLE POINTER - POINTS TO START OF SIMPLE VARIABLE SPACE (AT
 END OF APPLESOFT PROGRAM TEXT)
 \$006B-\$006C (107-108) [ARYTAB] \P2\APPLESOFT ARRAY TABLE POINTER (POINTS TO BEGINNING OF ARRAY SPACE)
 \$006D-\$006E (109-110) [STREND] \P2\APPLESOFT STORAGE END POINTER (POINTS TO TOP OF ARRAY STORAGE I.E. TO END OF NUMERIC
 STORAGE IN USE)
 \$006F-\$0070 (111-112) \PB\ PAGE ZERO LOCATIONS USED BY DOS
 \$006F-\$0070 (111-112) [FRETOP] \P2\APPLESOFT POINTER TO END OF STRING STORAGE OR TOP OF USER-AVAILABLE FREE SPACE.
 DEFAULTS TO HIMEM - USUALLY \$BFFF FOR 48K APPLE)
 \$0071-\$0072 (113-114) [FRESPC] \P2\APPLESOFT TEMPORARY POINTER FOR STRING-STORAGE ROUTINES
 \$0073-\$0074 (115-116) [MEMSIZE] \P2\APPLESOFT HIMEM (HIGHEST LOC IN MEM AVAIL + 1). INIT TO HIGHEST RAM - \$BFFF FOR 48K
 APPLE IF DOS NOT ACTIVE BEGINNING OF DOS IF DOS ACTIVE
 \$0075-\$0076 (117-118) [CURLIN] \P2\APPLESOFT - LINE # OF LINE CURRENTLY BEING EXECUTED NOTE: HI BYTE OF CURLIN TESTED
 BY DOS FOR DIRECT-DEFERRED MODE USAGE - BYTE SET TO \$FF IN DIRECT. IF CONTENTS OF
 \$AAB6<>0 AND IF PROMPT=']' OR IF THIS LOCN CONTAINS \$FF DOS ASSUMES DIRECT MODE AND
 WILL NOT DO OPEN OR OTHER DIRECT MODE COMMANDS
 \$0077-\$0078 (119-120) [OLDLIN] \P2\APPLESOFT - LAST LINE EXECUTED - LINE # AT WHICH EXECUTION INTERRUPTED BY CTRL-C
 STOP ETC.
 \$0078-\$0097 (120-151) [NOUNSTKH] INTEGER BASIC MEMORY LOCATION 'NOUNSTKH' (NOUN STACK HI BYTE)
 \$0079-\$007A (121-122) [(OLD TEXT PTR)] \P2\APPLESOFT OLD TEXT PTR. PTS TO LOC IN MEM FOR NEXT STMT TO BE EXE
 \$007B-\$007C (123-124) [DATLIN] \P2\APPLESOFT CURRENT LINE # FROM WHICH DATA IS BEING READ
 \$007D-\$007E (125-126) [DATPTR] \P2\POINTS TO ABS LOC IN MEM FROM WHICH DATA IS BEING READ BY APPLESOFT
 \$007F-\$0080 (127-128) [(INP SOURCE PTR)] \P2\APPLESOFT - PTR TO CURRENT SOURCE OF INPUT. \$201 DURING INPUT STATEMENT IF
 STANDARD BUFFER IN USE
 \$0080-\$009F (128-159) [SYNSTKL] INTEGER BASIC MEMORY LOCATION 'SYNSTKL' (SYNTAX STACK LOCATION)
 \$0081-\$0082 (129-130) [(LAST VBL NAME)] \P2\APPLESOFT - HOLDS LAST-USED VARIABLE'S NAME
 \$0083-\$0084 (131-132) [VARPNT] \P2\APPLESOFT POINTER TO THE LAST-USED VARIABLE'S VALUE (USED BY PTRGET)
 \$0085-\$009C (133-156) \PB\ APPLESOFT GENERAL USAGE
 \$0085-\$0086 (133-134) [FORPNT] \P2\APPLESOFT GENERAL POINTER. SEE COPY SUBROUTINE FOR EXAMPLE
 \$008A-\$008E (138-142) [TEMP3] \P5\APPLESOFT REGISTER TEMP3 FOR FLOATING POINT MATH PACKAGE (PACKED 5-BYTE FORMAT)
 \$0090 (144) INITIALIZED TO \$4C (JMP)
 \$0093-\$0097 (147-151) [TEMP1] \P5\APPLESOFT REGISTER TEMP1 FOR FLOATING POINT MATH PACKAGE (PACKED 5-BYTE FORMAT)
 \$0094-\$0095 (148-149) [HIGHDS] \P2\USED BY BLOCK TRANSFER UTILITY (BLTU) AS HIGH DESTINATION
 \$0096-\$0097 (150-151) [HIGHTR] \P2\APPLESOFT - USED BY BLOCK TRANSFER UTILITY (BLTU) AS HIGH END OF BLOCK TO BE
 TRANSFERRED

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$0098-\$009C (152-156) [TEMP2] \P5\APPLESOFT FLOATING POINT MATH PACKAGE REGISTER TEMP2 (PACKED 5-BYTE FORMAT)

\$009B-\$009C (155-156) [LOWTR] \P2\APPLESOFT GENERAL PURPOSE REGISTER USED BY GETARYPT-FNDLN-BLTU (E.G. LOW END OF BLOCK TO BE TRANSFERRED IN BLTU)

\$009D-\$00A3 (157-163) [FAC] \P6\APPLESOFT MAIN FLOATING-POINT ACCUMULATOR (USES 6-BYTE UNPACKED MATH PACKAGE FORMAT DESCRIBED BELOW)

\$009D-\$009F (157-159) [DSCTMP] \P3\APPLESOFT TEMPORARY STRING DESCRIPTOR (SEE VALTYP & TEMPPT)

\$009D (157) [FACEXP] \P1\ EXPONENT BYTE OF FAC. SIGNED NUMBER IN EXCESS \$80 FORM (SIGNED VALUE HAS \$80 ADDED)

\$009E-\$00A1 (158-161) \P4\ FOUR BYTE MANTISSA OF FAC. BINARY POINT ASSUMED TO RIGHT OF MSB. NAMES OF BYTES IN MATH PACKAGE HO-MOH-MO-LO RESPECTIVELY.

\$009E (158) [FACHO] \P1\ HIGH ORDER BYTE OF MANTISSA OF FAC

\$009F (159) [FACMOH] \P1\ MIDDLE ORDER HIGH BYTE OF MANTISSA OF FAC

\$00A0-\$00BF (160-191) [NOUNSTKC] INTEGER BASIC MEMORY LOCATION 'NOUNSTKC' (NOUN STACK COUNTER)

\$00A0-\$00A1 (160-161) [FACMO-FACLO] \P2\POINTER TO STRING DESCRIPTOR USED IN STRING UTILITIES

\$00A0 (160) [FACMO] \P1\ MIDDLE ORDER BYTE OF MANTISSA OF FAC

\$00A1 (161) [FACLO] \P1\ LOW ORDER BYTE OF MANTISSA OF FAC

\$00A2 (162) [(FACSIGN)] \P1\ SINGLE BYTE SIGN OF FAC. WHILE IN MATH PKG SIGN IS KEPT IN SGN WHERE ONLY BIT 7 IS SIGNIFICANT

\$00A4 (164) GENERAL USE IN FLOATING POINT MATH ROUTINES

\$00A5-\$00AA (165-170) [ARG] \PB\APPLESOFT SECONDARY FLOATING POINT ACCUMULATOR (USES 6-BYTE UNPACKED MATH PACKAGE FORMAT DESCRIBED BELOW)

\$00A5 (165) [ARGEXP] \P1\ EXPONENT PART OF ARG. SINGLE BYTE SIGNED NUMBER IN EXCESS \$80 FORM (SIGNED VALUE HAS \$80 ADDED TO IT)

\$00A6-\$00A9 (166-169) \P4\ FOUR BYTE MANTISSA PART OF ARG. BINARY POINT ASSUMED TO RIGHT OF MSB. NAMES OF BYTES IN MATH PACKAGE HO-MOH-MO-LO RESPECTIVELY.

\$00A8-\$00C7 (168-199) [TXTNDXSTK] INTEGER BASIC MEMORY LOCATION 'TXTNDXSTK' (TEXT INDEX STACK)

\$00AA (170) \P1\ SIGN BYTE OF ARG (UNPACKED FORMAT). BYTE NAMED SGN

\$00AB-\$00AC (171-172) [STRNG1] \P2\APPLESOFT POINTER TO A STRING USED IN 'MOVINS' STRING UTILITY

\$00AC-\$00AE (172-174) \PB\ APPLESOFT GENERAL USAGE FLAGS/POINTERS

\$00AD-\$00AE (173-174) [STRNG2] \P2\APPLESOFT POINTER TO A STRING USED IN STRLT2 STRING UTILITY

\$00AF-\$00B0 (175-176) PAGE ZERO LOCATIONS USED BY DOS

\$00AF-\$00B0 (175-176) [PRGEND] \P2\APPLESOFT POINTER TO END OF PROGRAM. NOT CHANGED BY LOMEM:

\$00B1-\$00C8 (177-200) [CHRGET] \SB\APPLESOFT CHRGET ROUTINE. CALLED WHEN WANTS ANOTHER CHARACTER (X- Y-REGS NOT ALTERED)

\$00B1 (177) [CHRGET] \SE\ APPLESOFT CHRGET S/R CALL - GETS NEXT SEQUENTIAL CHR OR TOKEN - LOADS A-REG FROM LOCN SPECIFIED BY TXTPTR(\$00B8-\$00B9 & INCREMENTS TXTPTR. CARRY IS RESET TO ZERO IF CHARACTER IS A DIGIT OTHERWISE IT IS SET; ZERO FLAG SET IF CHAR =0 (END OF LINE SIGN) OR \$3A (END OF STATEMENT SIGN ':') OTHERWISE RESET (X- Y-REGS NOT ALTERED)

\$00B7 (183) [CHRGOT] \SE\ APPLESOFT CHRGOT S/R CALL. CHRGET INCREMENTS TXTPTR. CHRGOT DOES NOT

\$00B8-\$00B9 (184-185) [(LAST CHAR PTR)] \P2\APPLESOFT PTR TO LAST CHAR OBTAINED THRU CHRGET ROUTINE

\$00B8-\$00B9 (184-185) [TXTPTR] \P2\TXTPTR - POINTS AT NEXT CHAR OR TOKEN FROM PROG (C/A DEC 78)

\$00C8 (200) [OUTVAL] INTEGER BASIC MEMORY LOCATION 'OUTVAL' (OUTPUT VALUE TEMPORARY)

\$00C8 (200) [TXTNDX] INTEGER BASIC MEMORY LOCATION 'TXTNDX' (TEXT INDEX VALUE)

\$00C9-\$00CD (201-205) [RND] \P5\APPLESOFT FLOATING POINT RANDOM NUMBER (5-BYTE FLOATING POINT PACKED FORMAT C9=EXP CA-CD=MANTISSA)

\$00C9 (201) [LEADBL] INTEGER BASIC MEMORY LOCATION 'LEADBL' (LEADING BLANKS INDEX)

\$00C9 (201) [YTEMP] INTEGER BASIC MEMORY LOCATION 'YTEMP' (TEMPORARY STORAGE FOR Y-REGISTER)

\$00CA-\$00CD (202-205) \PB\ PAGE ZERO LOCATIONS USED BY DOS

\$00CA-\$00CB (202-203) [PPL-PPH] \P2\INTEGER BASIC PROGRAM POINTER (START-OF-PROGRAM EQUAL TO HIMEM IF NO PROGRAM)

\$00CC-\$00CD (204-205) [PVL-PVH] \P2\INTEGER BASIC CURRENT VARIABLE POINTER (END OF CURRENT VARIABLE EQUAL TO LOMEM IF NO ACTIVE CURRENT VARIABLE)

\$00CE-\$00CF (206-207) [ACL-ACH] \P2\INTEGER BASIC MAIN ACCUMULATOR

\$00CE-\$00CF (206-207) [-VALGETL-VALGETH] \P2\INTEGER BASIC PRIMARY EVALUATOR TEMPORARY LOCATION

\$00CE-\$00CF	(206-207)	[VALL-VALH]	\P2\INTEGER BASIC 16-BIT TEMPORARY VALUE FOR MATHEMATICAL OPERATIONS
\$00D0-\$00DF	(208-223)	\PB\	ONERR POINTERS/SCRATCH
\$00D0-\$00D1	(208-209)	[SRCHL-SRCHH]	\P2\INTEGER BASIC MEMORY LOCATION 'SRCHL' (POINTER TO SEARCH VARIABLE TABLE)
\$00D0	(208)	[ERRFLG]	\P1\ ERROR FLAG. ON IF BIT 7 SET (PEEK(216)>127). POKE 0 TO CLEAR.
\$00D1-\$00F0	(209-240)	[TOKNDXSTK]	INTEGER BASIC MEMORY LOCATION 'TOKNDXSTK' ('TOKEN INDEX STACK?')
\$00D2-\$00D3	(210-211)	\P2\	IF ONERR GOTO OCCURS CONTAINS ADDRESS OF LINE # OF STMT WHERE ERROR OCCURED
\$00D2-\$00D3	(210-211)	[SRCH2L-SRCH2H]	\P2\INTEGER BASIC MEMORY LOCATION 'SRCH2L' (SECOND VARIABLE SEARCH POINTER)
\$00D4	(212)	[IFSKIP]	\P1\ INTEGER BASIC MEMORY LOCATION 'IFSKIP' (IF\THEN FAIL FLAG)
\$00D5	(213)	[CRFLAG]	\P1\ INTEGER BASIC MEMORY LOCATION 'CRFLAG' (CARRIAGE RETURN FLAG)
\$00D6	(214)	[VERBNOW]	\P1\ INTEGER BASIC MEMORY LOCATION 'VERBNOW' (VERB CURRENTLY IN USE)
\$00D6	(214)	\P1\	APPLESOFT MYSTERY PARAMETER. IF SET TO \$80 MAKES ALL COMMANDS = RUN
\$00D7	(215)	[PRINOW]	\P1\ INTEGER BASIC MEMORY LOCATION 'PRINOW' (PRINT IT NOW FLAG)
\$00D8	(216)		PAGE ZERO LOCATION USED BY DOS (INFO FROM DCT RELATED TO MOTOR-ON TIME-REQUIREMENT?)
\$00D8	(216)	[ERRFLG]	\P1\ APPLESOFT ERROR FLAG: \$80 IF ONERR ACTIVE. SET TO 0 TO DISABLE 'ONERR GOTO'
\$00D8	(216)	[XSAVE]	\P1\ INTEGER BASIC MEMORY LOCATION 'XSAVE' (TEMPORARY STORAGE FOR CONTENTS OF X-REGISTER)
\$00D9	(217)	[RUNMODE]	\P1\ USED BY DOS TO TEST FOR DIRECT-DEFERRED MODE USAGE. IF \$AAB6 CONTAINS 0 AND BIT 7 OF THIS LOCATION IS CLEAR DOS ASSUMES DIRECT MODE AND WILL NOT DO OPEN OR OTHER DIRECT MODE COMMANDS
\$00D9	(217)	[RUNMODE]	\P1\ INTEGER BASIC MEMORY LOCATION 'RUNMODE' USED AS RUN MODE FLAG BYTE
\$00DA-\$00DB	(218-219)	[AUXL-AUXH]	\P2\INTEGER BASIC MEMORY LOCATIONS 'AUXL-AUXH' (AULILIARY COUNTER)
\$00DA-\$00DB	(218-219)	[ERRLIN]	\P2\APPLESOFT LINE # WHERE ERROR OCCURED
\$00DC-\$00DD	(220-221)	[ERRPOS]	\P2\APPLESOFT TEXPTR SAVE FOR HNDLERR SUBROUTINE
\$00DC-\$00DD	(220-221)	[PRL-PRH]	\P2\INTEGER BASIC MEMORY LOCATIONS 'PRL-PRH' (CURRENT LINE VALUE)
\$00DE-\$00DF	(222-223)	[PNL-PNH]	\P2\INTEGER BASIC MEMORY LOCATIONS 'PNL-PNH' (CURRENT NOUN POINTER)
\$00DE	(222)	[ERRNUM]	\P1\ APPLESOFT - WHEN ERROR OCCURS" TYPE-OF-ERROR CODE APPEARS HERE - SEE MANUAL FOR CODE NUMBER MEANINGS
\$00DF	(223)	[ERRSTK]	\P1\ APPLESOFT STACK POINTER VALUE BEFORE ERROR OCCURED
\$00E0-\$00E1	(224-225)	[PXL-PXH]	\P2\INTEGER BASIC MEMORY LOCATIONS 'PXL-PXH' (CURRENT VERB POINTER)
\$00E0-\$00E1	(224-225)	\P2\	HIGH-RES GRAPHICS X-COORDINATE
\$00E2	(226)	\P1\	HIGH-RES GRAPHICS Y-COORDINATE
\$0032-\$00E3	(50-227)	[P1L-P1H]	\P2\INTEGER BASIC MEMORY LOCATIONS 'P1L-P1H' (AUXILIARY POINTER ONE)
\$00E2-\$00E3	(226-227)	[DELL-DELH]	\P2\INTEGER BASIC MEMORY LOCATIONS 'DELL-DELH' (DELETE LINE POINTER)
\$00E4-\$00E5	(228-229)	[LNAL-LNAH]	\P2\INTEGER BASIC MEMORY LOCATIONS 'LNAL-LNAH' (LINE NUMBER ADDRESS)(NEXT LINE NUMBER)
\$00E4-\$00E5	(228-229)	[P2L-P2H]	\P2\INTEGER BASIC MEMORY LOCATIONS 'P2L-P2H' (AUXILIARY POINTER TWO)
\$00E4	(228)	\P1\	HI-RES GRAPHICS COLOR BYTE
\$00E4	(228)	[FLAG]	INTEGER BASIC MEMORY LOCATION 'FLAG' (GENERAL FLAG BYTE)
\$00E5-\$00E7	(229-231)	\PB\	GENERAL USAGE FOR HI-RES GRAPHICS
\$00E5	(229)	\P1\	HI-RES GRAPHICS HORIZONTAL BYTE INDEX FOR CURRENT POSITION(?)
\$00E6-\$00E7	(230-231)	[NXTL-NXTH]	\P2\INTEGER BASIC MEMORY LOCATIONS 'NXTL-NXTH' (NEXT POINTER)
\$00E6-\$00E7	(230-231)	[P3L-P3H]	\P2\INTEGER BASIC MEMORY LOCATIONS 'P3L-P3H' (AUXILIARY POINTER THREE)
\$00E6	(230)	[HPAG]	\P1\ HI-RES PAGE TO PLOT ON REGARDLESS OF WHICH PAGE BEING DISPLAYED - \$20 FOR PG1; \$40 FOR PG2
\$00E7	(231)	[SCALE]	\P1\ HI-RES GRAPHICS SCALE FACTOR
\$00E8-\$00E9	(232-233)	\P2\	HI-RES GRAPHICS POINTER TO BEGINNING OF SHAPE TABLE
\$00EA	(234)	\P1\	COLLISION COUNTER FOR HI-RES GRAPHICS
\$00F0-\$00F3	(240-243)	\PB\	GENERAL USE FLAGS
\$00F0	(240)	[FIRST]	\P1\ APPLESOFT - USED BY UTILITY PLOTfNS FOR DESTINATION OF FIRST NUMBER OF LO-RES PLOT COORDINATES
\$00F1	(241)	[SPDBYT]	\P1\ USED FOR SPEED CONTROL OF OUTPUT & DISPLAY. SPEED 0-255 (\$00-\$FF) CONTROLS INSERTED DELAY)
\$00F1	(241)	[TOKNDX]	\P1\ INTEGER BASIC MEMORY LOCATION 'TOKNDX' (TOKEN INDEX VALUE)

\$00F2~\$00F3 (242~243) [CONL~CONH] \P2\INTEGER BASIC MEMORY LOCATIONS 'CONL~CONH' (CONTINUE POINTER)
 \$00F3 (243) [ORMASK] \P1\ MASK FOR OUTPUT CONTROL: NORMAL/FLASHING/INVERSE
 \$00F3 (243) [SIGN] \P1\ MONITOR & FLOATING POINT ROUTINES MEMORY LOC 'SIGN'
 \$00F4~\$00F8 (244~248) \PB\ ONERR POINTERS
 \$00F4~\$00F7 (244~247) [FP1] \P4\MONITOR & FLOATING POINT ROUTINES FLOATING POINT ACCUMULATOR 2 (CONTAINS X2 & M2)
 \$00F4~\$00F5 (244~245) [AUTOINCL~AUTOINCH] \P2\INTEGER BASIC MEMORY LOCATIONS 'AUTOINCL~AUTOINCH' (CURRENT AUTO LINE
 NUMBER VALUE)
 \$00F4 (244) [X2] \P1\ MONITOR & OLD (NON-APPLESOFT) FLOATING POINT ROUTINES FLOATING POINT ACCUMULATOR 2
 MEMORY LOC 'X2' (EXPONENT)
 \$00F5~\$00F7 (245~247) [M2] \P3\ MONITOR & OLD (NON-APPLESOFT) FLOATING POINT ACCUMULATOR 2 MEMORY LOC 'M2' (MANTISSA -
 3 BYTES)
 \$00F6~\$00F7 (246~247) [AUTOLNL~AUTOLNH] \P2\INTEGER BASIC MEMORY LOCATIONS 'AUTOLNL~AUTOLNH'
 \$00F7 (247) [S16PAG] \P\ SWEET-16 MEMORY LOCATION 'S16PAG'
 \$00F8~\$00FE (248~254) [FP1] \P6\OLD (NON-APPLESOFT) FLOATING POINT ROUTINES FLOATING POINT ACCUMULATOR FP1 (CONTAINS X1
 M1 AND E (EXTENSION))
 \$00F8 (248) [AUTCMODE] \P1\ INTEGER BASIC MEMORY LOCATION 'AUTOMODE' (THE AUTOMODE FLAG)
 \$00F8 (248) [X1] OLD (NON-APPLESOFT) FLOATING POINT ROUTINES FLOATING POINT ACCUMULATOR FP1 MEMORY LOC
 'X1' (EXPONENT)
 \$00F8 (248) [REMSTK] \P1\ APPLESOFT STACK POINTER SAVED BEFORE EACH STATEMENT
 \$00F9~\$00FB (249~251) [M1] \P3\ FLOATING POINT ROUTINES FLOATING POINT ACCUMULATOR FP1 MEMORY LOC 'M1' (MANTISSA)
 \$00F9 (249) [CHAR] \P1\ INTEGER BASIC MEMORY LOCATION 'CHAR' (CURRENT CHARACTER)
 \$00F9 (249) [COUNT] \P1\ INTEGER BASIC MEMORY LOCATION 'COUNT'
 \$00FA (250) [LEAD2R] \P1\ INTEGER BASIC MEMORY LOCATION 'LEADZR' (LEADING ZEROS INDEX)
 \$00FB (251) [FORNDX] \P1\ INTEGER BASIC MEMORY LOCATION 'FORNDX' (FOR-NEXT LOOP INDEX)
 \$00FC~\$00FE (252~254) [E] \P3\ MONITOR & FLOATING POINT ROUTINES MEMORY LOC 'E' (3 BYTE MANTISSA EXTENTION OF FP
 ACCUMULATOR 1)
 \$00FC (252) [GOSUBNDX] \P1\ INTEGER BASIC MEMORY LOCATION 'GOSUBNDX' (GOSUB INDEX)
 \$00FD (253) [SYNSTKDX] \P1\ INTEGER BASIC MEMORY LOCATION 'SYNSTKDX' (SYNTAX STACK INDEX VALUE)
 \$00FE~\$00FF (254~255) [SYNPAGL~SYNPAGH] INTEGER BASIC SYNTAX PAGE POINTER. IF \$00FF NOT ZERO THEN ERROR CONDITION EXISTS
 \$0100~\$01FF (256~511) \HB\ APPLE SYSTEM STACK. MANY USES INCLUDING SUBROUTINE RETURN STACK
 \$0100~\$01FF (256~511) THIS PAGE IS THE STACK USED BY DOS 3.2 TO GET THE SLOTNUMBER IN WHICH THE BOOT DISK IS
 LOCATED
 \$0100~\$0110 (256~272) [FOUT] \PB\FOUT BUFFER
 \$0200~\$02FF (512~767) [BUF INBUFF] \HB\KEYIN (CHARACTER INPUT) BUFFER (MONITOR~INTEGER BASIC~APPLESOFT BASIC)
 \$0200 (512) [IN] MONITOR & MINIASSEMBLER MEMORY LOCATION 'IN'
 \$0300~\$03FF (768~1023) \HB\ MEMORY PAGE 3 (MONITOR VECTOR MEMORY PAGE - BUT MONITOR VECTORS ONLY IN \$03F0~\$0EFF)
 \$0300~\$03E7 (768~999) \HB\ BLOCK OFTEN AVAILABLE AS FREE SPACE FOR USER PROGRAMS. NOTE CONSTRAINTS & COMPETING
 USES
 \$0300~\$03FF (768~1023) \HB\ FIRST STAGE OF DOS 3.2 BOOT USES THIS AREA FOR PART 1 OF THE NIBBLE BUFFER. THEN LATER
 DOS 3.2 BOOT USES IT FOR CODE. AREA CLOBBERED BY EITHER MASTER OR SLAVE DISKETTE BOOT.
 READS DATA FROM TRACK 0; SECTORS 0-9 INTO MEMORY AT \$B600~\$BFFF (48K MACHINE) SLAVE
 DISKETTE OR \$3600~\$3FFF FOR A MASTER DISKETTE
 \$0300~\$03AF (768~943) \SB\ EXAMPLE: DECWRITER PRINTER OUTPUT FOR SERIAL COMMUNICATIONS CARD (BLOADED FROM DISK)
 \$0301 (769) \SE\ DOS 3.2 BOOT PROCESS JUMPS HERE AFTER ROM BOOT IS FINISHED. TRANSFER (ENTRY) POINT FOR
 ENTRY TO PART 2 OR STAGE 2 OF DOS 3.2 BOOT. READS IN RWTS & ITS SUBPROGRAMS
 \$0320~\$0321 (800~801) [XOL~XOH] \P2\HI-RES GRAPHICS- PRIOR X-COORD SAVE AFTER HLIN OR HPLT
 \$0322 (802) [YO] \P1\ HI-RES GRAPHICS YO - MOST RECENT Y-COORDINATE
 \$0323 (803) [BXSAY] HI-RES GRAPHICS 'BXSAY'
 \$0324 (804) [HCOLOR] \P1\ HI-RES GRAPHICS COLOR FOR HPLT~ HPOSN
 \$0325 (805) [HNDX] \P1\ HI-RES ON-THE-FLY BYTE INDEX FROM BASE ADDRESS TO CURRENT PLOT BYTE (FUNCTION OF
 CURRENT X-COORD)

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$0326 (806) [HPAG] \P1\ HI-ORDER BYTE OF START ADDR OF CURRENT HI-RES DISPLAY MEM PG (POKE 32 FOR HI-RES PG1 ~ 64 FOR PG2)
 \$0326 (806) [HPAG] \P1\ HI-RES GRAPHICS MEM PAGE FOR PLOTTING GRAPHICS \$20 FOR PG1 ~\$40 FOR PG2
 \$0327 (807) [SCALE] \P1\ ON-THE-FLY SCALE FACTOR FOR DRAW~ SHAPE~ MOVE
 \$0328~\$0329 (808~809) [SHAPXL~SHA] \P2\START-OF-SHAPE-TABLE POINTER
 \$032A (810) [COLLSN] \P1\ COLLISION COUNT FROM DRAW~DRAW1
 \$0399 (921) DOS 3.2 OFFSET IN THE 1ST NIBBLE BUFFER USED IN RECONSTRUCTING THE REAL DATA
 \$03CC (972) DOS 3.2 OFFSET IN THE FIRST NIBBLE BUFFER USED IN RECONSTRUCTING THE REAL DATA
 \$03D0~\$03E0 (976~992) \SB\ BLOCK OF COMMANDS ETC. COPIED FROM \$9E50~\$9E80 ON DOS 3.2 300T TO CONTROL TRANSFERS TO SOFT ENTRY~ HARD ENTRY~ I-O PKG~ RWTS AND TO GET END OF SYSTEM BUFFER~ IOB ADDRESS~ AND TO UPDATE I-O HOOKS~ AND DO JUMP TRANSFERS TO AUTO BRK ENTRY~ CTRL~Y ENTRY~ NMI ENTRY AND PROVIDE IRQ ADDRESS
 \$03D0 (976) [(3D0G)] \SE\ DOS 3.2 SOFT-ENTRY POINT; I.E. RE-ENTRY POINT (3D0G) FOR RE-INITIALIZATION SAVING ALL VARIABLES & DATA OF CURRENT BASIC PROGRAM (JMP \$9DBF)
 \$03D3 (979) \SE\ DOS 3.1/3.2 HARD ENTRY POINT; I.E. RE-INITIALIZATION DESTROYS ALL INFORMATION RELATING TO CURRENT BASIC PROGRAM (JMP \$9D84)
 \$03D6 (982) \SE\ DOS 3.1~3.2 ENTRY POINT FOR I~O PACKAGE (JMP \$AAFD)
 \$03D9 (985) \SE\ DOS 3.1~3.2 ENTRY POINT FOR RWTS (JMP \$B7B5)
 \$03DC (988) \SE\ DOS 3.1~3.2 ENTRY POINT TO LOAD Y~A WITH ADDRESS AT END OF SYS BUFFER
 \$03E3 (995) [995] \SE\ DOS 3.1~3.2 ENTRY POINT TO LOAD Y~A WITH ADDRESS OF IOBLK
 \$03EA (1002) [1002] \SE\ DOS 3.2 ENTRY POINT FOR ROUTINE THAT UPDATES I/O HOOK TABLES IN \$0036~\$0039. (JMP \$A851 - SAVES ADDRESSES OF CHARACTER INPUT & OUTPUT ROUTINES CURRENTLY IN USE AND RECONNECTS DOS I/O)
 \$03EA (1002) [(LOAD DOS 3.2 REGS)] \SE\RECONNECT DOS 3.2 VIA APPLE MONITOR REGS. PREVIOUS CONTENTS OF MONITOR I/O REGS (\$0036~\$0039) TO DOS 3.2 INPUT & OUTPUT REGS (DOS 3.2 REGS ALTERED)
 \$03F0~\$03F1 (1008~1009) [BRKV] \P2\AUTOSTART ROM BREAK VECTOR - DEFAULT VALUE \$FA59
 \$03F2~\$03F3 (1010~1011) [SOFTEV] \P2\AUTOSTART ROM RESET VECTOR USED FOR SOFT ENTRY TO LANGUAGE IN USE - DEFAULT VALUE \$E003 FOR APPLESOFT
 \$03F4 (1012) [PWREDUP] \P1\ AUTOSTART ROM POWER UP MASK. SET BY SETPWRC TO EXCLUSIVE 'OR' OF \$03F3 & \$00A5
 \$03F5~\$03F7 (1013~1015) [AMPERV] APPLESOFT - HOLDS JMP (JUMP) INSTRUCTION TO S/R WHICH HANDLES & COMMANDS. DEFAULT \$4C \$58 \$FF (JUMP TO \$FF58)
 \$03F8~\$03FA (1016~1018) HOLDS JMP (JUMP) INSTRUCTION TO S/R WHICH HANDLES 'USER' COMMANDS (E.G. CTRL-Y)
 \$03F8 (1016) [USRADR] IN MONITOR MODE KEYBOARD ENTRY OF CTL-Y WILL CAUSE JSR HERE
 \$03FB~\$03FD (1019~1021) HOLDS JMP (JUMP) INSTRUCTION TO S/R WHICH HANDLES NON-MASKABLE INTERRUPTS
 \$03FB (1019) [NMI] NMI'S VECTORED TO THIS LOCATION
 \$03FE~\$03FF (1022~1023) [IRQADR~IRQLOC] \P2\IRQ'S VECTORED BY POINTER HERE TO SUBROUTINE TO HANDLE INTERRUPT REQUESTS
 \$0400~\$07FF (1024~2047) \HB\ SCREEN BUFFER (MEMORY PAGES 4~7)(LOW-RES GRAPHICS & TEXT PAGE 1); CONSISTS OF 8 SUBPAGES: EACH CONTAINING 3 TEXT LINES OF 40 (\$27) CHARACTERS EACH FOLLOWED BY 8 BYTES WHICH ARE USED AS INPUT-OUTPUT PARAMETERS - ONE BYTE FOR EACH SLOT (0~7). LINES ARE INTERLACED DOWN PAGE: I.E. FIRST SUBPAGE CONTAINS LINES 1~9~17 & FIRST BLOCK OF I-O BYTES; SECOND SUBPAGE CONTAINS LINES 2~10~18 & SECOND BLOCK OF I-O BYTES; THIRD SUBPAGE CONTAINS LINES 3~11~19 & THIRD BLOCK OF I-O BYTES ETC.
 \$0400~\$0477 (1024~1143) [(MACROLINE)] \HB\TEXT VIDEO SCREEN DISPLAY PAGE 1 - MACROLINE ORSUBPAGE CONSISTING OF LINES 0 ~ 8 & 16
 \$0400~\$0427[(LO-RESLNS0/1)] \BB\ VIDEO SCREEN BUFFER LO-RES LINES 0 AND 1
 \$0400~\$0427[(TEXTLN0)] \BB\ VIDEO SCREEN BUFFER TEXT LINE 0
 \$0428~\$044F[(LO-RESLNS16/17)] \BB\VIDEO SCREEN BUFFER LO-RES LINES 16 AND 17
 \$0428~\$044F[(TEXTLN8)] \BB\ VIDEO SCREEN BUFFER TEXT LINE 8
 \$0450~\$0477[(LO-RESLNS32/33)] \BB\VIDEO SCREEN BUFFER LO-RES LINES 32 AND 33
 \$0450~\$0477[(TEXTLN16)] \BB\ VIDEO SCREEN BUFFER TEXT LINE 16
 \$0478+S (1144+S) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #S

\$0478+S (1144+S) [BRATE] \P1\ EXAMPLE: SERIAL INTERFACE BAUD QUANTUM RATE. \$1= 19200 BAUD;\$40=300 BAUD
 \$0478+S (1144+S) [DVOTRK] \P1\ EXAMPLE: 'DRVOTRK'= DISK DRIVE 0 CURRENT TRACK (VALUE = 2*TRACK#); DOS 3.2 PARAMETER FOR DISK IN SLOT #S
 \$0478 (1144) [CURTRK] \P1\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) PARAMETER CURRENT TRACK (LAST TRACK 'SEEK'-ED)
 \$0478-\$047F (1144-1151) SCRATCHPAD BYTES FOR I/O PERIPHERALS - ONE BYTE FOR EACH PERIPHERAL 'SLOT' 0 THRU 7
 \$0479 (1145) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #1
 \$047A (1146) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #2
 \$047B (1147) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #3
 \$047C (1148) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #4
 \$047D (1149) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #5
 \$047E (1150) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #6
 \$047F (1151) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #7
 \$0480-\$04A7[(LO-RESLNS2/3)] \BB\ VIDEO SCREEN BUFFER LO-RES LINES 2 AND 3
 \$0480-\$04A7[(TEXTLN1)] \BB\ VIDEO SCREEN BUFFER TEXT LINE 1
 \$0480-\$04F7 (1152-1271) [(MACROLINE1)] \HB\TEXT PAGE 1 - MACROLINE OR SUBPAGE CONSISTING OF 3 TEXT LINES OF 40 BYTES (CHARACTERS) EACH PLUS A BLOCK OF 8 I-O PERIPHERAL BYTES. SUBSEQUENT MACROLINES WILL BE OMITTED FROM DATABASE
 \$04A8-\$04CF[(LO-RESLNS18/19)] \BB\VIDEO SCREEN BUFFER LO-RES LINES 18 AND 19
 \$04A8-\$04CF[(TEXTLN9)] \BB\ VIDEO SCREEN BUFFER TEXT LINE 9
 \$04D0-\$04F7[(LO-RESLNS34/35)] \BB\VIDEO SCREEN BUFFER LO-RES LINES 34 AND 35
 \$04D0-\$04F7[(TEXTLN17)] \BB\ VIDEO SCREEN BUFFER TEXT LINE 17
 \$04F8+S (1272+S) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #S
 \$04F8+S (1272+S) [DRV1TRK] \P1\ EXAMPLE: 'DRV1TRK' = DISK DRIVE 1 CURRENT TRACK (VALUE = 2*TRACK#); DOS 3.2 PARAMETER FOR DISK IN SLOT #S
 \$04F8+S (1272+S) [STBITS] \P1\ EXAMPLE: APPLE SERIAL INTERFACE IN SLOT #S: CONTAIN NUMBER OF STOP BITS (INCLUDING 1 PARITY BIT)
 \$04F8 (1272) \P1\ SCRATCHPAD MEMORY BYTE USED BY DOS 3.2 (SHARED BY ALL PERIPHERAL CARDS)
 \$04F8-\$04FF (1272-1279) \HB\ TEXT PAGE 1 - BLOCK OF 8 I-O PERIPHERAL BYTES ONE FOR EACH SLOT (0-7)
 \$04F9 (1273) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #1
 \$04FA (1274) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #2
 \$04FB (1275) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #3
 \$04FB (1275) [SEEKCN] \P1\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) SEEK COUNTER PARAMETER
 \$04FC (1276) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #4
 \$04FD (1277) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #5
 \$04FE (1278) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #6
 \$04FF (1279) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #7
 \$0500-\$0527[(LO-RESLNS4/5)] \BB\ VIDEO SCREEN BUFFER LO-RES LINES 4 AND 5
 \$0500-\$0527[(TEXTLN2)] \BB\ VIDEO SCREEN BUFFER TEXT LINE 2
 \$0500-\$0577 (1280-1399) [(TEXTMACROLINE2)] \HB\TEXTVIDEO DISPLAY - SUBPAGE 2. CONSISTS OF TEXT LINES 2- 10 & 18 FOLLOWED BY AN 8-BYTE BLOCK FOR I-O PERIPHERALS
 \$0528-\$054F[(LO-RESLNS20/21)] \BB\VIDEO SCREEN BUFFER LO-RES LINES 20 AND 21
 \$0528-\$054F[(TEXTLN10)] \BB\ VIDEO SCREEN BUFFER TEXT LINE 10
 \$0550-\$0577[(LO-RESLNS36/37)] \BB\VIDEO SCREEN BUFFER LO-RES LINES 36 AND 37
 \$0550-\$0577[(TEXTLN18)] \BB\ VIDEO SCREEN BUFFER TEXT LINE 18
 \$0578+S (1400+S) \P1\ EXAMPLE APPLE PARALLEL PRINTER INTERFACE IN SLOT #S: CARRIAGE WIDTH. E.G. POKE 1400+S-80 FOR 80 COLUMN PRINT WIDTH
 \$0578+S (1400+S) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT#S
 \$0578+S (1400+S) [STATUS] \P1\ EXAMPLE: APPLE SERIAL INTERFACE IN SLOT #S: PARITY CHECKSUM OPTIONS (SEE MANUAL)
 \$0578 (1400) \P1\ SCRATCHPAD MEMORY BYTE USED BY DOS 3.2 (SHARED BY ALL PERIPHERAL CARDS)
 \$0578-\$057F (1400-1407) \HB\ BLOCK OF SCRATCH PAD BYTES FOR PERIPHERALS IN SLOTS 0-7
 \$0579 (1401) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #1

.....

\$06F8+S (1784+S) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #S
 \$06F8 (1784) \P1\ SCRATCHPAD MEMORY BYTE USED BY DOS (SHARED BY ALL PERIPHERAL CARDS)
 \$06F9 (1785) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #1
 \$06FA (1786) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #2
 \$06FB (1787) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #3
 \$06FC (1788) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #4
 \$06FD (1789) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #5
 \$06FE (1790) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #6
 \$06FF (1791) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #7
 \$0700-\$0727[(LO-RESLNS12/13)] \BB\VIDEO SCREEN BUFFER LO-RES LINES 12 AND 13
 \$0700-\$0727[(TEXTLN6)] \BB\VIDEO SCREEN BUFFER TEXT LINE 6
 \$0728-\$074F[(LO-RESLNS28/29)] \BB\VIDEO SCREEN BUFFER LO-RES LINES 28 AND 29
 \$0728-\$074F[(TEXTLN14)] \BB\VIDEO SCREEN BUFFER TEXT LINE 14
 \$0750-\$0777[(LO-RESLNS44/45)] \BB\VIDEO SCREEN BUFFER LO-RES LINES 44 AND 45
 \$0750-\$0777[(TEXTLN22)] \BB\VIDEO SCREEN BUFFER TEXT LINE 22
 \$0778+S (1912+S) \P1\ EXAMPLE: APPLE COMMUNICATIONS INTERFACE CARD IN SLOT #S - VIDEO ECHO (SEE ACIC MANUAL PAGE 17). E.G. POKE 1912+S~0 FOR NO VIDEO ECHO
 \$0778+S (1912+S) \P1\ EXAMPLE: APPLE PARALLEL PRINTER INTERFACE CARD IN SLOT #S - VIDEO & LINEFEED STATUS (HIGH BIT CONTROLS VIDEO; LOW BIT CONTROLS L.F.). E.G. POKE 1912+S~1 FOR NO VIDEO LF-ENABLE. POKE 1912+S~128 FOR VIDEO-ENABLE NO LF. (CENTRONICS VERSION OF APPI DOES NOT HAVE LF OPTIONS ACTIVATED)
 \$0778+S (1912+S) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #S
 \$0778+S (1912+S) [NBITS] \P1\EXAMPLE: APPLE SERIAL INTERFACE IN SLOT #S NUMBER OF DATA BITS PLUS 1 FOR START BIT
 \$0778 (1912) \P1\ SCRATCHPAD MEMORY BYTE USED BY DOS 3.2 (SHARED BY ALL PERIPHERAL CARDS)
 \$0779 (1913) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #1
 \$077A (1914) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #2
 \$077B (1915) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #3
 \$077C (1916) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #4
 \$077D (1917) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #5
 \$077E (1918) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #6
 \$077F (1919) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #7
 \$0780-\$07A7[(LO-RESLNS14/15)] \BB\VIDEO SCREEN BUFFER LO-RES LINES 14 AND 15
 \$0780-\$07A7[(TEXTLN7)] \BB\VIDEO SCREEN BUFFER TEXT LINE 7
 \$07A8-\$07CF[(LO-RESLNS30/31)] \BB\VIDEO SCREEN BUFFER LO-RES LINES 30 AND 31
 \$07A8-\$07CF[(TEXTLN15)] \BB\VIDEO SCREEN BUFFER TEXT LINE 15
 \$07D0-\$07F7[(LO-RESLNS46/47)] \BB\VIDEO SCREEN BUFFER LO-RES LINES 46 AND 47
 \$07D0-\$07F7[(TEXTLN23)] \BB\VIDEO SCREEN BUFFER TEXT LINE 23
 \$07F8+S (2040+S) \P1\ INTERRUPT RETURN MEMORY BYTE FOR PERIPHERAL IN SLOT #S (LOAD WITH \$00CS)
 \$07F8+S (2040+S) [FLAGS] \P1\EXAMPLE: APPLE SERIAL INTERFACE IN SLOT #S OPERATION MODE
 \$07F8+S (2040+S) [STAT] \P1\APPLE COMMUNICATIONS INTERFACE CARD IN SLOT #S - STATUS (SEE ACIC MANUAL PG 17). E.G. POKE 2040+S~17
 \$07F8 (2040) [(SLOT #)] CONTAINS SLOT NUMBER (IN THE FORMAT \$CS) OF THE PERIPHERAL CARD CURRENTLY ACTIVE - PRINT PEEK(2040)-192 YIELDS SLOT # IN DECIMAL FORMAT
 \$07F8 (2040) \P1\ SCRATCHPAD MEMORY BYTE USED BY DOS 3.2 (SHARED BY ALL PERIPHERAL CARDS)
 \$07F9 (2041) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #1
 \$07FA (2042) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #2
 \$07FB (2043) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #3
 \$07FC (2044) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #4
 \$07FD (2045) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #5
 \$07FE (2046) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #6
 \$07FF (2047) \P1\ SCRATCHPAD MEMORY BYTE FOR PERIPHERAL IN SLOT #7

\$0800-\$C000 (2048-16384)	RANGE OF POSSIBLE SETTINGS FOR HIMEM (DEPENDING UPON MEM SIZE- DOS 3.2 ETC.)
\$0800-\$3003 (2048-12291)	APPLESOFT - AREA OCCUPIED BY RAM VERSION (AS OPPOSED TO ROM OR LANGUAGE PACK VERSION) - MOST LOCATIONS IN ATLAS ARE GIVEN AT ROM LOCATIONS. USE OFFSET TO TRANSFER TO RAM LOCATIONS
\$0800-\$03FF (2048-3071) [(LO-RES PAGE 2)] \HB\	SECONDARY SCREEN BUFFER (TEXT & LOW-RES GRAPHICS PAGE 2)
\$0800-\$0BFF (2048-3071) \SB\	NORMAL LOCATION FOR HI-RES SUBROUTINES (INTEGER BASIC)
\$0800-\$09FF (2048-2559) \HB\	*NIBBLE* BUFFER AREA FOR PART 2 OF DOS 3.2 BOOT. CLOBBERED BY ANY DOS 3.2 BOOT.
\$0800-LOMEM	PROGRAM STORAGE FOR ROM VERSION OF APPLESOFT
\$0800 (2048)	DEFAULT INTEGER BASIC LOMEM
\$0801-\$084C (2049-2124) \SB\	DOS 3.3 - PHASE 2 OF BOOT FROM SECTOR ZERO ON TRACK ZERO - FIRST RAM BOOTSTRAP LOADER (BOOT1). THIS ROUTINE LOADS THE SECOND RAM LOADER; BOOT 2 INCLUDING RWTS; INTO MEMORY AND JUMPS TO IT. USES \$081F FOR SLOT#; \$08FE FOR BOOT2 MEM PG; \$08FE FOR BOOT2 LENGTH
\$081F (2079) \SE\	DOS 3.3 - PHASE 2 OF BOOT - FIRST RAM BOOTSTRAP LOADER. GETS SECTOR TO READ. IF ZERO GOTO \$0839. TRANSLATES THEORETICAL SECTOR NUMBER INTO PHYSICAL SECTOR NUMBER BY INDEXING INTO SKEWING TABLE AT \$084D. DECREMENTS \$08FF (THEORETICAL SECTOR #). SETS UP PARAMETERS FOR ROM S/R \$C65C AND JUMPS TO IT. (IT RETURNS TO \$0801 WHEN SECTOR READ)
\$0839 (2105) \SE\	DOS 3.3 - PHASE 2 OF BOOT - FIRST RAM BOOTSTRAP LOADER (BOOT1). ADJUSTS PAGE NUMBER AT \$08FE TO LOCATE ENTRY POINT OF BOOT2. INITIALIZES MONITOR (TEXT MODE - STD WINDOW ETC.). GOTO BOOT2 (\$3700 FOR A MASTER DISK; \$B700 IN ITS FINAL RELOCATED LOCN)
\$08A0 (2208) \SB\	DURING DOS 3.2 BOOT AREA STARTING HERE HOLDS THE DISK -> NIBBLE TRANSLATE TABLE
\$0C00-\$1FFF (3072-8191) \HB\	OFTEN FREE SPACE UNLESS RAM\DISK APPLESOFT IN USE)
\$0C00 (3072) \HB\	DEFAULT LOCATION FOR START OF SHAPE TABLE AS SET BY HI-RES SHAPE LOAD S/R
\$0C3C (3132) \SE\	DOS 3.2\APPLESOFT TRANSFER POINT TO RAM APPLESOFT (DISK AS OPPOSED TO ROM OR LANGUAGE PACK VERSION) USED BY DOS 3.2 FOR SOFT ENTRY
\$0CF2 (3314) \SE\	APPLESOFT - SET (OR RESET) POINTERS & LINKAGES FOR RAM APPLESOFT STORED AT \$0800-\$3003 (2048-12291)
\$0CF2 (3314) \SE\	APPLESOFT - TO CNVRT A/S PROG FROM FIRMWARE (ROM OR LANGUAGE CARD) TO RAM (A/S STORED IN \$0800-\$3003): LOAD PROG- CALL 3314-LIST-SAVE
\$1067 (4199) \SE\	DOS 3.2\APPLESOFT TRANSFER POINT USED BY DOS 3.2 INTO RAM (DISK AS OPPOSED TO ROM OR LANGUAGE PACK) VERSION OF APPLESOFT WHEN PROCESSING ERRORS
\$1B00-\$3FFF (6912-16383) \SB\	THIS REGION OF MEMORY IS CLOBBERED BY A SLAVE DISKETTE BOOT
\$1B00-\$3FFF (6912-16383) \SB\	TEMP LOCATION OF RAWDOS 3.2 DURING DOS 3.2 BOOT
\$1B00-\$1CFF (6912-7423) [SB]	TEMPORARY LOCATION OF DOS 3.2 RELOCATION CODE DURING DOS 3.2 BOOT (SB)
\$1DBF (7615) \SE\	ROUTINE TO RECONNECT DOS 3.2 IF PAGE 3 MONITOR LINKAGES OVERWRITTEN (16K APPLE ONLY)
\$2000-\$3FFF (8192-16383) [(HI-RES P1)] \HB\	HI-RES GRAPHICS PAGE 1
\$2000-\$2027 (8192-8231) [(HIRES P1L000)] \HB\	HI-RES GRAPHICS: PAGE 1 - LINE #000
\$2028-\$204F (8232-8271) [(HIRES P1L064)] \HB\	HI-RES GRAPHICS: PAGE 1 - LINE #064
\$2050-\$2077 (8272-8311) [(HIRES P1L128)] \HB\	HI-RES GRAPHICS: PAGE 1 - LINE #128
\$2080-\$20A7 (8312-8359) [(HIRES P1L008)] \HB\	HI-RES GRAPHICS: PAGE 1 - LINE #008
\$20A8-\$20CF (8360-8399) [(HIRES P1L072)] \HB\	HI-RES GRAPHICS: PAGE 1 - LINE #072
\$20D0-\$20E7 (8400-8423) [(HIRES P1L136)] \HB\	HI-RES GRAPHICS: PAGE 1 - LINE #136
\$2100-\$2127 (8448-8487) [(HIRES P1L016)] \HB\	HI-RES GRAPHICS: PAGE 1 - LINE #016
\$2128-\$214F (8488-8527) [(HIRES P1L80)] \HB\	HI-RES GRAPHICS: PAGE 1 - LINE #80
\$2150-\$217F (8528-8575) [(HIRES P1L144)] \HB\	HI-RES GRAPHICS: PAGE 1 - LINE #144
\$2180-\$21A7 (8576-8615) [(HIRES P1L024)] \HB\	HI-RES GRAPHICS: PAGE 1 - LINE #024
\$21A8-\$21CF (8616-8655) [(HIRES P1L088)] \HB\	HI-RES GRAPHICS: PAGE 1 - LINE #088
\$21D0-\$21F7 (8656-8695) [(HIRES P1L152)] \HB\	HI-RES GRAPHICS: PAGE 1 - LINE #152
\$2200-\$2227 (8704-8743) [(HIRES P1L032)] \HB\	HI-RES GRAPHICS: PAGE 1 - LINE #032


```

$2228~$224F (8744~8783) [(HIRES P1L096)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #096
$2250~$2277 (8784~8823) [(HIRES P1L160)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #160
$2280~$22A7 (8832~8871) [(HIRES P1L040)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #040
$22A8~$22CF (8872~8911) [(HIRES P1L104)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #104
$22D0~$22F7 (8912~8951) [(HIRES P1L168)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #168
$2300~$2327 (8960~8999) [(HIRES P1L048)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #048
$2328~$234F (9000~9039) [(HIRES P1L112)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #112
$2350~$237F (9040~9087) [(HIRES P1L176)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #176
$2380~$23A7 (9088~9127) [(HIRES P1L056)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #056
$23A8~$23CF (9128~9167) [(HIRES P1L120)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #120
$23D0~$23F7 (9168~9207) [(HIRES P1L184)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #184
$2400~$2427 (9216~9255) [(HIRES P1L001)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #001
$2428~$244F (9256~9295) [(HIRES P1L065)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #065
$2450~$2477 (9296~9335) [(HIRES P1L129)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #129
$2480~$24A7 (9344~9383) [(HIRES P1L009)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #009
$24A8~$24CF (9384~9423) [(HIRES P1L073)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #073
$24D0~$24E7 (9424~9447) [(HIRES P1L137)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #137
$2500~$2527 (9472~9511) [(HIRES P1L017)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #017
$2528~$254F (9512~9551) [(HIRES P1L081)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #081
$2550~$257F (9552~9599) [(HIRES P1L145)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #145
$2580~$25A7 (9600~9639) [(HIRES P1L025)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #025
$25A8~$25CF (9640~9679) [(HIRES P1L089)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #089
$25D0~$25F7 (9680~9719) [(HIRES P1L153)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #153
$2600~$2627 (9728~9767) [(HIRES P1L033)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #033
$2628~$264F (9768~9807) [(HIRES P1L097)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #097
$2650~$2677 (9808~9847) [(HIRES P1L161)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #161
$2680~$26A7 (9856~9895) [(HIRES P1L041)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #041
$26A8~$26CF (9896~9935) [(HIRES P1L105)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #105
$26D0~$26F7 (9936~9975) [(HIRES P1L169)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #169
$2700~$2727 (9984~10023) [(HIRES P1L049)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #049
$2728~$274F (10024~10063) [(HIRES P1L113)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #113
$2750~$277F (10064~10111) [(HIRES P1L177)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #177
$2780~$27A7 (10112~10151) [(HIRES P1L057)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #057
$27A8~$27CF (10152~10191) [(HIRES P1L121)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #121
$27D0~$27F7 (10192~10231) [(HIRES P1L185)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #185
$2800~$2827 (10240~10279) [(HIRES P1L002)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #002
$2828~$284F (10280~10319) [(HIRES P1L066)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #066
$2850~$2877 (10320~10359) [(HIRES P1L130)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #130
$2880~$28A7 (10368~10407) [(HIRES P1L010)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #010
$28A8~$28CF (10408~10447) [(HIRES P1L074)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #074
$28D0~$28E7 (10448~10471) [(HIRES P1L138)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #138
$2900~$2927 (10496~10535) [(HIRES P1L018)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #018
$2928~$294F (10536~10575) [(HIRES P1L082)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #082
$2950~$297F (10576~10623) [(HIRES P1L146)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #146
$2980~$29A7 (10624~10663) [(HIRES P1L026)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #026
$29A8~$29CF (10664~10703) [(HIRES P1L090)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #090
$29D0~$29F7 (10704~10743) [(HIRES P1L154)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #154
$2A00~$2A27 (10752~10791) [(HIRES P1L034)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #034
$2A28~$2A4F (10792~10831) [(HIRES P1L098)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #098
$2A50~$2A77 (10832~10871) [(HIRES P1L162)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #162
$2A80~$2AA7 (10880~10919) [(HIRES P1L042)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #042

```

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$2AA8-$2ACF (10920-10959) [(HIRES P1L106)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #106
$2AD0-$2AF7 (10960-10999) [(HIRES P1L170)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #170
$2B00-$2B27 (11008-11047) [(HIRES P1L050)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #050
$2B28-$362F (11048-13871) [(HIRES P1L114)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #114
$2B50-$2B7F (11088-11135) [(HIRES P1L178)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #178
$2B80-$2BA7 (11136-11175) [(HIRES P1L058)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #058
$2BA8-$2BCF (11176-11215) [(HIRES P1L122)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #122
$2BD0-$2BF7 (11216-11255) [(HIRES P1L186)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #186
$2C00-$2C27 (11264-11303) [(HIRES P1L003)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #003
$2C28-$2C4F (11304-11343) [(HIRES P1L067)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #067
$2C50-$2C77 (11344-11383) [(HIRES P1L131)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #131
$2C80-$2CA7 (11392-11431) [(HIRES P1L011)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #011
$2CA8-$2CCF (11432-11471) [(HIRES P1L075)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #075
$2CD0-$2CE7 (11472-11495) [(HIRES P1L139)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #139
$2D00-$2D27 (11520-11559) [(HIRES P1L019)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #019
$2D28-$2D4F (11560-11599) [(HIRES P1L083)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #083
$2D50-$2D7F (11600-11647) [(HIRES P1L147)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #147
$2D80-$2DA7 (11648-11687) [(HIRES P1L027)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #027
$2DA8-$2DCF (11688-11727) [(HIRES P1L091)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #091
$2DD0-$2DF7 (11728-11767) [(HIRES P1L155)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #155
$2E00-$2E27 (11776-11815) [(HIRES P1L035)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #035
$2E28-$2E4F (11816-11855) [(HIRES P1L099)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #099
$2E50-$2E77 (11856-11895) [(HIRES P1L163)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #163
$2E80-$2EA7 (11904-11943) [(HIRES P1L043)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #043
$2EA8-$2ECF (11944-11983) [(HIRES P1L107)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #107
$2ED0-$2EF7 (11984-12023) [(HIRES P1L171)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #171
$2F00-$2F27 (12032-12071) [(HIRES P1L051)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #051
$2F28-$2F4F (12072-12111) [(HIRES P1L115)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #115
$2F50-$2F7F (12112-12159) [(HIRES P1L179)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #179
$2F80-$2FA7 (12160-12199) [(HIRES P1L059)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #059
$2FA8-$2FCF (12200-12239) [(HIRES P1L123)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #123
$2FD0-$2FF7 (12240-12279) [(HIRES P1L187)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #187
$3000-LOMEM\SB\
$3000-$3027 (12288-12327) [(HIRES P1L004)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #004
$3003 (12291) APPLESOFT - DISKETTE APPLESOFT FP SETS LOMEM TO THIS VALUE
$3028-$304F (12328-12367) [(HIRES P1L068)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #068
$3050-$3077 (12368-12407) [(HIRES P1L132)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #132
$3080-$30A7 (12416-12455) [(HIRES P1L012)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #012
$30A8-$30CF (12456-12495) [(HIRES P1L076)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #076
$30D0-$30E7 (12496-12519) [(HIRES P1L140)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #140
$3100-$3127 (12544-12583) [(HIRES P1L020)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #020
$3128-$314F (12584-12623) [(HIRES P1L084)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #084
$3150-$317F (12624-12671) [(HIRES P1L148)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #148
$3180-$31A7 (12672-12711) [(HIRES P1L028)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #028
$31A8-$31CF (12712-12751) [(HIRES P1L092)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #092
$31D0-$31F7 (12752-12791) [(HIRES P1L156)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #156
$3200-$3227 (12800-12839) [(HIRES P1L036)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #036
$3228-$324F (12840-12879) [(HIRES P1L100)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #100
$3250-$3277 (12880-12919) [(HIRES P1L164)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #164
$3280-$32A7 (12928-12967) [(HIRES P1L044)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #044
$32A8-$32CF (12968-13007) [(HIRES P1L108)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #108

```

```

$32D0-$32F7 (13008-13047) [(HIRES P1L172)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #172
$3300-$3327 (13056-13095) [(HIRES P1L045)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #045
$3328-$334F (13096-13135) [(HIRES P1L116)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #116
$3350-$337F (13136-13183) [(HIRES P1L180)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #180
$3380-$33A7 (13184-13223) [(HIRES P1L060)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #060
$33A8-$33CF (13224-13263) [(HIRES P1L124)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #124
$33D0-$33F7 (13264-13303) [(HIRES P1L188)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #188
$3400-$3427 (13312-13351) [(HIRES P1L005)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #005
$3428-$344F (13352-13391) [(HIRES P1L069)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #069
$3450-$3477 (13392-13431) [(HIRES P1L133)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #133
$3480-$34A7 (13440-13479) [(HIRES P1L013)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #013
$34A8-$34CF (13480-13519) [(HIRES P1L077)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #077
$34D0-$34E7 (13520-13543) [(HIRES P1L141)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #141
$3500-$3527 (13568-13607) [(HIRES P1L021)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #021
$3528-$354F (13608-13647) [(HIRES P1L085)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #085
$3550-$357F (13648-13695) [(HIRES P1L149)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #149
$3580-$35A7 (13696-13735) [(HIRES P1L029)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #029
$35A8-$35CF (13736-13775) [(HIRES P1L093)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #093
$35D0-$35F7 (13776-13815) [(HIRES P1L157)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #157
$3600-$3627 (13824-13863) [(HIRES P1L037)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #037
$3628-$364F (13864-13903) [(HIRES P1L101)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #101
$3650-$3677 (13904-13943) [(HIRES P1L165)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #165
$3680-$36A7 (13952-13991) [(HIRES P1L045)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #045
$36A8-$36CF (13992-14031) [(HIRES P1L109)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #109
$36D0-$36F7 (14032-14071) [(HIRES P1L173)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #173
$3700 (14080) DOS 3.3 - START OF BOOT2 AREA FOR A MASTER DISK
$3700-$3727 (14080-14119) [(HIRES P1L053)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #053
$3728-$374F (14120-14159) [(HIRES P1L117)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #117
$3750-$377F (14160-14207) [(HIRES P1L181)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #181
$3780-$37A7 (14208-14247) [(HIRES P1L061)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #061
$37A8-$37CF (14248-14287) [(HIRES P1L125)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #125
$37D0-$37F7 (14288-14327) [(HIRES P1L189)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #189
$3800-$3827 (14336-14375) [(HIRES P1L006)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #006
$3828-$384F (14376-14415) [(HIRES P1L070)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #070
$3850-$3877 (14416-14455) [(HIRES P1L134)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #134
$3880-$38A7 (14464-14503) [(HIRES P1L014)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #014
$38A8-$38CF (14504-14543) [(HIRES P1L078)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #078
$38D0-$38E7 (14544-14567) [(HIRES P1L142)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #142
$3900-$3927 (14592-14631) [(HIRES P1L022)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #022
$3928-$394F (14632-14671) [(HIRES P1L086)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #086
$3950-$397F (14672-14719) [(HIRES P1L150)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #150
$3980-$39A7 (14720-14759) [(HIRES P1L030)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #030
$39A8-$39CF (14760-14799) [(HIRES P1L094)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #094
$39D0-$39F7 (14800-14839) [(HIRES P1L158)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #158
$3A00-$3A27 (14848-14887) [(HIRES P1L038)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #038
$3A28-$3A4F (14888-14927) [(HIRES P1L102)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #102
$3A50-$3A77 (14928-14967) [(HIRES P1L166)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #166
$3A80-$3AA7 (14976-15015) [(HIRES P1L046)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #046
$3AA8-$3ACF (15016-15055) [(HIRES P1L110)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #110
$3AD0-$3AF7 (15056-15095) [(HIRES P1L174)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #174
$3B00-$3B27 (15104-15143) [(HIRES P1L054)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #054

```

```

$3B28-$362F (15144-13871) [(HIRES P1L118)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #118
$3B50-$3B7F (15184-15231) [(HIRES P1L182)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #182
$3B80-$3BA7 (15232-15271) [(HIRES P1L062)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #062
$3BA8-$3BCF (15272-15311) [(HIRES P1L126)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #126
$3BD0-$3BF7 (15312-15351) [(HIRES P1L190)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #190
$3C00-$3C27 (15360-15399) [(HIRES P1L007)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #007
$3C28-$3C4F (15400-15439) [(HIRES P1L071)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #071
$3C50-$3C77 (15440-15479) [(HIRES P1L135)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #135
$3C80-$3CA7 (15488-15527) [(HIRES P1L015)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #015
$3CA8-$3CCF (15528-15567) [(HIRES P1L079)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #079
$3CD0-$3CE7 (15568-15591) [(HIRES P1L143)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #143
$3D00-$3D27 (15616-15655) [(HIRES P1L023)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #023
$3D00-$3E93 (15616-16027) [RWTS] \SB\DOS 3.1/3.2 RWTS SUBROUTINE
$3D00 (15616) [RWTS] \SE\ DOS 3.1/3.2 READ\WRITE A TRACK & SECTOR. UPON ENTRY A- & Y-REGS POINT AT I/O
CONTROL BLOCK (IOB)
$3D1E (15646) [STILLON] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL STARTS CODE WHICH SENSES IF
MOTOR STILL ON
$3D23 (15651) [NOTSURE] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL - AT THIS POINT PROGRAM NOT
SURE WHETHER MOTOR IS RUNNING (STABLE LONG ENOUGH)
$3D28-$3D4F (15656-15695) [(HIRES P1L087)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #087
$3D2D (15661) [SAMESLOT] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL - STARTS CODE TO DETERMINE IF
SAME SLOT BEING USED
$3D44 (15684) [PTRMOV] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL - STARTS CODE TO MOVE OUT ALL
POINTERS FROM IOB (IN-OUT-BLOCK) TO ZERO PAGE
$3D50-$3D7F (15696-15743) [(HIRES P1L151)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #151
$3D5E (15710) [OK] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL - STARTS CODE THAT IT IS OKAY
TO CONTINUE
$3D67 (15719) [DRVSEL] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL
$3D7D (15741) [MOTOF] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL - STARTSCODE TO DELAY UNTIL
MOTOR UP TO SPEED
$3D7F (15743) [CONWAIT] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL - STARTS CONSTANT WAIT DELAY
LOOP RETURN POINT
$3D80-$3DA7 (15744-15783) [(HIRES P1L031)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #031
$3D8A (15754) [TRYTRK] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL - TRY DISK TRACK AS PART OF
LOCATING CORRECT SECTOR FOR READ
$3D9B (15771) [TRYTRK2] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL 'TRYTRK2'
$3DA0 (15776) [TRYADR] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK SECTOR) INTERIOR LABEL 'TRYADR'
$3DA8-$3DCF (15784-15823) [(HIRES P1L095)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #095
$3DA8 (15784) [TRYADR2] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK SECTOR) INTERIOR LABEL 'TRYADR2'
$3DC1 (15809) [GOCAL] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL - GO CALCULATE CORRECT TRACK
$3DC7 (15815) [RDRIGHT] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL WHICH STARTS CODE TO
DETERMINE IF ONE IS READING CORRECT TRACK SECTOR AND VOLUME
$3DD0-$3DF7 (15824-15863) [(HIRES P1L159)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #159
$3DDE (15838) [DRVERR] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL - STARTS CODE FOR CLEANUP
WHEN DRIVE ERROR DETECTED
$3DE1 (15841) [JMPT01] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL 'JMPT01'
$3DE2 (15842) [JMPTOERR] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL 'JMPTOERR' (JUMP TO ERROR
HANDING ROUTINE HNDLERR)
$3DF0 (15856) [RTTRK] \SL\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL WHICH ASSUMES RIGHT TRACK
SELECTED AND BEGINS CHECK OF CORRECT VOLUME NUMBER ON DISKETTE
$3E00-$3E27 (15872-15911) [(HIRES P1L039)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #039

```


HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$3E06 (15878) [CORRECTVOL] \SL\      DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL WHICH ASSUMES CORRECT VOLUME
                                     HAS BEEN DETECTED AND CHECKS FOR SECTOR SELECTION
$3E15 (15893) [JJTOER] \SL\          DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL 'JJTOER'
$3E17 (15895) [CORRECTSECT] \SL\     DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL AT START OF CODE WHICH ASSUME
                                     SECTOR CORRECTLY CHOSEN AND JUMPS TO APPROPRIATE SUBROUTINE TO READ OR WRITE
$3E27 (15911) [ALLDONE] \SL\         DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL 'ALLDONE'
$3E28~$3E4F (15912~15951) [(HIRES P1L103)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #103
$3E29 (15913) [HNDLERR] \SL\        DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL AT START OF ERROR HANDLING
                                     MODULE
$3E32 (15922) [WRIT] \SL\            DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL AT START OF CODE TO WRITE
                                     VIBBLES TO DISK IF NOT WRITE PROTECTED
$3E3B (15931) [MYSEEK] \SE\          DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL AT START OF ROUTINE WHICH
                                     SEEKS TRACK 'N' IN SLOT #X/$10. (IF DRIVEN0 IS - THEN DRIVE 0; IF DRIVEN0 IS + THEN
                                     DRIVE 1
$3E4C (15948) [SEEK] \SE\            DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL AT SOFT ENTRY POINT OF SEEK
                                     SUBROUTINE
$3E50~$3E77 (15952~15991) [(HIRES P1L167)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #167
$3E67 (15975) [ESDF0] \SL\          DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL 'WASDO'
$3E75 (15989) [ISDRV0] \DL\         DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL 'ISDRV0'
$3E78 (15992) [GOSEEK] \DL\         DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL 'GOSEEK'
$3E7B (15995) [XT0Y] \DL\           DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL 'XT0Y'
$3E80~$3EA7 (16000~16039) [(HIRES P1L047)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #047
$3E82 (16002) [SETTRK] \SM\         DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL - CODE SETS THE
                                     SLOT-DEPENDENT TRACK LOCATION
$3E8F (16015) [SETTRK2] \SM\        DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL 'SETTRK2'
$3E9B (16027) [ONDRV0] \DL\         DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) INTERIOR LABEL 'ONDRV0'
$3E9C~$3FD4 (16028~16340) [DSKFORM] \SB\DOS 3.2 DISK FORMATTER PACKAGE
$3E9C~$3ED9 (16028~16089) [DSKFORM] \SB\DOS 3.2 DISK FORMATTER MODULE TO FILL TRACK WITH SYNC
$3E9C (16028) [DSKFORM] \SE\        DOS 3.2 DISK FORMATTER ENTRY POINT - TURN MOTOR ON & FILL TRACK WITH SYNC
$3EA8~$3ECF (16040~16079) [(HIRES P1L111)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #111
$3EAB (16043) [DSKF2] \SL\          DOS 3.2 DISK FORMATTER LABEL AT POINT WHERE MOTOR IS RUNNING AND ON TRACK 0. BEGINS
                                     CODE WHICH FORMATS THIS TRACK
$3EAE (16046) [TRKFRM] \SL\         DOS 3.2 DISK FORMATTER LABEL AT POINT WHERE TRACK FORMATTING BEGINS
$3EC4 (16068) [WRTRK] \SL\          DOS 3.2 DISK FORMATTER - LABEL AT POINT WHERE WRITE OF FORMATTING INFO ONTO TRACK
                                     BEGINS -- A HIGHLY TIMING-SENSITIVE AREA OF CODE
$3ECA (16074) [CONSYNC] \SL\        DOS 3.2 DISK FORMATTER - LABEL AT POINT WHERE CONSTRUCTION OF SYNC BEGINS
$3ED0~$3EF7 (16080~16119) [(HIRES P1L175)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #175
$3ED6 (16086) [NXTPRT] \SL\         DOS 3.2 DISK FORMATTER - LABEL AT POINT WHERE CHECK IS MADE TO SEE IF TRACK DONE
$3EDA~$3F72 (16090~16242) \SB\      DOS 3.2 DISK FORMATTER BLOCK OF CODE TO DO SECTOR-BY-SECTOR FORMATTING ON TRACK
                                     ALREADY FILLED WITH SELF-SYNC
$3EDE (16094) [RGTIM] \SL\          DOS 3.2 DISK FORMATTER INTERIOR LABEL 'RGTIM'
$3EE0 (16096) [FRMWSYNC] \SL\       DOS 3.2 DISK FORMATTER INTERIOR LABEL 'FRMWSYNC'
$3EE2 (16098) [WRIT2] \SL\          DOS 3.2 DISK FORMATTER INTERIOR LABEL 'WRIT2'
$3EE6 (16102) [WRITSF] \SL\         DOS 3.2 DISK FORMATTER INTERIOR LABEL 'WRITSF'
$3EE7 (16103) [WRIT3] \SL\         DOS 3.2 DISK FORMATTER INTERIOR LABEL 'WRIT3'
$3F00~$3F27 (16128~16167) [(HIRES P1L055)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #055
$3F28~$3F4F (16168~16207) [(HIRES P1L119)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #119
$3F40 (16192) [FAKESCT] \SL\        DOS 3.2 DISK FORMATTER INTERIOR LABEL 'FAKESCT' AT BEGINNING OF CODE TO WRITE FAKE
                                     SECTOR
$3F46 (16198) [INTOIT] \SL\         DOS 3.2 DISK FORMATTER INTERIOR LABEL 'INTOIT'
$3F50~$3F7F (16208~16255) [(HIRES P1L183)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #183

```

\$3E06 - \$3F50

Prof. Luebbert's "What's Where in the Apple"

NUMERIC ATLAS

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$3F50 (16208) [NXTTRY] \SL\      DOS 3.2 DISK FORMATTER INTERIOR LABEL 'NXTTRY'
$3F80-$3FA7 (16256-16295) [(HIRES P1L063)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #063
$3FC6 (16326) [CHGIT] \SL\      DOS 3.2 DISK FORMATTER INTERIOR LABEL 'CHGIT'
$3F73-$3FD4 (16243-16340) [TRKDON] \SB\DOS 3.2 DISK FORMATTER CHECK TRACK FORMATTING ROUTINE
$EF73 (-4237) [TRKDON] \SE\      DOS 3.2 DISK FORMATTER INTERIOR LABEL AT POINT WHERE TRACK FORMATTING IS DONE AND
                                CHECKING OF THAT FORMATTING BEGINS
$3F80 (16256) [WLOOP] \SL\      DOS 3.2 DISK FORMATTER INTERIOR LABEL AT BEGINNING OF 26 MICROSECOND WAIT LOOP
$3F94 (16276) [NOGOOD] \SL\      DOS 3.2 DISK FORMATTER INTERIOR LABEL AT BEGINNING OF CLEAN UP IF NOGOOD CONDITION
                                DETECTED
$3F9E (16286) [ITSGOOD] \SL\      DOS 3.2 DISK FORMATTER INTERIOR LABEL AT BEGINNING OF CONTINUATION IF GOOD
                                CONDITION DETECTED
$3FA8-$3FCF (16296-16335) [(HIRES P1L127)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #127
$3FB3 (16307) [DRIVERR] \SL\      DOS 3.2 DISK FORMATTER INTERIOR LABEL AT BEGINNING OF CLEANUP IF DRIVE ERROR IS
                                DETECTED
$3FB8 (16312) [DONEDSK] \SL\      DOS 3.2 DISK FORMATTER INTERIOR LABEL AT POINT WHERE DISK IS COMPLETED AND NO
                                ERRORS HAVE BEEN DETECTED
$3FBB (16315) [WBYTE] \SL\      DOS 3.2 DISK FORMATTER INTERIOR LABEL AT BEGINNING OF TIGHT TIMING ROUTINE
$3FCA (16330) [WNIBLA] \SL\      DOS 3.2 DISK FORMATTER INTERIOR LABEL 'WNIBLA'
$3FCB (16331) [WINBLB2] \SL\      DOS 3.2 DISK FORMATTER INTERIOR LABEL 'WINBLB2'
$EFCD (-4147) [WINBLC] \SL\      DOS 3.2 DISK FORMATTER INTERIOR LABEL 'WINBLC'
$EFCE (-4146) [WRNIBL] \SL\      DOS 3.2 DISK FORMATTER INTERIOR LABEL 'WRNIBL'
$3FD0-$3FF7 (16336-16375) [(HIRES P1L191)] \HB\HI-RES GRAPHICS: PAGE 1 - LINE #191
$4000-$5FFF (16384-24575) [(HI-RES PAGE 2)] \HB\HI-RES GRAPHICS PAGE 2
$4000-$4520 (16384-17696) \PB\      NORMAL LOCATION FOR MANY HI RES TEXT SETS - E.G. KAPOR'S
$4000-$4027 (16384-16423) [(HIRES P2L000)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #000
$4028-$404F (16424-16463) [(HIRES P2L064)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #064
$4050-$4077 (16464-16503) [(HIRES P2L128)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #128
$4080-$40A7 (16512-16551) [(HIRES P2L008)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #008
$40A8-$40CF (16552-16591) [(HIRES P2L072)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #072
$40D0-$40E7 (16592-16615) [(HIRES P2L136)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #136
$4100-$4127 (16640-16679) [(HIRES P2L016)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #016
$4128-$414F (16680-16719) [(HIRES P2L080)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #080
$4150-$417F (16720-16767) [(HIRES P2L144)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #144
$4180-$41A7 (16768-16807) [(HIRES P2L024)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #024
$41A8-$41CF (16808-16847) [(HIRES P2L038)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #088
$41D0-$41F7 (16848-16887) [(HIRES P2L152)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #152
$4200-$4227 (16896-16935) [(HIRES P2L032)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #032
$4228-$424F (16936-16975) [(HIRES P2L096)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #096
$4250-$4277 (16976-17015) [(HIRES P2L160)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #160
$4280-$42A7 (17024-17063) [(HIRES P2L040)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #040
$42A8-$42CF (17064-17103) [(HIRES P2L104)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #104
$42D0-$42F7 (17104-17143) [(HIRES P2L168)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #168
$4300-$4327 (17152-17191) [(HIRES P2L048)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #048
$4328-$434F (17192-17231) [(HIRES P2L112)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #112
$4350-$437F (17232-17279) [(HIRES P2L176)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #176
$4380-$43A7 (17280-17319) [(HIRES P2L056)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #056
$43A8-$43CF (17320-17359) [(HIRES P2L120)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #120
$43D0-$43F7 (17360-17399) [(HIRES P2L184)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #184
$4400-$4427 (17408-17447) [(HIRES P2L001)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #001
$4428-$444F (17448-17487) [(HIRES P2L065)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #065
$4450-$4477 (17488-17527) [(HIRES P2L129)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #129

```

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$4480~$44A7 (17536~17575) [(HIRES P2L009)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #009
$44A8~$44CF (17576~17615) [(HIRES P2L073)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #073
$44D0~$44E7 (17616~17639) [(HIRES P2L137)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #137
$4500~$4527 (17664~17703) [(HIRES P2L017)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #017
$4528~$454F (17704~17743) [(HIRES P2L081)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #081
$4550~$457F (17744~17791) [(HIRES P2L145)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #145
$4580~$45A7 (17792~17831) [(HIRES P2L025)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #025
$45A8~$45CF (17832~17871) [(HIRES P2L089)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #089
$45D0~$45F7 (17872~17911) [(HIRES P2L153)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #153
$4600~$4627 (17920~17959) [(HIRES P2L033)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #033
$4628~$464F (17960~17999) [(HIRES P2L97)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #97
$4650~$4677 (18000~18039) [(HIRES P2L161)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #161
$4680~$46A7 (18048~18087) [(HIRES P2L041)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #041
$46A8~$46CF (18088~18127) [(HIRES P2L105)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #105
$46D0~$46F7 (18128~18167) [(HIRES P2L169)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #169
$4700~$4727 (18176~18215) [(HIRES P2L049)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #049
$4728~$474F (18216~18255) [(HIRES P2L113)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #113
$4750~$477F (18256~18303) [(HIRES P2L177)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #177
$4780~$47A7 (18304~18343) [(HIRES P2L057)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #057
$47A8~$47CF (18344~18383) [(HIRES P2L121)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #121
$47D0~$47F7 (18384~18423) [(HIRES P2L185)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #185
$4800~$4827 (18432~18471) [(HIRES P2L002)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #002
$4828~$484F (18472~18511) [(HIRES P2L066)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #066
$4850~$4877 (18512~18551) [(HIRES P2L130)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #130
$4880~$48A7 (18560~18599) [(HIRES P2L010)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #010
$48A8~$48CF (18600~18639) [(HIRES P2L074)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #074
$48D0~$48E7 (18640~18663) [(HIRES P2L138)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #138
$4900~$4927 (18688~18727) [(HIRES P2L018)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #018
$4928~$494F (18728~18767) [(HIRES P2L082)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #082
$4950~$497F (18768~18815) [(HIRES P2L146)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #146
$4980~$49A7 (18816~18855) [(HIRES P2L026)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #026
$49A8~$49CF (18856~18895) [(HIRES P2L090)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #090
$49D0~$49F7 (18896~18935) [(HIRES P2L154)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #154
$4A00~$4A27 (18944~18983) [(HIRES P2L034)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #034
$4A28~$4A4F (18984~19023) [(HIRES P2L098)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #098
$4A50~$4A77 (19024~19063) [(HIRES P2L162)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #162
$4A80~$4AA7 (19072~19111) [(HIRES P2L042)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #042
$4AA8~$4ACF (19112~19151) [(HIRES P2L106)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #106
$4AD0~$4AF7 (19152~19191) [(HIRES P2L170)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #170
$4B00~$4B27 (19200~19239) [(HIRES P2L050)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #050
$4B28~$4B4F (19240~19263) [(HIRES P2L114)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #114
$4B50~$4B7F (19280~19327) [(HIRES P2L178)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #178
$4B80~$4BA7 (19328~19367) [(HIRES P2L058)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #058
$4BA8~$4BCF (19368~19407) [(HIRES P2L122)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #122
$4BD0~$4BF7 (19408~19447) [(HIRES P2L186)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #186
$4C00~$4C27 (19456~19495) [(HIRES P2L003)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #003
$4C28~$4C4F (19496~19535) [(HIRES P2L067)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #067
$4C50~$4C77 (19536~19575) [(HIRES P2L131)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #131
$4C80~$4CA7 (19584~19623) [(HIRES P2L011)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #011
$4CA8~$4CCF (19624~19663) [(HIRES P2L075)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #075
$4CD0~$4CE7 (19664~19687) [(HIRES P2L139)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #139

```

\$4480 - \$4CD0

Prof. Luebbert's "What's Where in the Apple"

NUMERIC ATLAS

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$4D00~$4D27 (19712~19751) [(HIRES P2L019)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #019
$4D28~$4D4F (19752~19791) [(HIRES P2L083)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #083
$4D50~$4D7F (19792~19839) [(HIRES P2L147)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #147
$4D80~$4DA7 (19840~19879) [(HIRES P2L027)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #027
$4DA8~$4DCF (19880~19919) [(HIRES P2L091)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #091
$4DD0~$4DF7 (19920~19959) [(HIRES P2L155)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #155
$4E00~$4E27 (19968~20007) [(HIRES P2L035)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #035
$4E28~$4E4F (20008~20047) [(HIRES P2L099)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #099
$4E50~$4E77 (20048~20087) [(HIRES P2L163)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #163
$4E80~$4EA7 (20096~20135) [(HIRES P2L043)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #043
$4EA8~$4ECF (20136~20175) [(HIRES P2L107)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #107
$4ED0~$4EF7 (20176~20215) [(HIRES P2L171)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #171
$4F00~$4F27 (20224~20263) [(HIRES P2L051)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #051
$4F28~$4F4F (20264~20303) [(HIRES P2L115)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #115
$4F50~$4F7F (20304~20351) [(HIRES P2L179)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #179
$4F80~$4FA7 (20352~20391) [(HIRES P2L059)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #059
$4FA8~$4FCF (20392~20431) [(HIRES P2L123)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #123
$4FD0~$4FF7 (20432~20471) [(HIRES P2L187)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #187
$5000~$5027 (20480~20519) [(HIRES P2L004)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #004
$5028~$504F (20520~20559) [(HIRES P2L068)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #068
$5050~$5077 (20560~20599) [(HIRES P2L132)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #132
$5080~$50A7 (20608~20647) [(HIRES P2L012)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #012
$50A8~$50CF (20648~20687) [(HIRES P2L076)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #076
$50D0~$50E7 (20688~20711) [(HIRES P2L140)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #140
$5100~$5127 (20736~20775) [(HIRES P2L020)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #020
$5128~$514F (20776~20815) [(HIRES P2L084)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #084
$5150~$517F (20816~20863) [(HIRES P2L148)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #148
$5180~$51A7 (20864~20903) [(HIRES P2L028)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #028
$51A8~$51CF (20904~20943) [(HIRES P2L092)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #092
$51D0~$51F7 (20944~20983) [(HIRES P2L156)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #156
$5200~$5227 (20992~21031) [(HIRES P2L036)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #036
$5228~$524F (21032~21071) [(HIRES P2L100)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #100
$5250~$5277 (21072~21111) [(HIRES P2L164)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #164
$5280~$52A7 (21120~21159) [(HIRES P2L044)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #044
$52A8~$52CF (21160~21199) [(HIRES P2L108)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #108
$52D0~$52F7 (21200~21239) [(HIRES P2L172)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #172
$5300~$5327 (21248~21287) [(HIRES P2L045)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #045
$5328~$534F (21288~21327) [(HIRES P2L116)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #116
$5350~$537F (21328~21375) [(HIRES P2L180)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #180
$5380~$53A7 (21376~21415) [(HIRES P2L060)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #060
$53A8~$53CF (21416~21455) [(HIRES P2L124)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #124
$53D0~$53F7 (21456~21495) [(HIRES P2L188)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #188
$5400~$5427 (21504~21543) [(HIRES P2L005)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #005
$5428~$544F (21544~21583) [(HIRES P2L069)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #069
$5450~$5477 (21584~21623) [(HIRES P2L133)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #133
$5480~$54A7 (21632~21671) [(HIRES P2L013)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #013
$54A8~$54CF (21672~21711) [(HIRES P2L077)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #077
$54D0~$54E7 (21712~21751) [(HIRES P2L141)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #141
$5500~$5527 (21760~21799) [(HIRES P2L021)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #021
$5528~$554F (21800~21839) [(HIRES P2L085)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #085
$5550~$557F (21840~21887) [(HIRES P2L149)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #149

```


HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$5580-$55A7 (21888-21927) [(HIRES P2L029)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #029
$55A8-$55CF (21928-21967) [(HIRES P2L093)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #093
$55D0-$55F7 (21968-22007) [(HIRES P2L157)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #157
$5600-$8000 (22016-32768) \SB\ DOS (32K APPLE ONLY) - DISK OPERATING SYSTEM
$5600-$5627 (22016-22055) [(HIRES P2L037)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #037
$5628-$564F (22056-22095) [(HIRES P2L101)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #101
$5650-$5677 (22096-22135) [(HIRES P2L165)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #165
$5680-$56A7 (22144-22183) [(HIRES P2L045)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #045
$56A8-$56CF (22184-22223) [(HIRES P2L109)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #109
$56D0-$56F7 (22224-22263) [(HIRES P2L173)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #173
$5700-$5727 (22272-22311) [(HIRES P2L053)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #053
$5728-$574F (22312-22351) [(HIRES P2L117)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #117
$5750-$577F (22352-22399) [(HIRES P2L181)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #181
$5780-$57A7 (22400-22439) [(HIRES P2L061)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #061
$57A8-$57CF (22440-22479) [(HIRES P2L125)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #125
$57D0-$57F7 (22480-22519) [(HIRES P2L189)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #189
$5800-$5827 (22528-22567) [(HIRES P2L006)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #006
$5828-$584F (22568-22607) [(HIRES P2L070)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #070
$5850-$5877 (22608-22647) [(HIRES P2L134)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #134
$5880-$58A7 (22648-22687) [(HIRES P2L014)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #014
$58A8-$58CF (22688-22727) [(HIRES P2L078)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #078
$58D0-$58E7 (22728-22767) [(HIRES P2L142)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #142
$5900-$5927 (22768-22807) [(HIRES P2L022)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #022
$5928-$594F (22808-22847) [(HIRES P2L086)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #086
$5950-$597F (22848-22887) [(HIRES P2L150)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #150
$5980-$59A7 (22888-22927) [(HIRES P2L030)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #030
$59A8-$59CF (22928-22967) [(HIRES P2L094)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #094
$59D0-$59F7 (22968-23007) [(HIRES P2L158)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #158
$5A00-$5A27 (23008-23047) [(HIRES P2L038)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #038
$5A28-$5A4F (23048-23087) [(HIRES P2L102)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #102
$5A50-$5A77 (23088-23127) [(HIRES P2L166)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #166
$5A80-$5AA7 (23128-23167) [(HIRES P2L045)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #046
$5AA8-$5ACF (23168-23207) [(HIRES P2L110)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #110
$5AD0-$5AF7 (23208-23247) [(HIRES P2L174)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #174
$5B00-$5B27 (23248-23287) [(HIRES P2L054)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #054
$5B28-$5B4F (23288-23327) [(HIRES P2L118)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #118
$5B50-$5B7F (23328-23367) [(HIRES P2L182)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #182
$5B80-$5BA7 (23368-23407) [(HIRES P2L062)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #062
$5BA8-$5BCF (23408-23447) [(HIRES P2L126)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #126
$5BD0-$5BF7 (23448-23487) [(HIRES P2L190)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #190
$5C00-$5C27 (23488-23527) [(HIRES P2L007)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #007
$5C28-$5C4F (23528-23567) [(HIRES P2L071)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #071
$5C50-$5C77 (23568-23607) [(HIRES P2L135)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #135
$5C80-$5CA7 (23608-23647) [(HIRES P2L015)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #015
$5CA8-$5CCF (23648-23687) [(HIRES P2L079)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #079
$5CD0-$5CE7 (23688-23727) [(HIRES P2L143)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #143
$5D00-$5D27 (23728-23767) [(HIRES P2L023)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #023
$5D28-$5D4F (23768-23807) [(HIRES P2L087)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #087
$5D50-$5D7F (23808-23847) [(HIRES P2L151)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #151
$5D80-$5DA7 (23848-23887) [(HIRES P2L031)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #031
$5DA8-$5DCF (23888-23927) [(HIRES P2L095)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #095

```

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$5000~$5DF7 (24016~24055) [(HIRES P2L159)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #159
$5E00~$5E27 (24064~24103) [(HIRES P2L039)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #039
$5E28~$5E4F (24104~24143) [(HIRES P2L103)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #103
$5E50~$5E77 (24144~24183) [(HIRES P2L167)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #167
$5E80~$5EA7 (24192~24231) [(HIRES P2L047)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #047
$5EA8~$5ECF (24232~24271) [(HIRES P2L111)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #111
$5ED0~$5EF7 (24272~24311) [(HIRES P2L175)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #175
$5F00~$5F27 (24320~24359) [(HIRES P2L055)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #055
$5F28~$5F4F (24360~24399) [(HIRES P2L119)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #119
$5F50~$5F7F (24400~24447) [(HIRES P2L183)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #183
$5F80~$5FA7 (24448~24487) [(HIRES P2L063)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #063
$5FA8~$5FCF (24488~24527) [(HIRES P2L127)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #127
$5FD0~$5FF7 (24528~24567) [(HIRES P2L191)] \HB\HI-RES GRAPHICS: PAGE 2 - LINE #191
$6884 (26756) [(COMMAND TBL)] \PB\ DOS 3.2 COMMAND TABLE (32K APPLE ONLY!)
$6974 (26996) [(DOS 3.2 ERR MSGS)] \PB\DOS 3.2 ERROR MESSAGES (32K APPLE ONLY!)
$6996~$6A53 (27030~27219) \PB\ DOS 3.2 COUT AND OTHER HOOKS (32K APPLE ONLY! - SEE $A996~$AA53 FOR MORE
DESCRIPTION BASED ON 48K APPLE)
$6A60 (27232) \P2\ LENGTH OF MOST RECENTLY BLOADED PROGRAM OR DATA (32K APPLE ONLY)
$6A72 (27250) \P2\ STARTING ADDRESS OF MOST RECENTLY BLOADED PROGRAM OR DATA (32K APPLE ONLY)
$8F57~$91B9 (-28841~-28231) \PB\ SPACE NORMALLY AVAILABLE FOR USER USE. HOWEVER IF DOS MAXFILES >=6 THIS AREA
BECOMES DOS FILE BUFFER #6
$91B9~$940C (-28231~-27636) \PB\ SPACE NORMALLY AVAILABLE FOR USER USE. HOWEVER IF DOS MAXFILES >=5 THIS AREA
BECOMES DOS FILE BUFFER #5
$940D~$95FF (-27635~-27137) \PB\ SPACE NORMALLY AVAILABLE FOR USER USE. HOWEVER IF DOS MAXFILES >=4 THIS AREA
BECOMES DOS FILE BUFFER #4
$95FF (-27137) DEFAULT (MAXFILES = 3) END OF USER RAM WHEN DOS ACTIVE (HIMEM=49151)
$9600~$9CF8 (-27136~-25352) \HB\ 3 DOS FILE BUFFERS (DEFAULT CASE) - APPLICABLE TO ALL VERSIONS
(3.1~3.2~3.2.1~3.3) 48K
$9600~$9853 (-27136~-26541) \HB\ DOS FILE BUFFER #3. NOTE: THIS IS DEFAULT FIRST BUFFER USED BY DOS. IF MAXFILES>3
ADDITIONAL BUFFERS WILL BE PLACED BELOW $9600 AND HIGHEST NUMBER BUFFER WILL BE
USED DEFAULT FIRST
$9600~$9700 (-27136~-26880) \HB\ DOS FILE BUFFER #3 - SECTION 1: DATA BUFFER. RECEIVES CONTENTS OF CURRENT DATA
SECTOR
$9600 (-27136) HIMEM VALUE (+1) SET HERE WHEN USING DOS 3.1~3.2~3.2.1~3.3 OR 3.2 IN DEFAULT CASE
(MAXFILES=3)
$9701~$9800 (-26879~-26624) \PB\ DOS FILE BUFFER #3 - SECTION 2: TRACK & SECTOR BUFFER. RECEIVES THE CURRENT
TRACK+SECTOR LIST (TSL) SECTOR
$9801~$9853 (-26623~-26541) \PB\ DOS FILE BUFFER #3 - FILE NAME & MISC DATA
$9CF8~$9CFF (-25352~-25345) \HB\ 7-BYTE VACANT AREA NOT USED BY DOS 3.23.2
$982D (-26579) DOS FILE BUFFER #3 - START OF NAME OF FILE
$984B~$984C (-26549~-26548) DOS FILE BUFFER #3 - ADDRESS OF START OF MISC INFO SECTION (SECTION 3) (DEFAULT
CONTENTS = $9800)
$984D~$984E (-26547~-26546) DOS FILE BUFFER #3 - ADDRESS OF START OF TRACK & SECTOR SECTION (SECTION 2)
(DEFAULT CONTENTS = $9700)
$984F~$9850 (-26545~-26544) DOS FILE BUFFER #3 - ADDRESS OF START OF DATA SECTION (SECTION 1) (DEFAULT
CONTENTS = $9600)
$9851~$9852 (-26543~-26542) DOS FILE BUFFER #3 - ADDRESS OF START OF NAME BUFFER FOR NEXT FILE ($0000 = NO
MORE FILES)
$9853 (-26541) START OF DOS (=HIMEM+1) FOR MAXFILES=2
$9853~$9952 (-26541~-26286) DOS FILE BUFFER #2 - SECTION 1: DATA BUFFER
$9953~$9A52 (-26285~-26030) DOS FILE BUFFER #2 - SECTION 2: TRACK & SECTOR BUFFER

```

\$5000 - \$9953

Prof. Luebbert's "What's Where in the Apple"

NUMERIC ATLAS

\$9A53 (-26029)		DOS FILE BUFFER #2 - SECTION 3: START OF MISCELLANEOUS INFO BUFFER
\$9A80 (-25984)		DOS FILE BUFFER #2 - NAME
\$9A9E-\$9A9F (-25954--25953)		DOS FILE BUFFER #2 - ADDRESS OF START OF SECTION 3 MISCELLANEOUS INFO BUFFER (\$9A53)
\$9AA0-\$9AA1 (-25952--25951)		DOS FILE BUFFER #2 - ADDRESS OF START OF SECTION 2 TRACK AND SECTOR BUFFER (\$9953)
\$9AA2-\$9AA3 (-25950--25949)		DOS FILE BUFFER #2 - ADDRESS OF START OF SECTION 1 DATA BUFFER (\$9853)
\$9AA4-\$9AA5 (-25948--25947)		DOS FILE BUFFER #2 - ADDRESS OF START OF NAME BUFFER OF NEXT FILE DOWN (\$982D)
\$9AA6 (-25946)		START OF DOS (=HIMEM+1) WHEN MAXFILES=1
\$9AA6-\$9BA5 (-25946--25691)		DOS FILE BUFFER #1 - SECTION 1 DATA BUFFER
\$9BA6-\$9CA5 (-25690--25435)		DOS FILE BUFFER #1 - SECTION 2 & SECTOR BUFFER
\$9CA6 (-25434)		DOS FILE BUFFER #1 - SECTION 3 START OF MISC INFO BUFFER (\$53 BYTES)
\$9CD3 (-25389)		DOS FILE BUFFER #1 - NAME
\$9CF1-\$9CF2 (-25359--25358)		DOS FILE BUFFER #1 - ADDRESS OF SECTION 3 OF MISC INFO BUFFER (\$9CA6)
\$9CF3-\$9CF4 (-25357--25356)		DOS FILE BUFFER #1 - ADDRESS OF START OF SECTION 2 TRACK & SECTOR BUFFER (\$9BA6)
\$9CF5-\$9CF6 (-25355--25354)		DOS FILE BUFFER #1 - ADDRESS OF START OF SECTION 1 DATA BUFFER (\$9AA6)
\$9CF7-\$9CF8 (-25353--25352)		DOS FILE BUFFER #1 - ADDRESS OF START OF NAME BUFFER OF NEXT FILE DOWN (\$9A80)
\$9CF9-\$9CFF (-25351--25345)		DOS 3.2 UNUSED
\$9D00-\$BFFF (-25344--16385)	\SB\	DOS 3.2/3.3 (NOT INCLUDING ANY BUFFERS)
\$9D00-\$9D83 (-25344--25213)	\SB\	DOS 3.2/3.3 ADDRESS TABLE (LIST OF TWO-BYTE ADDRESS CONSTANTS USED BY DOS)
\$9D00-\$9D01 (-25344--25343)	\P2\	ADDRESS OF DOS 3.2/3.3 FILE BUFFER #1 AT ITS FILE NAME FIELD (\$9CD3)
\$9D02-\$9D03 (-25342--25341)	\P2\	ADDRESS OF DOS 3.2/3.3 INPUT CHARACTER (KEYBOARD INTERCEPT) ROUTINE (\$9E81)
\$9D04-\$9D05 (-25340--25339)	\P2\	ADDRESS OF DOS 3.2/3.3 OUTPUT CHARACTER (VIDEO INTERCEPT) ROUTINE (\$9EBD)
\$9D06-\$9D07 (-25338--25337)	\P2\	ADDRESS OF DOS 3.2/3.3 FILE NAME FOR BUFFER #1 (PRIMARY FILE NAME) (\$AA75)
\$9D08-\$9D09 (-25336--25335)	\P2\	ADDRESS OF DOS 3.2/3.3 FILE NAME FOR BUFFER #2 (SECONDARY OR 'RENAME' FILE NAME) (\$AA93)
\$9D0A-\$9D0B (-25334--25333)	\P2\	ADDRESS POINTS TO PARAMETER SECTION FOR FIRST LEVEL OF DOS 3.2/3.3 - SEE NEXT ITEM FOR FIRST ENTRY IN SECTION
\$9D0A-\$9D0B (-25334--25333)	\P2\	ADDRESS OF DOS 3.2/3.3 LENGTH OF LOAD (\$AA60)
\$9D0C-\$9D0D (-25332--25331)	\P2\	ADDRESS OF DOS 3.2/3.3 LOAD ADDRESS - I.E. BEGINNING OF DOS (\$9D00)
\$9D0E-\$9D0F (-25330--25329)	\P2\	DOS 3.2/3.3 ADDRESS POINTS TO PARAMETER SECTION FOR FILE MANAGER - I.E. SECOND (I/O ROUTINE) LEVEL OF DOS
\$9D0E-\$9D0F (-25330--25329)	\P2\	ADDRESS OF DOS 3.2/3.3 END OF SYSTEM BUFFERS (\$B5BB)
\$9D10-\$9D1C (-25328--25316)	\SB\	DOS VIDEO (CSWL) INTERCEPT'S STATE HANDLER ADDRESS TABLE; I.E. TABLE OF ADDRESSES USED IN STATE MACHINE THAT ROUTES OUTPUT CHARACTERS. USED FROM \$9ECD TO \$9ED0. \$AA52 IS USED TO CHOOSE WHICH ONE
\$9D10-\$9D11 (-25328--25327)	\P2\	ADDRESS OF DOS 3.2/3.3 STATE MACHINE CONDITION #0 CODE (\$9EEB-1)
\$9D12-\$9D13 (-25326--25325)	\P2\	ADDRESS OF DOS 3.2/3.3 STATE MACHINE CONDITION #1 CODE (\$9F12-1)
\$9D14-\$9D15 (-25324--25323)	\P2\	ADDRESS OF DOS 3.2/3.3 STATE MACHINE CONDITION #2 CODE (\$9F23-1)
\$9D16-\$9D17 (-25322--25321)	\P2\	ADDRESS OF DOS 3.2/3.3 STATE MACHINE CONDITION #3 CODE (\$9F2F-1)
\$9D18-\$9D19 (-25320--25319)	\P2\	ADDRESS OF DOS 3.2/3.3 STATE MACHINE CONDITION #4 CODE (\$9F52-1)
\$9D1A-\$9D1B (-25318--25317)	\P2\	ADDRESS OF DOS 3.2/3.3 STATE MACHINE CONDITION #5 CODE (\$9F61-1)
\$9D1C-\$9D1D (-25316--25315)	\P2\	ADDRESS OF DOS 3.2/3.3 STATE MACHINE CONDITION #6 CODE (\$9F71-1)
\$9D1E-\$9D55 (-25314--25259)	\SB\	DOS 3.2/3.3 COMMAND DECODER TABLE OF SUBROUTINE ADDRESSES (EXPRESSED IN VALUE-1 FORM TO SIMPLIFY CALLING)
\$9D1E-\$9D1F (-25314--25313)	\P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'INIT' COMMAND (\$A54F-1)
\$9D20-\$9D21 (-25312--25311)	\P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'LOAD' COMMAND (\$A413-1)
\$9D22-\$9D23 (-25310--25309)	\P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'SAVE' COMMAND (\$A397-1)
\$9D24-\$9D25 (-25308--25307)	\P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'RUN' COMMAND (\$A4D1-1)
\$9D26-\$9D27 (-25306--25305)	\P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'CHAIN' COMMAND (\$A4F0-1)
\$9D28-\$9D29 (-25304--25303)	\P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'DELETE' COMMAND (\$A263-1)

\$9D2A~\$9D2B (-25302~-25301) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'LOCK' COMMAND (\$A271-1)
\$9D2C~\$9D2D (-25300~-25299) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'UNLOCK' COMMAND (\$A275-1)
\$9D2E~\$9D2F (-25298~-25297) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'CLOSE' COMMAND (\$A2EA-1)
\$9D30~\$9D31 (-25296~-25295) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'READ' COMMAND (\$A51B-1)
\$9D32~\$9D33 (-25294~-25293) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'EXEC' COMMAND (\$A5C6-1)
\$9D34~\$9D35 (-25292~-25291) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'WRITE' COMMAND (\$A510-1)
\$9D36~\$9D37 (-25290~-25289) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'POSITION' COMMAND (\$A5DD-1)
\$9D38~\$9D39 (-25288~-25287) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'OPEN' COMMAND (\$A2A3-1)
\$9D3A~\$9D3B (-25286~-25285) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'APPEND' COMMAND (\$A298-1)
\$9D3C~\$9D3D (-25284~-25283) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'RENAME' COMMAND (\$A281-1)
\$9D3E~\$9D3F (-25282~-25281) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'CATALOG' COMMAND (\$A56E-1)
\$9D40~\$9D41 (-25280~-25279) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'MON' COMMAND (\$A233-1)
\$9D42~\$9D43 (-25278~-25277) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'NOMON' COMMAND (\$A23D-1)
\$9D44~\$9D45 (-25276~-25275) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'PR#' COMMAND (\$A229-1)
\$9D46~\$9D47 (-25274~-25273) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'IN#' COMMAND (\$A22E-1)
\$9D48~\$9D49 (-25272~-25271) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'MAXFILES' COMMAND (\$A251-1)
\$9D4A~\$9D4B (-25270~-25269) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'FP' COMMAND (\$A57A-1)
\$9D4C~\$9D4D (-25268~-25267) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'INT' COMMAND (\$A59E-1)
\$9D4E~\$9D4F (-25266~-25265) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'BSAVE' COMMAND (\$A331-1)
\$9D50~\$9D51 (-25264~-25263) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'BLOAD' COMMAND (\$A35D-1)
\$9D52~\$9D53 (-25262~-25261) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'BRUN' COMMAND (\$A38E-1)
\$9D54~\$9D55 (-25260~-25259) \P2\	DOS 3.2/3.3 ADDRESS-1 OF CODE FOR 'VERIFY' COMMAND (\$A27D-1)
\$9D56~\$9D83 (-25258~-25213) \SBI\	FOUR TABLES OF VECTORS USED BY DOS 3.2/3.3 TO INTERFACE WITH THE VARIOUS SUPPORTED LANGUAGES. DOS USES THESE ADDRESSES TO JUMP INTO THE LANGUAGE WHEN RUNNING (OR CHAINING IN THE CASE OF INTEGER BASIC) A NEW PROGRAM OR WHEN PROCESSING ERRORS
\$9D56~\$9D61 (-25258~-25247) \SBI\	TABLE OF VECTORS USED BY DOS 3.2/3.3 TO INTERFACE WITH CURRENT LANGUAGE
\$9D56~\$9D57 (-25258~-25257) \P2\	DOS 3.2/3.3 CURRENT LANGUAGE ENTRY-VECTOR TO 'CHAIN'
\$9D58~\$9D59 (-25256~-25255) \P2\	DOS 3.2/3.3 CURRENT LANGUAGE ENTRY-VECTOR TO 'RUN'
\$9D5A~\$9D5B (-25254~-25253) \P2\	DOS 3.2/3.3 CURRENT LANGUAGE ENTRY-VECTOR TO 'ERROR'
\$9D5C~\$9D5D (-25252~-25251) \P2\	DOS 3.2/3.3 CURRENT LANGUAGE ENTRY-VECTOR TO 'HARD ENTRY'
\$9D5E~\$9D5F (-25250~-25249) \P2\	DOS 3.2/3.3 CURRENT LANGUAGE ENTRY-VECTOR TO 'SOFT ENTRY'
\$9D60~\$9D61 (-25248~-25247) \P2\	DOS 3.2/3.3 CURRENT LANGUAGE ENTRY-VECTOR TO 'RECOMPUTE LINKS' FOR APPROPRIATE LOCATION OF APPLESOFT BASIC (APPLESOFT ONLY)
\$9D62~\$9D6B (-25246~-25237) \SBI\	IMAGE OF THE ENTRY POINT VECTOR FOR INTEGER BASIC; I.E. TABLE OF VECTORS USED BY DOS 3.2/3.3 TO INTERFACE WITH INTEGER BASIC. MOVED INTO \$9D56~\$9D59 WHEN INTEGER BASIC IS CURRENT LANGUAGE
\$9D62~\$9D63 (-25246~-25245) \P2\	DOS 3.2/3.3 ENTRY-VECTOR TO INTEGER BASIC 'CHAIN' (\$E839)
\$9D64~\$9D65 (-25244~-25243) \P2\	DOS 3.2/3.3 ENTRY-VECTOR TO INTEGER BASIC 'RUN' (\$A4E5)
\$9D66~\$9D67 (-25242~-25241) \P2\	DOS 3.2/3.3 ENTRY-VECTOR TO INTEGER BASIC 'ERROR' (\$E3E3)
\$9D68~\$9D69 (-25240~-25239) \P2\	DOS 3.2/3.3 ENTRY-VECTOR TO INTEGER BASIC - 'CONTROL-B' OR 'COLD' OR 'HARD' ENTRY (\$E000)
\$9D6A~\$9D6B (-25238~-25237) \P2\	DOS 3.2/3.3 ENTRY-VECTOR TO INTEGER BASIC 'SOFT ENTRY' (\$E003)
\$9D6C~\$9D6D (-25236~-25235) \P2\	NOT USED
\$9D6C~\$9D77 (-25236~-25225) \PBI\	DOS 3.2/3.3 - IMAGE OF THE ENTRY POINT VECTOR FOR APPLESOFT (ROM VERSION) I.E. TABLE OF INTERFACE VECTORS MOVED INTO \$9D56~\$9D61 WHEN ROM APPLESOFT IS CURRENT LANGUAGE
\$9D6C~\$9D6D \P2\	DOS 3.2/3.3 ENTRY-VECTOR TO APPLESOFT (ROM VERSION) 'CHAIN' (REALLY RUN) (\$A4FC)
\$9D6E~\$9D6F (-25234~-25233) \P2\	DOS 3.2/3.3 ENTRY-VECTOR TO APPLESOFT (ROM VERSION) 'RUN' (\$A4FC)
\$9D70~\$9D71 (-25232~-25231) \P2\	DOS 3.2/3.3 ENTRY-VECTOR TO APPLESOFT (ROM VERSION) 'ERROR' (\$D865)
\$9D72~\$9D73 (-25230~-25229) \P2\	DOS 3.2/3.3 ENTRY-VECTOR TO APPLESOFT (ROM VERSION) - 'CONTROL-B' OR 'COLD' OR 'HARD' ENTRY (\$E000)


```

$9D73-$A7DF (-25229~-22561) \SB\    SYSTEM SECTION OF DOS 3.1 (48K APPLE)
$9D74-$9D75 (-25228~-25227) \P2\    DOS 3.2/3.3 ENTRY-VECTOR TO APPLESOFT (ROM VERSION) 'SOFT ENTRY' ($D43C)
$9D76-$9D77 (-25226~-25225) \P2\    DOS 3.2/3.3 ENTRY-VECTOR TO APPLESOFT (ROM VERSION) 'RECOMPUTE LINKS' ($D4F2)
$9D78-$9D83 (-25224~-25213) \PB\    DOS 3.2/3.3 APPLESOFT (RAM OR DISK VERSION) INTERFACE VECTORS (MOVED INTO
$9D56-$9D61 WHEN RAM OR DISK APPLESOFT IS CURRENT LANGUAGE)
$9D84-$A883 (-25212~-22397)          DOS 3.2/3.3 (48K) SYSTEM CODE SECTION
$9D84-$9DBE (-25212~-25154) \SB\    DOS 3.2/3.3 COLDSTART ENTRY ROUTINE
$9D84 (-25212) \SE\                LOCATION TO WHICH DOS 3.2/3.3 JUMPS (ON A CTRL-B OR 3D3G) FOR CODE TO IMPLEMENT A
                                     HARD ENTRY TO RAM (DISK AS OPPOSED TO ROM OR LANGUAGE PACK) VERSION OF APPLESOFT
$9D78-$9D79 (-25224~-25223) \P2\    DOS 3.2/3.3 ENTRY-VECTOR TO APPLESOFT (RAM OR DISK) 'CHAIN' ($A506)
$9D7A-$9D7B (-25222~-25221) \P2\    DOS 3.2/3.3 ENTRY-VECTOR TO APPLESOFT (RAM OR DISK) 'RUN' ($A506)
$9D7C-$9D7D (-25220~-25219) \P2\    DOS 3.2/3.3 ENTRY-VECTOR TO APPLESOFT (RAM OR DISK) 'ERROR' ($1067)
$9D7E-$9D7F (-25218~-25217) \P2\    DOS 3.2/3.3 ENTRY-VECTOR TO APPLESOFT (RAM OR DISK) 'HARD ENTRY' ($9D84)
$9D80-$9D81 (-25216~-25215) \P2\    DOS 3.2/3.3 ENTRY-VECTOR TO APPLESOFT (RAM OR DISK) 'SOFT ENTRY' ($0C3C)
$9D82-$9D83 (-25214~-25213) \P2\    DOS 3.2/3.3 ENTRY-VECTOR TO APPLESOFT (RAM OR DISK) 'RECOMPUTE LINKS' ($0CF2)
$9D84 (-25212) \SE\                DOS 3.2/3.3 HARD ENTRY POINT. BOOTSTRAP ROUTINE AT $B700 AND $03D3G BOTH JUMP HERE
$9DB9 (-25159) \SE\                INITIALIZE OR RE-INITIALIZE DOS 3.2/3.3 IF PAGE 3 LINKAGES DESTROYED. OBSOLETE
                                     (DOS 3.1 ONLY?)
$9DBF-$9DE9 \SB\                  DOS 3.2/3.3 WARMSTART ENTRY ROUTINE. GETS REMEMBERED BASIC TYPE AND SETS ROM CARD
                                     AS NECESSARY CALLING $A5B2
$9DBF (-25153) \SE\                DOS 3.2/3.3 (48K) SOFT ENTRY POINT. $03DOG AND RESET WITH AUTOSTART ROM BOTH JUMP
                                     HERE. (RECONNECTS DOS 3.2 IF PAGE 3 MONITOR LINKAGES OVERWRITTEN)
$9DD1 (-25135)                    DOS 3.2/3.3 PARAMETER TO REMEMBER WHETHER ENTRY IS COLDSTART OR WARMSTART
$9DEA (-25110) \SE\                DOS 3.2/3.3 (48K) BLOCK OF CODE WHICH INITIS DOS BUFFERS AND SETS VECTORS FOR RAM
                                     APPLESOFT. RESTORES $03D0-$03FF FROM $9E51-$9E80. CALLED BY KEYIN IF APPLESOFT
                                     MUST COME FROM DISK
$9DEA-$9E50 \SB\                  DOS 3.2/3.3 FIRST ENTRY PROCESSING ROUTINE CALLED BY KEYBOARD INTERCEPT HANDLER
                                     WHEN FIRST KEYBOARD INPUT REQUEST MADE BY BASIC AFTER A DOS COLDSTART
$9E4D (-25011) \SE\                ROUTINE WHICH HANDLES DOS 3.1 INPUT HOOK
$9E50-$9E80 (-25008~-24960) \SB\    BLOCK OF COMMANDS ETC. COPIED INTO $03D0-$03ED ON DOS 3.2/3.3 BOOT TO CONTROL
                                     TRANSFERS TO SOFT ENTRY~ HARD ENTRY~ I-O PKG~ RWTS AND TO GET END OF SYSTEM
                                     BUFFER~ IOB ADDRESS~ AND TO UPDATE I-O HOOKS~ AND DO JUMP TRANSFERS TO AUTO BRK
                                     ENTRY~ CTRL~Y ENTRY~ NMI ENTRY AND PROVIDE IRQ ADDRESS
$9E51-$9E7F (-25007~-24961)        DOS 3.3 IMAGE OF 3-PAGE JUMP VECTOR WHICH ROUTINE AT $9DEA COPIES TO $3D0-$3FF
$9E7E (-24962) \SE\                ROUTINE WHICH HANDLES DOS 3.1 OUTPUT HOOK
$9E81-$9EB9 (-24959~-24903) \SE\    DOS 3.2/3.3 (48K) KEYBOARD INTERCEPT (INPUT CHARACTER) ROUTINE. CALLS $9ED1 AND
                                     MAY CALL $9E9E~$A626 AND~OR $9DEA. DOS COMES HERE FOR EVERY BASIC INPUT
                                     STATEMENT OR EVERY LINE TYPED TO THE BASIC PROMPT (E.G. ] OR >) OR EVERY TIME
                                     PROGRAM USES JSR $FD18 OR $FDOC
$9EBA-$9EBC (-24902~-24900)        DOS 3.2/3.3 JUMP TO THE TRUE KSWL HANDLER ROUTINE
$9EBD-$9EEA (-24899~-24854) \SB\    DOS 3.2/3.3 (48K) DOS COMMAND DECODER -- PART 3. OUTPUT STATE MACHINE AND DEVICE
                                     SELECTION CODE
$9EBD-$9ED0 (-24899~-24880)        DOS 3.2/3.3 DOS VIDEO INTERCEPT ROUTINE. CALLS $9ED1 TO SAVE REGISTERS AT ENTRY
                                     TO DOS. GETS VIDEO INTERCEPT STATE AND USING IT AS INDEX TO STATE HANDLER TABLE
                                     ($9D10) GOES TO PROPER HANDLER ROUTINE & PASSES IT THE CHARACTER TO BE PRINTED
$9EBD (-24899) \SE\                DOS 3.2/3.3 OUTPUT ROUTINE. IF DOS ACTIVE OUTPUT HOOK POINTS HERE & EVERY CHAR TO
                                     BE OUTPUTTED PUT INTO ACCUMULATOR FOR DISPOSAL BY CALLING THIS ROUTINE. IT PUSHES
                                     ADDRESS FROM STATE MACHINE TABLE ONTO STACK AND THEN RTS'S TO JUMP TO THAT
                                     ADDRESS+1
$9ED1-$9EEA                        DOS 3.2/3.3 COMMON INTERCEPT SAVE REGISTERS ROUTINE. SAVES A~X~Y AND S-REGISTERS
                                     AT $AA59-$AA5C. WHILE IN DOS RESTOR TRUE I/O HANDLERS TO $0036~$0039

```

\$9ED1 (-24879) \SE\	ENTRY POINT TO ABOVE ROUTINE WHICH RESTORES KEYBOARD AND PRINT HOOKS
\$9EEB~\$9F11 (-24853~-24815) \SB\	DOS 3.2/3.3 STATE 0 OUTPUT HANDLER
\$9EEB (-24853) \SE\	DOS 3.2/3.3 STATE MACHINE ENTRY DOS#0 (\$AA52=0). DEFAULT VALUE ON DOS ENTRY (SET AT \$9DDA) AND ALSO USED AT FRONT OF LINE OUTPUTTED FROM A PROGRAM. CHECKS FOR A VARIETY OF SPECIAL CASES
\$9F12~\$9F22 (-24814~-24798) \SB\	DOS 3.2/3.3 STATE 1 OUTPUT HANDLER. FUNCTION: COLLECT DOS COMMAND
\$9F12 (-24814) \SE\	DOS 3.2/3.3 (48K) STATE MACHINE ENTRY DOS#1 (\$AA52=1). USED WHEN OUTPUTTING CTRL-D LINE (DOS COMMAND) FROM PROGRAM SO DOS MUST COLLECT THE LINE FOR DECODING
\$9F23~\$9F2E (-24797~-24786) \SB\	DOS 3.2/3.3 STATE 2 OUTPUT HANDLER. FUNCTION: NON-DOS COMMAND TO BE IGNORED
\$9F23 (-24797) \SE\	DOS 3.2/3.3 (48K) STATE MACHINE ENTRY DOS#2 (\$AA52=2). USED FOR OUTPUTTING NORMAL LINE FROM PROGRAM SO DOS MUST ROUTE TO OUTPUT DEVICE
\$9F2F (-24785) \SB\	DOS 3.2/3.3 (48K) STATE 3 OUTPUT HANDLER. FUNCTION: INPUT STATEMENT HANDLER
\$9F2F (-24785) \SE\	DOS 3.2/3.3 (48K) STATE MACHINE ENTRY DOS#3 (\$AA52=3). COME HERE TO OUTPUT A CHARACTER BEING ECHOED FROM THE INPUT ROUTINE (KEYBOARD OR EXEC FILE)
\$9F52~\$9F60 (-24750~-24736) \SB\	DOS 3.2/3.3 (48K) STATE 4 OUTPUT HANDLER. FUNCTION: WRITE DATA TO A FILE
\$9F52 (-24750) \SE\	DOS 3.2/3.3 (48K) STATE MACHINE ENTRY DOS#4 (\$AA52=4). STATES DOS#4 & DOS#5 WORK TOGETHER TO OUTPUT TO THE DISK UNTIL A LINE COMES ALONG WITH A CTRL-D ON THE FRONT. DOS#4 - WRITE IS ACTIVE~ MIDDLE OF LINE
\$9F61 (-24735) \SB\	DOS 3.2/3.3 (48K) STATE 5 OUTPUT HANDLER. FUNCTION: START OF WRITE DATA LINE
\$9F61 (-24735) \SE\	DOS 3.2/3.3 (48K) STATE MACHINE ENTRY DOS#5 (\$AA52=5). SEE \$9F52 FOR EXPLANATION. DOS#5 - WRITE IS ACTIVE~ FRONT OF LINE
\$9F71~\$9F77 (-24719~-24713) \SB\	DOS 3.2/3.3 (48K) STATE 6 OUTPUT HANDLER. FUNCTION: SKIP PROMPT CHARACTER. SETS STATE TO 0 AND EXITS VIA \$9F9D (ECHO IF MON I)
\$9F71 (-24719) \SE\	DOS 3.2/3.3 (48K) STATE MACHINE ENTRY DOS#6 (\$AA52=6). CONDITION WHEN ECHOING INPUT FROM 'READ' FILE. DOS IGNORES CHARACTERS FOR DOS COMMAND PURPOSES. USED BY THE EXEC COMMAND
\$9F78~\$9F82 (-24712~-24702)	DOS 3.2/3.3 (48K) FINISHES RUN COMMAND INTERRUPTED BY APPLESOFT RAM LOAD. RESETS 'RUN INTERRUPTED' FLAG; CALLS \$A851 TO REPLACE DOS CSWL/KSWL INTERCEPTS AND GOES TO \$A4DC TO COMPLETE THE RUN COMMAND
\$9F83~\$9F94 (-24701~-24684)	DOS 3.2/3.3 (48K) COMMAND SCANNER EXIT TO BASIC ROUTINE. IF 1ST CHAR OF COMMAND LINE IS CONTROL-D GO TO ECHO EXIT (\$9F75); OTHERWISE SET THINGS UP SO BASIC WON'T SEE THE DOS COMMAND (BY PASSING A ZERO-LENGTH LINE I.E. ONLY A CARRIAGE RETURN) AND FALL THRU TO ECHO EXIT
\$9F95~\$9FB0 (-24683~-24656)	DOS 3.2/3.3 (48K) ROUTINE TO ECHO CHARACTER ON SCREEN (CONDITIONALLY) AND EXIT DOS. (\$9F95 ECHO ONLY IF MON C SET; OTHERWISE GOTO \$9FBE. \$9F99 ECHO ONLY IF MON O SET; OTHERWISE GO TO \$9FB3. \$9F9D ECHO ONLY IF MON I SET; OTHERWISE GOTO \$9FB3. \$9FA4 ALWAYS ECHO CHARACTER.) CALLS \$9FBA EXIT DOS \$9FC5
\$9FB3~\$9FC4 (-24653~-24636)	DOS 3.2/3.3 (48K) EXIT ROUTINE AND REGISTER RESTORE. CALLS \$A851 TO PUT BACK DOS KSWL/CSWL INTERCEPTS. RESTORES S-REGISTER FROM ENTRY TO DOS.
\$9FBA (-24646)	DOS 3.2/3.3 (48K) DOS REGISTER RESTORE SUBROUTINE. RESTORES REGISTERS FROM FIRST ENTRY TO DOS AND RETURNS TO CALLER
\$9FC5~\$9FC7	DOS 3.2/3.3 (48K) JUMP TO THE TRUE CSWL ROUTINE
\$9FC8~\$9FCC (-24632~-24628)	DOS 3.2/3.3 (48K) SKIP A LINE ON THE SCREEN BY LOADING A CARRIAGE RETURN INTO THE A REGISTER AND CALLING \$9FC5 TO PRINT IT
\$9FCD~\$A179 (-24627~-24199) \SB\	DOS 3.2/3.3 (48K) DOS COMMAND PARSE ROUTINE
\$9FCD (-24627)	START OF SECTION OF CODE THAT ATTEMPTS TO MATCH TO A COMMAND AND GET ALL INFO NEEDED & ALL OPERATIONAL INFO GIVEN. CHECKS SYNTAX AND RANGES BEFORE EXECUTION
\$A095 (-24427)	DOS 3.2/3.3 (48K) SUBROUTINE TO BLANK BOTH FILENAME BJFFERS
\$A0D1 (-24367)	DOS 3.2/3.3 (48K) SETS DEFAULTS FOR THE KEYWORD OPERANDS (V=0~L=0~B=0)
\$A0E8 (-24344)	DOS 3.2/3.3 (48K) GET THE LINE OFFSET INDEX AND FLUSH TO THE NEXT NON-BLANK SKIPPING ANY COMMAS FOUND. IF NOT YET TO END OF LINE GOTO \$A10C. CHECK TO SEE IF ANY KEYWORDS WERE GIVEN WHICH WERE NOT ALLOWED BY THIS COMMAND

```

$A10C (-24308)      DOS 3.2/3.3 (48K) LOOKUP THE KEYWORD FOUND ON THE COMMAND LINE IN THE TABLE OF
                    VALID KEYWORDS ($A941). SAVE VALUE OF KEYWORD IN KEYWORD VALUES TABLE STARTING AT
                    $AA66. GO PARSE NEXT KEYWORD. GOTO $AOE8
$A164 (-24220)      DOS 3.2/3.3 (48K) INDICATE C-I OR O KEYWORDS WERE PARSED. UPDATE MONN VALUE IN
                    KEYWORD VALUE TABLE APPROPRIATELY. GOT PARSE THE NEXT KEYWORD. GOTO $AOE8
$A180-$A192 (-24192-24174) DOS 3.2/3.3 (48K) DO COMMAND. RESET VIDEO INTERCEPT STATE TO ZERO; CLEAR FILE
                    MANAGER PARAMETER LIST. USING COMMAND INDEX GET ADDRESS OF THE COMMAND HANDLING
                    ROUTINE FROM THE COMMAND HANDLER ROUTINE TABLE AT $9D1E AND GO TO IT. COMMAND
                    HANDLER WILL EXIT TO CALLER OF THIS ROUTINE
$A193-$A1A3 (-24173-24157) DOS 3.2/3.3 (48K) GET NEXT CHARACTER ON COMMAND LINE AND CHECK TO SEE IF IT IS A
                    C/R OR A COMMA
$A1A4-$A1AD (-24156-24147) DOS 3.2/3.3 (48K) FLUSHES COMMAND LINE CHARACTERS UNTIL A NON-BLANK IS FOUND
$A1AE-$A1B8 (-24146-24136) DOS 3.2/3.3 (48K) CLEAR FILE MANAGER PARAMETER LIST AT $B5BB TO ZEROS
$A1B4 (-24140)      DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'PR#' COMMAND
$A1B9 (-24135) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'IN#' COMMAND
$A1BE (-24130) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'MON' COMMAND
$A1DC (-24100) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'MAXFILES' COMMAND
$A1EE (-24082) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'DELETE' COMMAND
$A1FC (-24068) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'LOCK' COMMAND
$A200 (-24064) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'BSAVE' COMMAND
$A200 (-24064) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'UNLOCK' COMMAND
$A208 (-24056) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'VERIFY' COMMAND
$A20C (-24052) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'RENAME' COMMAND
$A223 (-24029) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'APPEND' COMMAND
$A229-$A60D (-24023-23027) \SBI DOS 3.2/3.3 (48K) - BLOCK OF CODE TO HANDLE INDIVIDUAL DOS COMMANDS
$A229 (-24023) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'PR#' COMMAND
$A22E (-24018) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'IN#' COMMAND
$A233 (-24013) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'MON' COMMAND
$A236 (-24010) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'OPEN' COMMAND
$A23D (-24003) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'NOMON' COMMAND
$A251 (-23983) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'MAXFILES' COMMAND
$A263 (-23965) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'DELETE' COMMAND
$A271 (-23951) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'LOCK' COMMAND
$A275 (-23947) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'UNLOCK' COMMAND
$A278 (-23944) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'CLOSE' COMMAND
$A27D (-23939) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'VERIFY' COMMAND
$A281 (-23935) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'RENAME' COMMAND
$A298 (-23912) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'APPEND' COMMAND
$A2A3 (-23901) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'OPEN' COMMAND
$A2EA (-23830) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'CLOSE' COMMAND
$A2EC (-23828) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'BLOAD' COMMAND
$A327 (-23769) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'BRUN' COMMAND
$A330 (-23760) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'SAVE' COMMAND
$A331 (-23759) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'BSAVE' COMMAND
$A35D (-23715) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'BLOAD' COMMAND
$A38E (-23666) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'BRUN' COMMAND
$A397 (-23657) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'SAVE' COMMAND
$A3A5 (-23643) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'LOAD' COMMAND
$A313 (-23533) \SE\  DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'LOAD' COMMAND
$A376 (-23434) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'RUN' COMMAND
$A38D (-23411) \SE\  DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'CHAIN' COMMAND

```

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$A4A5 (-23387) \SE\      DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'WRITE' COMMAND
$A4B0 (-23376) \SE\      DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'READ' COMMAND
$A4D1 (-23343) \SE\      DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'RUN' COMMAND
$A4E4 (-23324) \SE\      DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'INIT' COMMAND
$A4E5 (-23323) \SE\      DOS 3.2/3.3 (48K) ENTRY POINT TO WHICH DOS TRANSFERS TO RUN A NEW INTEGER BASIC
                           PROGRAM
$A4F0 (-23312) \SE\      DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'CHAIN' COMMAND
$A4FC (-23300) \SE\      DOS 3.2/3.3\APPLESOFT TRANSFER POINT USED BY DOS 3.2 TO JUMP INTO EITHER CHAIN OR
                           RUN OF AN APPLESOFT (ROM) PROGRAM
$A501 (-23295) \SE\      DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'NOMON' COMMAND
$A506 (-23290) \SE\      DOS 3.2/3.3\APPLESOFT TRANSFER POINT USED BY DOS 3.2 TO JUMP INTO EITHER CHAIN OR
                           RUN OF AN APPLESOFT (RAM OR DISK VERSION) PROGRAM
$A50D (-23283) \SE\      DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'FP' COMMAND
$A510 (-23280) \SE\      DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'WRITE' COMMAND
$A51B (-23269) \SE\      DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'READ' COMMAND
$A531 (-23247) \SE\      DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'INT' COMMAND
$A54F (-23217) \SE\      DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'INIT' COMMAND
$A54F (-23217) \SE\      DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'EXEC' COMMAND
$A566 (-23194) \SE\      DOS 3.1 (48K) ENTRY POINT FOR CODE TO IMPLEMENT 'POSITION' COMMAND
$A56E (-23186) \SE\      DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'CATALOG' COMMAND
$A57A (-23174) \SE\      DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'FP' COMMAND
$A59E (-23138) \SE\      DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'INT' COMMAND
$A5C6 (-23098) \SE\      DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'EXEC' COMMAND
$A5DD (-23075) \SE\      DOS 3.2/3.3 (48K) ENTRY POINT OF CODE TO IMPLEMENT 'POSITION' COMMAND
$A60E (-23026) \SE\      DOS 3.2/3.3 - CODE WHICH STARTS THE READ PROCESS
$A626 (-23002) \SE\      DOS 3.2/3.3 - CODE WHICH STARTS THE WRITE PROCESS
$A644 (-22972) \SE\      DOS 3.2/3.3 - CODE WHICH STORES DATA COMING FROM TEXT FILE INTO KEYBOARD BUFFER.
                           USED BY EXEC COMMAND
$A679 (-22919) \SE\      DOS 3.2/3.3 - CODE TO CLOSE FILES AND EXIT DOS
$A69D (-22883) \SE\      DOS 3.2/3.3 - CODE TO SET UP ADDRESS OF NAME SECTION OF NEXT FILE
$A6AB (-22869) \SE\      DOS 3.2/3.3 - CODE TO CLOSE THE BUFFER LAST USED
$A6C4 (-22844) \SE\      DOS 3.2/3.3 - PRINTS 'SYNTAX ERROR'
$A6C8 (-22840) \SE\      DOS 3.2/3.3 - PRINT 'NO BUFFERS AVAILABLE'
$A6CC (-22836) \SE\      DOS 3.2/3.3 - PRINTS 'PROGRAM TOO LARGE'
$A6D0 (-22832) \SE\      DOS 3.2/3.3 - PRINTS 'FILE TYPE MISMATCH'
$A6D2 (-22830) \SE\      DOS 3.2/3.3 - START OF ERROR PROCESSING ROUTINE. ENTER WITH ERROR NUMBER IN A-REG
$A6D5 (-22827) \SE\      DOS 3.2/3.3 - PRINTS OTHER ERROR MESSAGES BY MESSAGE NUMBER CONTAINED IN $AA5C
$A702 (-22782) \SE\      DOS 3.2/3.3 - ANOTHER PART OF ROUTINE THAT PRINTS APPROPRIATE DOS ERROR MESSAGES
                           (?)
$A743 (-22717) \SE\      DOS 3.2/3.3 - MOVES NAME FROM THE NAME BUFFER TO THE NAME SECTION OF THE FILE
                           BUFFER
$A764 (-22684) \SE\      DOS 3.2/3.3 - ATTEMPTS TO FIND A FILE BUFFER ALREADY IN USE BY THE NAME GIVEN
$A7C4 (-22588) \SE\      DOS 3.2/3.3 - CHECKS FILE TYPE
$A7D4 (-22572) \SE\      DOS 3.2/3.3 - SETS UP FILE BUFFERS AND ADDRESSES (USED BY MAXFILES)
$A7E0-$A863 (-22560--22429) [(DOS 3.1 COMMAND TBL)] \PB\DOS 3.1 COMMAND TABLE (DOS 3.1 - 48K APPLE ONLY!)
$A851 (-22447) \SE\      DOS 3.2/3.3 - RESTORES DOS HOOKS (SAVE ADDRESSES OF CHARACTER INPUT AND OUTPUT
                           ROUTINES CURRENTLY IN USE AND RECONNECT DOS)
$A884-$A908 (-22396--22264) [(DOS 3.2/3.3 COMMAND TBL)] \PB\DOS 3.2 (48K) COMMAND NAME TABLE OF DOS COMMAND DECODER
                           (TABLE-DRIVEN COMMAND PARSER). CONTAINS NAMES OF DOS
                           COMMANDS WITH LAST BYTE OF EACH NAME HAVING HIGH (7TH) BIT
                           SET; OTHER BYTES HAVE IT CLEAR. THIS PERMITS CLOSE PACKING
                           FOR SEQUENTIAL SEARCH. EOT IS $00 BYTE

```


\$A909-\$A970 (-22263-22160) \PB\	DOS 3.2/3.3 (48K) PARAMETER VALIDITY TABLE OF DOS COMMAND DECODER. USED TO CHECK VALIDITY OF VARIOUS PARAMETERS AGAINST USABILITY WITH VARIOUS COMMANDS. USES 2-BYTE MASKS. ONE BYTE USED TO DETERMINED WHAT TYPE(S) OF EXTRA DATA ARE NEEDED BY A COMMAND; THE OTHER FOR WHAT FILE TYPE TO CREATE OR LOOK FOR
\$A941 (-22207)	DOS 3.2/3.3 -TABLE CONTAINING THE LETTERS V'D-S-L-R-B-A-C. THESE ARE USED AS SINGLE-CHARACTER KEYWORDS WHICH MAY APPEAR ON DOS COMMANDS. USED WHEN CHECKING FOR THIS OPTIONAL DATA
\$A94B-\$A954 (-22197-22188)	DOS 3.2/3.3 -TABLE OF BYTES FOR. TABLE CONTAINS OPERAND MASKS ASSOCIATED WITH EACH OPERAND. IF HIGH ORDER BIT IS CLEAR IT INDICATES A NUMERIC ASSOCIATED WITH IT DETERMINING WHAT TYPE OF OPTIONAL DATA TO LOOK FOR. TABLE CONTAINS OPERAND MASKS ASSOCIATED WITH EACH OPERAND. IF HIGH ORDER BIT IS CLEAR IT INDICATES A NUMERIC ASSOCIATED WITH IT
\$A955-\$A970 (-22187-22160)	DOS 3.2/3.3 -TABLE OF MINIMUM AND MAXIMUM RANGES FOR V'D-S-L-R-B-A
\$A971-\$AA3E (-22159-21954) \PB\	DOS 3.2/3.3 (48K) ERROR MESSAGE TABLE (TEXT OF MESSAGES) NOTE: \$AA3F-\$AA4F IS INDEX TABLE FOR SELECTION OF SPECIFIC MESSAGE FROM THIS BLOCK
\$AA3F-\$AA4F (-21953-21937) \PB\	DOS 3.2/3.3 (48K) INDEX TABLE FOR ERROR MESSAGES AT \$A971
\$A8CD-\$A980 (-22323-22144) [(DOS 3.1 ERROR MSGS)] \PB\	DOS 3.1 ERROR MSG TABLE (DOS 3.1 - 48K APPLE ONLY!)
\$A971-\$AA3E (-22159-21954) [(DOS 3.2/3.3 ERROR MSGS)] \PB\	DOS 3.2/3.3 ERROR MESSAGES (DOS 3.2/3.3 - 48K APPLE ONLY!)
\$A996-\$A997 (-22122-22121) [COUT] \P2\	DOS 3.1 INTERNAL HOOK ENTRY ADDRESS TO OUTPUT A CHARACTER
\$A998-\$A999 (-22120-22119) [CIN] \P2\	DOS 3.1 INTERNAL HOOK ENTRY ADDRESS TO INPUT A CHARACTER
\$A9A3-\$A9A4 (-22109-22108) \P2\	LENGTH OF MOST RECENTLY BLOADED FILE (DOS 3.1 ONLY - 48K)
\$A9B5-\$A9B6 (-22091-22090) \P2\	STARTING ENTRY ADDRESS OF BLOADED FILE (DOS 3.1 ONLY - 48K)
\$AA0B (-22005)	START OF LIST OF POINTERS TO SECTIONS OF DOS 3.1 I/O PACKAGES
\$AA3F-\$B2CE (-21953-19762) \SB\	DOS 3.1 I/O PACKAGE (48K APPLE) (SEE \$AAFD FOR CORRESPONDING PKG DOS 3.2-3.2.1-3.3)
\$AA42-\$AAC8 (-21950-21816) \PB\	DOS 3.2/3.3 (48K) BLOCK OF IMPORTANT VARIABLES (PARAMETERS)
\$AA4F-\$AA50 (-21937-21936) \P2\	DOS 3.2/3.3 (48K) CURRENT FILE BUFFER POINTER
\$AA51 (-21935) \P1\	DOS 3.2/3.3 STATE-MACHINE INPUT-STATE CONTROL PARAMETER
\$AA52 (-21934) \P1\	DOS 3.2/3.3 (48K) STATE-MACHINE OUTPUT-STATE-CONTROL PARAMETER (0-7)
\$AA53-\$AA54 (-21933-21932) \P2\	DOS 3.2/3.3 (48K) OUTPUT HOOK - I.E. ADDRESS OF CHARACTER OUTPUT ROUTINE WHICH WAS IN CONTROL WHEN DOS WAS RECONNECTED (DEFAULT \$FDF0)
\$AA55-\$AA56 (-21931-21930) \P2\	DOS 3.2/3.3 (48K) INPUT HOOK - I.E. ADDRESS OF CHARACTER INPUT ROUTINE WHICH WAS IN CONTROL WHEN DOS WAS RECONNECTED (DEFAULT \$FD1B)
\$AA57 (-21929) \P1\	DOS 3.2/3.3 (48K) CURRENT NUMBER OF DOS BUFFERS. DEFAULT=3; CHANGED BY SETTING MAXFILES
\$AA59 (-21927) \P1\	DOS 3.2/3.3 (48K) TEMPORARY DOS STORAGE FOR S-REGISTER
\$AA5A (-21926) \P1\	DOS 3.2/3.3 (48K) TEMPORARY DOS STORAGE FOR X-REGISTER
\$AA5B (-21925) \P1\	DOS 3.2/3.3 (48K) TEMPORARY DOS STORAGE FOR Y-REGISTER
\$AA5C (-21924) \P1\	DOS 3.2/3.3 (48K) TEMPORARY DOS STORAGE FOR A-REGISTER
\$AA5C (-21924) \P1\	DOS 3.2/3.3 (48K) UPON ENCOUNTERING A DOS ERROR CONTAINS DOS ERROR CODE USED AS INDEX INTO TABLE AT \$AA3F OUTPUT OF WHICH IS USED AS INDEX TO ERROR TEXT TABLE AT \$A971
\$AA5D (-21923) \P1\	DOS 3.2/3.3 (48K) LINE BUFFER INDEX (DISPLACEMENT)
\$AA5E (-21922) \P1\	DOS 3.2/3.3 (48K) MON-NOMON STATUS PARAMETERS MASK
\$AA5F (-21921) \P1\	DOS 3.2/3.3 (48K) COMMAND NUMBER
\$AA60-\$AA61 (-21920-21919) \P2\	DOS 3.2/3.3 (48K) BLOCK LENGTH (FOUND L\$ FROM A 'BLOAD')
\$AA60-\$AA61 (-21920-21919) \P2\	DOS 3.2/3.3 (48K) - CONTAINS LENGTH OF LOADED BASIC PROGRAM
\$AA62 (-21918) \P1\	DOS 3.2/3.3 (48K) STORES COMMAND NUMBER
\$AA63 (-21917) \P1\	DOS 3.2/3.3 (48K) TEMP 1A
\$AA64 (-21916) \P1\	DOS 3.2/3.3 (48K) TEMP 2A
\$AA65 (-21915) \P1\	DOS 3.2/3.3 (48K) COMMAND INPUT OPTIONS

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$AA66-\$AA74 (-21914-21900)	DOS 3.2/3.3 (48K) KEYWORD VALUES PARSED FROM COMMAND AND/OR DEFAULTED
\$AA66-\$AA67 (-21914-21913) \P2\	DOS 3.2/3.3 (48K) COMMAND (OR DEFAULT) VOLUME
\$AA68-\$AA69 (-21912-21911) \P2\	DOS 3.2/3.3 (48K) COMMAND (OR DEFAULT) DRIVE
\$AA6A-\$AA6B (-21910-21909) \P2\	DOS 3.2/3.3 (48K) COMMAND (OR DEFAULT) SLOT
\$AA6C-\$AA6D (-21908-21907) \P2\	DOS 3.2/3.3 (48K) COMMAND L-VALUE (LENGTH)
\$AA6E-\$AA6F (-21906-21905) \P2\	DOS 3.2/3.3 (48K) COMMAND R-VALUE (RECORD NUMBER)
\$AA70-\$AA71 (-21904-21903) \P2\	DOS 3.2/3.3 (48K) COMMAND B-VALUE (BYTE NUMBER)
\$AA72-\$AA73 (-21902-21901) \P2\	DOS 3.2/3.3 (48K) COMMAND A-VALUE (ADDRESS)
\$AA72-\$AA73 (-21902-21901) \P2\	CONTAINS START ADDRESS OF MOST RECENTLY BLOAD-ED PROGRAM OR DATA (DOS 3.2/3.3 - 48K APPLE)
\$AA74 (-21900) \P1\	DOS 3.2/3.3 (48K) DOS 'C' 'I' & 'O' BITS
\$AA75-\$AA92 (-21899-21870) \PB\	DOS 3.2/3.3 (48K) START OF LAST FILE NAME USED IN A DOS COMMAND. THIS IS NORMALLY FILE NAME OF BUFFER #3. IF RUN COMMAND USED WITHOUT FILE NAME THIS FIELD IS SET TO BLANKS. AT BOOT THIS AREA CONTAINS THE NAME OF THE GREETING PROGRAM
\$AA93-\$AAB0 (-21869-21840) \PB\	DOS 3.2/3.3 (48K) START OF FILE NAME - BUFFER #2
\$AAB1 (-21839) \P1\	DOS 3.2/3.3 (48K) DEFAULT NUMBER OF FILE BUFFERS (3)
\$AAB2 (-21838) \P1\	DOS 3.2/3.3 (48K) COMMAND CHARACTER (CTRL-D)
\$AAB3 (-21837) \P1\	DOS 3.2/3.3 (48K) EXEC FILE STATE (DIRECT DEFERRED ETC.)
\$AAB4-\$AAB5 (-21836-21835) \P2\	DOS 3.2/3.3 (48K) EXEC FILE BUFFER POINTER
\$AAB6 (-21834) \P1\	DOS 3.2/3.3 (48K) APPLESOFT-INTEGEBASIC SWITCH (\$00=INTEGER BASIC;\$40=ROM APPLESOFT;\$80=RAM APPLESOFT)
\$AAB7 (-21833) \P1\	DOS 3.2/3.3 (48K) APPLESOFT - BEGIN RUN SWITCH (\$00=NO;\$40 OR \$80=YES)
\$AAB8-\$AAC0 (-21832-21824) \PB\	TEXT WORD 'APPLESOFT' (NAME OF DOS 3.2/3.3 FP FILE USED TO GET DISK APPLESOFT)
\$AAC1-\$AAC2 (-21823-21822) \P2\	DOS 3.2/3.3 (48K) ADDRESS POINTER TO IOB (RWTS BUFFER) NOTE: THIS IS LOADED INTO Y & A-REGS WHEN \$03E3 IS BRANCHED TO
\$AAC3-\$AAC4 (-21821-21820) \P2\	DOS 3.2/3.3 (48K) ADDRESS POINTER TO VTOC BUFFER (BUFFER FOR TRACK/SECTOR LIST - USED BY RWTS)
\$AAC5-\$AAC6 (-21819-21818) \P2\	DOS 3.2/3.3 (48K) ADDRESS POINTER TO SYS BUFFER (BUFFER FOR DATA - USED BY RWTS)
\$AAC7-\$AAC8 (-21817-21816) \P2\	DOS 3.2/3.3 (48K) ADDRESS POINTER TO TOP OF RAM+1
\$AAC9-\$AAFC (-21815-21764) \SB\	DOS 3.2/3.3 (48K) I/O PACKAGE COMMANDS FUNCTIONAL-CODE LOOK-UP TABLE. THIS TABLE IS USED AT \$AB14 TO \$AB1E TO JUMP TO CORRECT I-O ROUTINE. \$B5BB IS USED TO CHOOSE WHICH I-O ROUTINE WILL BE CALLED
\$AAC9-\$AACA (-21815-21814) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR 'GOOD RETURN' (\$B37F-1)
\$AACB-\$AACC (-21813-21812) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR 'OPEN FILE' (\$AB22-1)
\$AACD-\$AACE (-21811-21810) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR 'CLOSE FILE' (\$AC06-1)
\$AACF-\$AAD0 (-21809-21808) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR 'READ FROM FILE' (\$AC58-1)
\$AAD1-\$AAD2 (-21807-21806) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR 'WRITE TO FILE' (\$AC70-1)
\$AAD3-\$AAD4 (-21805-21804) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR 'DELETE FILE' (\$AD28-1)
\$AAD5-\$AAD6 (-21803-21802) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR 'PRINT CATALOG' (\$AD98-1)
\$AAD7-\$AAD8 (-21801-21800) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR 'LOCK A FILE' (\$ACEF-1)
\$AAD9-\$AADA (-21799-21798) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR 'UNLOCK A FILE' (\$ACF6-1)
\$AADB-\$AADC (-21797-21796) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR 'RENAME FILE' (\$AC3A-1)
\$AADD-\$AADE (-21795-21794) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR 'POSITION FILE' (\$AD12-1)
\$AADF-\$AAE0 (-21793-21792) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR 'FORMAT DISK (INIT)' (\$AE8E-1)
\$AAE1-\$AAE2 (-21791-21790) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR 'VERIFY FILE' (\$AD18)
\$AAE3-\$AAE4 (-21789-21788) \P2\	DOS 3.2/3.3 (48K) I-O PKG ADDRESS FOR GOOD RETURN (\$B37F-1) [DUMMY ENTRY IN TABLE?]
\$AAE5-\$AAFD (-21787-21776) \PB\	DOS 3.2/3.3 (48K) I-O PKG READ COMMAND ENTRY-VECTOR TABLE. THIS TABLE USED AT \$AC58 TO \$AC69 TO JUMP TO CORRECT READ ROUTINE. THE VALUE OF \$B5BC IS USED TO GET THE CORRECT ENTRY AND A JUMP IS MADE TO THERE
\$AAE5-\$AAE6 (-21787-21786) \P2\	DOS 3.2/3.3 (48K) I-O PKG READ COMMAND ENTRY-VECTOR FOR 'GOOD RETURN' (\$B37F-1)

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$AAE7-\$AAE8 (-21785-21784) \P2\	DOS 3.2/3.3 (48K) I-O PKG READ COMMAND ENTRY-VECTOR FOR 'READ NEXT BYTE' (\$AC8A-1)
\$AAE9-\$AAEA (-21783-21782) \P2\	DOS 3.2/3.3 (48K) I-O PKG READ COMMAND ENTRY-VECTOR FOR 'READ NEXT BLOCK' (\$AC96-1)
\$AAEB-\$AAEC (-21781-21780) \P2\	DOS 3.2/3.3 (48K) I-O PKG READ COMMAND ENTRY-VECTOR FOR 'READ SPECIFIC BYTE' (\$AC93-1)
\$AAED-\$AAEE (-21779-21778) \P2\	DOS 3.2/3.3 (48K) I-O PKG READ COMMAND ENTRY-VECTOR FOR 'READ SPECIFIC BLOCK' (\$AC93-1)
\$AAEF-\$AAF0 (-21777-21776) \P2\	DOS 3.2/3.3 (48K) I-O PKG READ COMMAND ENTRY-VECTOR FOR 'GOOD RETURN' (DUMMY??)(\$B37F-1)
\$AAF1-\$Aafc (-21775-21764) \PB\	DOS 3.2/3.3 (48K) I-O PKG WRITE COMMAND ENTRY-VECTOR TABLE. THIS TABLE IS USED AT \$AC70 TO \$AC86 TO JUMP TO THE CORRECT WRITE ROUTINE. THE VALUE OF \$B5BC IS USED TO SPECIFY WHICH ROUTINE WILL BE JUMPED TO
\$AAF1-\$AAF2 (-21775-21774) \P2\	DOS 3.2/3.3 (48K) I-O PKG WRITE COMMAND ENTRY-VECTOR FOR 'GOOD RETURN' (\$B37F-1)
\$AAF3-\$AAF4 (-21773-21772) \P2\	DOS 3.2/3.3 (48K) I-O PKG WRITE COMMAND ENTRY-VECTOR FOR 'WRITE NEXT BYTE' (\$ACBE-1)
\$AAF5-\$AAF6 (-21771-21770) \P2\	DOS 3.2/3.3 (48K) I-O PKG WRITE COMMAND ENTRY-VECTOR FOR 'WRITE NEXT BLOCK' (\$ACCA-1)
\$AAF7-\$AAF8 (-21769-21768) \P2\	DOS 3.2/3.3 (48K) I-O PKG WRITE COMMAND ENTRY-VECTOR FOR 'WRITE SPECIFIC BYTE' (\$ACBB-1)
\$AAF9-\$AAFA (-21767-21766) \P2\	DOS 3.2/3.3 (48K) I-O PKG WRITE COMMAND ENTRY-VECTOR FOR 'WRITE SPECIFIC BLOCK' (\$ACC7-1)
\$AAFB-\$Aafc (-21765-21764) \P2\	DOS 3.2/3.3 (48K) I-O PKG WRITE COMMAND ENTRY-VECTOR FOR 'GOOD RETURN' (\$BE7F-1) [DUMMY ENTRY IN TABLE?]
\$AAFD-\$B5FF (-21763-18945) \SB\	DOS 3.2/3.3 (48K) FILE MANAGER I-O PACKAGE (INCLUDING PARAMETER & SYSTEM BUFFER AREAS). CONTAINS CODE TO PERFORM FUNCTIONS LIKE OPEN" CLOSE" RENAME" DELETE" WRITE BYTES TO A FILE" READ BYTES FROM A FILE ETC. NOTE: REFERENCED FROM PAGE 3 BY BRANCH FROM \$03D6
\$AAFD-\$B396 (-21763-19562) \SB\	DOS 3.2/3.3 (48K) FILE MANAGER (I-O PACKAGE) CODE (LESS PARAMETER & SYSTEM BUFFER AREAS)
\$AAFD (-21763) \SE\	DOS 3.2/3.3 FILE MANAGER (I-O PACKAGE) ENTRY POINT. REFERENCED FROM PAGE 3 BY A BRANCH FROM \$03D6
\$AB22 (-21726) \SE\	DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO OPEN FILE
\$AB28 (-21720)	DOS 3.2/3.3 (48K). READS VTOC & DIRECTORY ATTEMPTING TO FIND AN ENTRY WITH SAME NAME AS THAT GIVEN. IF NOT FOUND CHECKS TABLE OF MASKS TO SEE IF IT IS ALLOWED TO CREATE A FILE. IF IT IS ALLOWED IT DOES SO; IF NOT EXITS WITH 'FILE NOT FOUND' OR 'LANGUAGE NOT AVAILABLE'
\$ABDC (-21540)	DOS 3.2/3.3 (48K) - CLEARS MISCELLANEOUS INFO HARDWARE BUFFER;SETS VOLUME NUMBER DRIVE NUMBER AND SLOT NUMBER
\$AC06 (-21498) \SE\	DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO CLOSE FILE (UPDATES VTOC" TRACK BIT MAP AND SECTOR COUNT OF DIRECTORY ENTRY AS NEEDED)
\$AC3A (-21446) \SE\	DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO RENAME FILE (FINDS DIRECTORY ENTRY" STORES NEW NAME IN ENTRY" THEN WRITES THAT DIRECTORY SECTOR BACK TO DISK)
\$AC58 (-21416) \SE\	DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO READ FROM FILE
\$AC70 (-21392) \SE\	DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO WRITE TO FILE
\$AC87 (-21369) \SE\	DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO READ SPECIFIC BYTE
\$AC8A (-21366) \SE\	DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO READ NEXT BYTE
\$AC93 (-21357) \SE\	DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO READ SPECIFIC BLOCK
\$ACBB (-21317) \SE\	DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO WRITE SPECIFIC BYTE
\$AC96 (-21354) \SE\	DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO READ NEXT BLOCK
\$ACBE (-21314) \SE\	DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO WRITE NEXT BYTE
\$ACC7 (-21305) \SE\	DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO WRITE SPECIFIC BLOCK

\$IAE7 - \$ACC7

Prof. Luebbert's "What's Where in the Apple"

NUMERIC ATLAS

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$ACCA (-21302) \SE\      DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO WRITE NEXT BLOCK
$ACEF (-21265) \SE\      DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO LOCK A FILE
$ACF6 (-21258) \SE\      DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO UNLOCK A FILE
$AD12 (-21230) \SE\      DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO POSITION FILE
$AD18 (-21224) \SE\      DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO VERIFY FILE
$AD2B (-21205) \SE\      DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO DELETE FILE
$AD54 (-21164)           DOS 3.2/3.3 (48K) PART OF DELETE ROUTINE WHICH FREES SECTORS USED BY DELETED FILE
$AD98 (-21096) \SE\      DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO PRINT CATALOG
$AE39 (-20935)           DOS 3.2/3.3 (48K) PART OF CATALOG ROUTINE RESPONSIBLE FOR PAUSING DURING A
                        CATALOG LISTING. TO DISABLE THIS INSTRUCTION SIMPLY PATCH OVER IT WITH 3 NOP'S
$AE42 (-20926)           DOS 3.2/3.3 (48K) PART OF CATALOG ROUTINE WHICH PRINTS THE NUMBER IN $0044 AS 3
                        DIGIT ASCII
$AE6A (-20886)           DOS 3.2/3.3 (48K) MOVES MISCELLANEOUS INFO FROM THE FILE BUFFER TO THE I-O PKG
                        BUFFER
$AE7E (-20866)           DOS 3.2/3.3 (48K) MOVES MISCELLANEOUS INFO FROM THE FILE BUFFER TO THE I-O PKG
                        BUFFER
$AE8E (-20850) \SE\      DOS 3.2/3.3 (48K) I-O PKG ROUTINE TO FORMAT A DISK (INIT)
$AF1D (-20707)           DOS 3.2/3.3 (48K) WRITES DATA SECTION OF FILE BUFFER TO DISK
$AF34 (-20684)           DOS 3.2/3.3 (48K) WRITES TRACK/SECTOR LIST SECTION OF FILE BUFFER TO DISK
$AF4B (-20661)           DOS 3.2/3.3 (48K) SETS HARDWARE POINTER TO THE TRACK AND SECTOR LIST SECTION OF
                        THE FILE BUFFER BEING USED
$AF5E (-20642)           DOS 3.2/3.3 (48K) CHECKS POSITION IN FILE. IF OUT OF CURRENT SECTOR READS/WRITES
                        NEXT SECTOR" UPDATES VTOC BUFFER" UPDATES TRACK/SECTOR LIST SECTION OF FILE
                        BUFFER IF IN WRITE MODE
$AFDC (-20516)           DOS 3.2/3.3 (48K) READS FROM DISK INTO DATA SECTION OF FILE BUFFER
$AFE4 (-20508)           DOS 3.2/3.3 (48K) SETS HARDWARE POINTERS TO DATA SECTION OF FILE BUFFER BEING
                        USED
$AFF7 (-20489)           DOS 3.2/3.3 (48K) READS VTOC TO ITS BUFFER ($B3BB-$B4BA)
$AFFB (-20485)           DOS 3.2/3.3 (48K) WRITES VOTC FROM ITS BUFFER ($B3BB-$B4BA)
$B011 (-20463)           DOS 3.2/3.3 (48K) READS A DIRECTORY SECTOR INTO ITS BUFFER ($B4BB-$B5BA).
                        INITIALLY READS SECTOR A. SUCCESSIVE ENTRIES INTO THIS SUBROUTINE READ SUCCESSIVE
                        SECTORS FROM DISK. WHEN ALL SECTORS READ AND SUBROUTINE CALLED AGAIN IT MAY EXIT
                        WITH CARRY SET
$B037 (-20425)           DOS 3.2/3.3 (48K) WRITES CURRENT DIRECTORY SECTOR FROM BUFFER TO DISK
$B052 (-20398)           DOS 3.2/3.3 (48K) SETS UP IOB FOR DIRECTORY SECTORS; GOES TO RWTS
$B0A0 (-20320)           DOS 3.2/3.3 (48K) NO ERROR EXIT TO $B052
$B0A1 (-20319)           DOS 3.2/3.3 (48K) START OF ERROR-HANDLING ROUTINE FOR $B052
$B0B6 (-20298)           DOS 3.2/3.3 (48K) CHECKS POSITION IN FILE; READS/WRITES NEXT SECTOR AS NEEDED
$B134 (-20172)           DOS 3.2/3.3 (48K) INITIALIZES DATA SECTION OF FILE BUFFER TO ALL ZEROES
$B15B (-20133)           DOS 3.2/3.3 (48K) SETS NEXT POSITION IN FILE
$B194 (-20076)           DOS 3.2/3.3 (48K) INCREMENTS POSITION IN FILE
$B1A2 (-20062)           DOS 3.2/3.3 SETS NEXT RAM ADDRESS
$B1B5 (-20043)           DOS 3.2/3.3 CALCULATES HOW MUCH RAM IS LEFT
$B1C9-$B213 (-20023-19941) DOS 3.3 - LOCATE OR ALLOCATE A DIRECTORY ENTRY IN THE CATALOG; READ THE VTOC
                        SECTOR ($AFF7); SET $0042-$0043 TO POINT TO FILE NAME BEING LOOKED FOR; SET PAGE
                        NUMBER TO 1 (LOCATE FILE).
$B1C9 (-20023)           DOS 3.2/3.3 READS VTOC (VOLUME TABLE OF CONTENTS) AND SUCCESSIVE ENTRIES
                        ATTEMPTING TO FIND SPECIFIED FILE NAME
$B21C-$B22F (-19940-19921) DOS 3.3 - COPY FILE NAME TO DIRECTORY ENTRY. ADVANCE INDEX TO FILE NAME FIELD IN
                        DIRECTORY ENTRY; COPY 30 BYTE FILENAME TO DIRECTORY ENTRY; RELOAD DIRECTORY INDEX
                        AND RETURN TO CALLER

```


HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$B21E (-19938)	DOS 3.2/3.3 PUTS NAME OF FILE INTO DIRECTORY
\$B224 (-19932)	DOS 3.2/3.3 SETS NEXT SECTOR; UPDATES VTOC BUFFER
\$B230 (-19920)	DOS 3.3 ADVANCE INDEX TO NEXT DIRECTORY ENTRY IN SECTOR; ADD 35 (LENGTH OF ENTRY) TO INDEX; TEST FOR END OF SECTOR AND RETURN TO CALLER
\$B23A-\$B243 (-19910-19901)	DOS 3.3 SWITCH TO SECOND PASS IN DIRECTORY SCAN. IF ON PASS ONE SWITCH TO PASS 2 AND GOTO \$B1D8; IF ON PASS TWO EXIT FILE MANAGER WITH 'DISK FULL' ERROR
\$B244-\$B2C2 (-19900-19774)	DOS 3.3 ALLOCATE A DISK SECTOR
\$B2C3-\$B2D0 (-19773-19748)	DOS 3.3 RELEASE PRE-ALLOCATED SECTORS IN CURRENT TRACK AND CHECKPOINT THE VTOC.
\$B2C3 (-19773)	DOS 3.2/3.3 UPDATES VTOC
\$B2DD-\$B2FF (-19747-19713)	DOS 3.3 (48K) - FREE ONE OR MORE SECTORS BY SHIFTING MASK IN FILE MANAGER'S ALLOCATION AREA BACK INTO VTOC BIT MAP
\$B2DD (-19747)	DOS 3.2/3.3 CALCULATES TRACK BIT MAP FOR VTOC
\$B300-\$B35E (-19712-19618)	DOS 3.3 (48K) - CALCULATE FILE POSITION
\$B35F-\$B37D (-19617-19587)	DOS 3.3 (48K) - ERROR EXISTS
\$B35F (-19617)	DOS 3.3 (48K) - RC=1 "LANGUAGE NOT AVAILABLE"
\$B363 (-19613)	DOS 3.3 (48K) - RC=2 "RANGE ERROR" (BAD OPCODE)
\$B367 (-19609)	DOS 3.3 (48K) - RC=3 "RANGE ERROR" (BAD SUBCODE)
\$B36B (-19605)	DOS 3.3 (48K) - RC=4 "WRITE PROTECTED"
\$B36F (-19601)	DOS 3.3 (48K) - RC=5 "END OF DATA"
\$B373 (-19597)	DOS 3.3 (48K) - RC=6 "FILE NOT FOUND"
\$B37B (-19589)	DOS 3.3 (48K) - RC=A "FILE LOCKED"
\$B37F-\$B396 (-19585-19562)	EXIT FILE MANAGER
\$B37F (-19585) \SE\	DOS 3.2/3.3 (48K) FILE MANAGER (I-O) PKG GOOD RETURN (RETURN CODE =0; CLEAR CARRY FLAG AND GO TO \$B386)
\$B385 (-19579)	DOS 3.3 (48K) - EXIT SETTING CARRY FLAG TO INDICATE ERROR
\$B386 (-19578)	DOS 3.3 (48K) - SAVE RETURN CODE IN PARAMLIST; CLEAR MONITOR STATUS REGISTER; SAVE FILE MANAGER WORKAREA TO FILE BUFFER (\$AE7E); RESTORE PROCESSOR STATUS AND STACK REGISTER; EXIT TO ORIG CALLER OF FILE MANAGER
\$B397-\$B5FF (-19561-18689)	DOS 3.2/3.3 (48K) FILE MANAGER (I-O PACKAGE) DATA AREA (PARAMETERS & SYSTEM BUFFER)
\$B397-\$B3A3 (-19561-19549)	DOS 3.3 FILE MANAGER (I-O PACKAGE) SCRATCH SPACE
\$B397 (-19561) \P2\	DOS 3.2/3.3 (48K) CONTAINS TRACK AND SECTOR ADDRESS OF MOST RECENTLY READ DIRECTORY (CATALOG) SECTOR
\$B39B (-19557)	DOS 3.3 FILE MANAGER S-REGISTER SAVE AREA
\$B39C (-19556)	DOS 3.3 FILE MANAGER DIRECTORY INDEX
\$B39D (-19555)	DOS 3.3 FILE MANAGER CATALOG LINE COUNTER DIRECTOR LOOKUP FLAG - ETC
\$B39E (-19554)	DOS 3.3 (48K) LOCK/UNLOCK MASK ALLOCATION FLAG ETC.
\$B3A0 (-19552)	DOS 3.3 (48K) FOUR BYTE MASK USED BY INIT TO FREE AN ENTIRE TRACK IN THE VTOC BIT MAP
\$B3A4-\$B3A6 (-19548-19546)	DOS 3.3 (48K) DECIMAL CONVERSION TABLE (1-10-100)
\$B3A7-\$B3AE (-19545-19538)	DOS 3.3 (48K) FILE TYPE NAME TABLE USED BY CATALOG. FILE TYPES ARE T-I-A-B-S-R-A-B CORRESPONDING TO HEX VALUES OF \$00-\$02\$04-\$08-\$10-\$20 AND \$40 RESPECTIVELY
\$B3A7 (-19545)	DOS 3.2 (48K) CONTAINS 4 FILETYPE CHARACTERS T I A AND B
\$B3AF-\$B39A (-19537-19526)	DOS 3.2/3.3 (48K) CONTAINS CHARACTER STRING 'DISK VOLUME' FOR CATALOG COMMAND (IN REVERSE ORDER)
\$B3BB-\$B4BA (-19525-19270)	DOS 3.2/3.3 (48K) VTOC SECTOR BUFFER PART OF SYSTEM BUFFER - CONTAINS THE MASTER TRACK/SECTOR BIT MAP SECTOR OR VOLUME TABLE OF CONTENTS
\$B3BC (-19524)	TRACK/SECTOR OF FIRST DIRECTOR SECTOR
\$B3BE (-19522)	DOS RELEASE NUMBER (1-2 OR 3 FOR 3.1-3.2 OR 3.3)
\$B3C1 (-19519)	VOLUME NUMBER OF DISKETTE

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$B3E2 (-19486)	NUMBER OF ENTRIES IN EACH TRACK-SECTOR LIST SECTOR
\$B3EB (-19477)	TRACK TO ALLOCATE NEXT
\$B3EC (-19476)	DIRECTION OF TRACK ALLOCATION (+1 OR -1)
\$B3EF (-19473) \P1\	NUMBER OF TRACKS ON A DISK
\$BEF0 (-16656) \P1\	NUMBER OF SECTORS ON A DISK
\$BEF1 (-16655) \P2\	SECTOR SIZE IN BYTES
\$B3F3-\$B47B (-19469-19333)	ARRAY OF 34 TRACK BIT MAPS
\$B3F3 (-19469)	TRACK 0 BIT MAP
\$B3F4 (-19468)	TRACK 1 BIT MAP
\$B3F5 (-19467)	TRACK 2 BIT MAP
\$B3F6 (-19466)	TRACK 3 BIT MAP
\$B47A (-19334)	TRACK 33 BIT MAP
\$B47B (-19333)	TRACK 34 BIT MAP
\$B3EF-\$B642 (-19473-18878) \HBA\	DOS 3.1 (48K) SYSTEM BUFFER (FOR CATALOG ETC.)(SEE \$B4BB FOR DOS 3.2-3.2.1-3.3)
\$B4BB-\$B5BA (-19269-19014)	DOS 3.2/3.3 DIRECTORY SECTOR BUFFER PART OF SYSTEM BUFFER. CONTAINS LAST ACCESSED DIRECTORY SECTOR (ACCESS BY A CATALOG COMMAND OR ANY OTHER DOS COMMAND REQUIRING A DIRECTORY SECTOR SEARCH)
\$B4BC (-19268)	TRACK-SECTOR OF NEXT DIRECTORY SECTOR
\$B4C6 (-19258)	FIRST DIRECTORY ENTRY AND TRACK OF TRACK-SECTOR LIST
\$B4C7 (-19257)	SECTOR OF TRACK-SECTOR LIST
\$B4C8 (-19256)	FILE TYPE AND LOCK BIT
\$B4C9 (-19255)	FILENAME FIELD (30 BYTES)
\$B4E7 (-19225)	SIZE OF FILE IN SECTORS (INCLUDING TRACK-SECTOR LIST(S))
\$B5BB-\$B5D0 (-19013-18992)	DOS 3.2/3.3 (48K) FILE MANAGER PARAMETER LIST
\$B5BB (-19013)	1ST BYTE BEYOND SYSTEM BUFFER. PAGE 3 ROUTINE AT \$03DC LOADS Y-REG & A-REG TO POINT HERE
\$B5BB (-19013) \P\	DOS 3.2/3.3 (48K) I-O PKG 'OPCODE' PARAMETER USED TO CHOOSE WHICH I-O PKG 'OPCODE' ROUTINE WILL BE CALLED
\$B5BC (-19012)	DOS 3.2/3.3 (48K) I-O PKG 'SUBCODE' PARAMETER USED TO CHOOSE WHICH READ OR WRITE OPTION IS TO BE USED
\$B5BD-\$B5C4 (-19011-19004)	DOS 3.2/3.3 (48K) EIGHT BYTES OF PARAMETERS. PARAMETERS VARY ACCORDING TO 'OPCODE' PARAMETER IN \$B5BB
\$B5C5 (-19003)	DOS 3.2/3.3 FILE MANAAGER PARAMETER LIST RETURN CODE
\$B5C7 (-19001)	DOS 3.2/3.3 ADDRESS OF FILE MANAGER WORK AREA BUFFER
\$B5C9 (-18999)	DOS 3.2/3.3 ADDRESS OF TRACK/SECTOR LIST SECTOR BUFFER
\$B5CB (-18997)	DOS 3.2/3.3 (48K) ADDRESS OF DATA SECTOR BUFFER
\$B5CD (-18995)	DOS 3.2/3.3 (48K) ADDRESS OF NEXT DOS BUFFER ON CHAIN (NOT USED)
\$B5D1-\$B5FD (-18991-18947)	DOS 3.2/3.3 FILE MANAGER WORK AREA
\$B5D1 (-18991)	FIRST TRACK-SECTOR LIST SECTOR'S TRACK & SECTOR
\$B5D3 (-18989)	CURRENT TRACK-SECTOR LIST SECTOR'S TRACK & SECTOR
\$B5D5 (-18987)	FLAGE: 80=T'S LIST NEEDS CHECKPOINT;40=DATA SECTOR NEEDS CHECKPOINT;20=VTOC SECTOR NEEDS CHECKPOINT;02 LAST OPERATION WAS WRITE
\$B5D6 (-18986)	CURRENT DATA SECTOR'S TRACK-SECTOR
\$B5D8 (-18984)	DIRECTORY SECTOR INDEX FOR FILE ENTRY
\$B5D9 (-18983)	INDEX INTO DIRECTORY SECTOR TO DIRECTORY ENTRY FOR FILE
\$B5DA (-18982)	NUMBER OF SECTORS DESCRIBED BY ON TRACK-SECTOR LIST
\$B5DC (-18980)	RELATIVE SECTOR NUMBER OF FIRST SECTOR IN LIST
\$B5DE (-18978)	RELATIVE SECTOR NUMBER +1 OF LAST SECTOR IN LIST
\$B5E0 (-18976)	RELATIVE SECTOR NUMBER OF LAST SECTOR READ
\$B5E2 (-18974)	SECTOR LENGTH IN BYTES
\$B5E4 (-18972)	FILE POSITION (3 BYTES); SECTOR OFFSET;BYTE OFFSET INTO THAT SECTOR

HIEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$B5E8 (-18968)	RECORD LENGTH FROM 'OPEN'
\$B5EA (-18966)	RECORD NUMBER
\$B5EC (-18964)	BYTE OFFSET INTO RECORD.
\$B5EE (-18962)	NUMBER OF SECTORS IN FILE
\$B5F0 (-18960)	SECTOR ALLOCATION AREA (6 BYTES). NEXT SECTOR TO ALLOCATE (SHIFT COUNT); TRACK BEING ALLOCATED; FOUR BYTE BIT MAP OF TRACK BEING ALLOCATED - ROTATED TO NEXT SECTOR TO ALLOCATE
\$B5F6 (-18954)	FILE TYPE
\$B5F7 (-18953)	SLOT NUMBER *16
\$B5F8 (-18952)	DRIVE NUMBER
\$B5F9 (-18951)	VOLUME NUMBER (IN COMPLEMENT FORM)
\$B5FA (-18950)	TRACK NUMBER
\$B5FE-\$B5FF (-18946--18945)	DOS 3.2/3.3 NOT USED
\$B600-\$B6FF (-18944--18689)	DOS 3.2/3.3 BOOT SECTOR BUFFER; I.E. BOOT 2 RWTS (READ-WRITE TRACK-SECTOR) IMAGE
\$B600 (-18944)	DOS 3.3 (48K) START OF PHASE 2 (BOOT 1) IMAGE WHICH CAN BE WRITTEN TO INIT'ED DISKS ON TRACK 0 SECTOR 0
\$B65D (-18851)	DOS 3.3 (48K) PATCH AREA STARTS HERE WITH APPEND PATCH
\$B65E (-18850)	DOS 3.3 (48K) ANOTHER APPEND PATCH STARTS HERE
\$B686 (-18810)	DOS 3.3 (48K) VERIFY PATCH
\$B692 (-18798)	DOS 3.3 (48K) ANOTHER APPEND PATCH STARTS HERE
\$B6FE (-18690)	DOS 3.3 (48K) PAGE ADDRESS OF FIRST PAGE IN PHASE 3 (BOOT 2)
\$B6FF (-18689)	DOS 3.3 (48K) NUMBER OF SECTORS (PAGES) IN PHASE 3 (BOOT 2)
\$B700 (-18688)	DOS 3.2 BOOTSTRAP LOADER FOR PHASE 3 (BOOT 2) OF DOS BOOT (PHASE 1 IN DISK CONTROLLER ROM; PHASE 2 IN PAGE 3 [\$300-\$3FF]). READS DRIVE1 CURRENT SLOT \$B1 SECTORS AND TRACK 0 SECTOR A INTO RAM STARTING AT \$1B00
\$B700-\$B749 (-18688--18615)	DOS 3.3 BOOTSTRAP LOADER FOR PHASE 3 (BOOT 2) OF DOS BOOT (PHASE 2 IN \$0800-\$08FF). SETS RWTS PARAMETER LIST TO READ DOS FROM DISK; CALLS READ-WRITE GROUP OF PAGES (\$B793) & CREATES NEW STACK. ALSO CALLS \$FE93 (SETVID) AND \$FE89 (SETKBD) AND EXITS TO COLDSTART AT \$9D84
\$B74A-\$B78C (-18614--18548)	DOS 3.3 (48K) - WRITES DOS ONTO TRACKS 0-2. SETS RWTS PARAMETER LIST TO READ DOS FROM DISK; CALLS READ/WRITE GROUP OF PAGES (\$B793); EXITS TO CALLER
\$B74A (-18614)	DOS 3.2 (48K) - WRITES \$0A SECTORS STARTING FROM \$B600 THEN \$1B SECTORS STARTING AT \$1B00 BEGINNING AT TRACK 0 SECTOR 0
\$B78D-\$B792 (-18547--18542)	DOS 3.3 (48K) UNUSED
\$B793-\$B7B4 (-18541--18508) \SBA	DOS 3.3 (48K) READ/WRITE A GROUP OF PAGES. CALLS RWTS THROUGH EXTERNAL ENTRY POINT \$B7B5 & EXITS TO CALLER
\$B793 (-18541)	DOS 3.2-3.2.1-3.3 ROUTINE TO STORE A BLOCK OF CONSECUTIVE SECTORS. LOADS COMMAND BYTE (\$B7FC); NUMBER OF SECTORS IN \$B7E1; DOS 3.2 INCREMENTS - SET UP IOBLK TO 1ST SECTOR; DOS 3.3 DECREMENTS - SET UP IOBLK TO LAST SECTOR
\$B793 (-18541)	DOS 3.2 (48K) - INCREMENTS OR DECREMENTS TRACK/SECTOR AS NEEDED AND DATA ADDRESS FOR \$B700 & \$B793 ROUTINES
\$B7B5-\$B7C1 (-18507--18495)	DOS 3.3 (48K) DISABLE INTERRUPTS AND CALL RWTS
\$B7B5 (-18507)	DOS 3.2 (48K) START OF RWTS-IN-ENVIRONMENT ROUTINE. DISABLES INTERRUPTS; CALLS RWTS (LOCATED AT \$BD00); RE-ENABLES INTERRUPTS AND PASSES BACK RETURN CODE FROM RWTS IN FORM OF CARRY FLAG
\$B7C2-\$B7D5 (-18494--18475)	DOS 3.3 (48K) SET RWTS PARAMETERS FOR WRITING DOS
\$B7C2 (-18494)	DOS 3.2 (48K) SETS ADDRESS OF DATA BUFFER AND SETS EXPECTED VOLUME NUMBER
\$B7D6-\$B7DE (-18474--18466)	DOS 3.3 (48K) ZERO CURRENT BUFFER (256 BYTES POINTED TO BY \$0042-\$0043) AND EXIT TO CALLER
\$B7DB (-18469)	DOS 3.2 (48K) STORES ZEROES IN ONE PAGE STARTING AT ADDRESS IN \$0042-\$0043
\$B7DF-\$B7E7 (-18465--18457)	DOS 3.3 (48K) DOS PHASE 3 (BOOT 2) BOOT LOADER PARAMETER LIST

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$B7DF (-18465)      DOS 3.3 (48K) UNUSED
$B7E0 (-18464)      DOS 3.3 (48K) NUMBER OF PAGES IN 2ND DOS LOAD (PHASE 3)
$B7E1 (-18463)      DOS 3.3 NUMBER OF SECTORS TO READ/WRITE
$B7E2 (-18462)      DOS 3.3 NUMBER OF PPAGES IN 1ST DOS LOAD (PHASE 2)
$B7E3 (-18461)      DOS 3.3 INIT DOS PAGE COUNTER
$B7E4~$B7E5 (-18460~-18459)  DOS 3.3 POINTER TO RWTS PARAMETER LIST
$B7E6~$B7E7 (-18458~-18457)  DOS 3.3 POINTER TO 1ST STAGE BOOT LOCATION
$B7E8~$B7F8 (-18456~-18440)  DOS 3.2/3.3 (48K) RWTS PARAMETER LIST OR SYSTEM IOB. THIS IOB SET UP ACCORDING TO
                                LAST DOS OPERATION THAT OCCURED
$B7E8 (-18456)      DOS 3.2/3.3 (48K) - TABLE TYPE. MUST BE $01
$B7E9 (-18455)      DOS 3.2/3.3 (48K) - SLOT NUMBER * 16
$B7EA (-18454)      DOS 3.2/3.3 (48K) - DRIVE NUMBER ($01 OR $02)
$B7EB (-18453)      DOS 3.2/3.3 (48K) - VOLUME NUMBER (NOTE: 0 MATCHES ANY VOLUME.)
$B7EC (-18452)      DOS 3.2/3.3 (48K) - TRACK NUMBER ($00~$22)
$B7ED (-18451)      DOS 3.2/3.3 (48K) - SECTOR NUMBER (DOS 3.2 $0~$C; DOS 3.3 $0~$F)
$B7EE~$B7EF (-18450~-18449)  DOS 3.2/3.3 - POINTER TO DCT (DEVICE CHARACTERISTICS TABLE)
$B7F0~$BFF1 (-18448~-16399)  DOS 3.2/3.3 - POINTER TO USER DATA BUFFER FOR READ/WRITE
$B7F2 (-18446)      DOS 3.2/3.3 - UNUSED
$B7F3 (-18445)      DOS 3.2/3.3 - BYTE COUNTER FOR PARTIAL SECTOR; USE $00 FOR FULL 256 BYTES
$B7F4 (-18444)      DOS 3.2/3.3 - COMMAND CODE: 0=SEEK; 1=READ; 2=WRITE; 4=FORMAT.
$B7F5 (-18443)      DOS 3.2/3.3 - ERROR CODE (VALID IF CARRY SET): $10=WRITE PROTECT; $20=VOLUME
                                MISMATCH; $40=DRIVE ERROR; $08=INIT ERROR.
$B7F6 (-18442)      DOS 3.2/3.3 - VOLUME NUMBER FOUND
$B7F7 (-18441)      DOS 3.2/3.3 - SLOT NUMBER FOUND
$B7F8 (-18440)      DOS 3.2/3.3 - DRIVE NUMBER FOUND
$B7F9~$B7FA        DOS 3.3 (48K) UNUSED
$B7FB~$B7FE (-18437~-18434)  DOS 3.2/3.3 (48K) - DEVICE CHARACTERISTICS TABLE (DCT) ASSOCIATED WITH SYSTEM
                                IOB. NOTE: IOB CONTAINS DETAILED DEVICE CHARACTERISTICS TABLE AS DOCUMENTED FOR
                                RWTS IN WOZPACK
$B7FB (-18437)      DOS 3.2/3.3 (48K) - DEVICE TYPE (SHOULD BE $00)
$B7FC (-18436)      DOS 3.3 (48K) - PHASES PER TRACK (SHOULD BE $01)
$B7FD~$B7FE (-18435~-18434)  DOS 3.3 (48K) - MOTOR ON TIME COUNT (SHOULD BE $EF & $D8)
$B7FF (-18433)      DOS 3.3 (48K) - UNUSED.
$B800~$B869 (-18432~-18327) [PRENIBL~PRENIB16] \SB\DOS 3.1~3.2~3.3 RWTS (READ-WRITE TRACK-SECTOR) PRENIBL MODULE.
                                CONVERTS A PAGE OF 256 OF REAL BYTES TO A SECTOR OF 410 ($19A) RIGHT
                                JUSTIFIED 5 BIT NIBBLES (EXCEPT DOS 3.3 CONVERTS TO 342 6 BIT
                                NIBBLES OF THE FORM 00XXXXXX). POINTER TO PAGE TO CONVERT AT
                                $003E~$003F; DATA STORED AT PRIMARY XXX) SECONDARY BUFFERS; ON EXIT
                                X-REG XXX) Y-REG CONTAIN $FF & CARRY SET.
$B82A~$B8B7 (-1839C~-18249) [WRITE16 (DOS 3.3)] \SB\DOS 3.3 'WRITE'. WRITES PRENIBBILIZED DATA FROM PRIMARY & SECONDARY
                                BUFFERS TO DISK; CALLS WRITE-A-BYTE S/R; WRITES 5 BYTES AUTSYNC~
                                STARTING DATA MARKS ($D5~$AA~$AD)~ 342 BYTES DATA~ ONE BYTE
                                CHECKSUM~ AND CLOSING DATA MARKS ($DE~$AA~$EB). USES WRITE
                                TRANSLATE TABLE ($BA29). ON ENTRY X-REG CONTAINS SLOT#*16. ON EXIT
                                X-REG UNCHANGED; Y-REG $00; CARRY CLEAR. USES $0026~ $0027~ $678
$B86A~$B8FC (-18326~-18180) [WRITE] \SB\DOS 3.1~3.2~3.2.1 (SEE $B82A FOR DOS 3.3 'WRITE') RWTS (READ-WRITE
                                TRACK-SECTOR) WRITE MODULE. WRITES A BUFFER OF 410 ($19A) 5-BIT RIGHT-JUSTIFIED
                                NIBBLES ONTO THE DISK SURFACE AS A SECTOR CONVERTING THEM TO A 8-BIT 'DISK
                                BYTE' FORMAT FIRST
$B8B8~$B8C1 (-18248~-18239)  DOS 3.3 WRITE-A-BYTE S/R. THIS IS TIMING-CRITICAL CODE USED TO WRITE BYTES AT 32
                                CYCLE INTERVALS. EXITS TO CALLER

```


HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$B8C2~\$B8DB (-18238~-18213) [POSTNIB16] \SB\DOS 3.3 POSTNIBBLE ROUTINE. CONVERTS 342 6-BIT NIBBLES OF FORM 00XXXXXX TO 256 8-BIT BYTES. NIBBLES STORED AT PRIMARY (\$B800-\$B8FF) AND SECONDARY (\$BC00-\$BC55) BUFFERS. POINTER TO DATA PARSE STORED AT 'BUFPTR' (\$003E~\$003F). ON ENTRY X-REG= SLOT*16; CSW (\$0036~\$0037) POINTS TO USER DATA; \$0026= BYTE COUNT IN SECONDARY BUFFER. ON EXIT CARRY SET 'BUFPTR' Y-REG CONTAINS BYTE COUNT IN SECONDARY BUFFER

\$B8C2 (-18238) [POSTNIBL (DOS 3.3)] \SB\DOS 3.3 'POSTNIBL'

\$B8DC~\$B943 (-18212~-18109) [READ16] \SB\DOS 3.3 'READ' IN RWTS (READ-WRITE TRACK-SECTOR). READS A SECTOR OFF THE DISK INTO SECONDARY BUFFER (\$BC00-\$BC55) HIGH TO LOW THEN INTO PRIMARY (\$B800-\$B8FF) LOW TO HIGH EN ROUTE TO OVERALL PROCESS OF FORMING \$153 RIGHT-JUSTIFIED 6-BIT NIBBLES

\$B8FD~\$B964 (-18179~-18C76) [READ] \SB\DOS 3.1~3.2~3.2.1 (SEE \$B8DC FOR DOS 3.3 'READ') RWTS (READ-WRITE TRACK-SECTOR) READ MODULE. READS A SECTOR OFF THE DISK FORMING 410 (\$19A) 5-BIT RIGHT-JUSTIFIED NIBBLES

\$B944~\$B99F (-18108~-18017) [READADR-RDADR16 (DOS 3.3)] \SB\DOS 3.3 READADR. FUNCTION SAME AS READADR-RDADR16 (DOS 3.2)

\$B944 (-18108) [RDADR16] DOS 3.3 SYNONYM FOR READADR

\$B965~\$B9C0 (-18075~-17984) [READADR (DOS 3.2)] \SB\DOS 3.1~3.2~3.2.1 (SEE \$B944 FOR DOS 3.3 'READADR (DOS 3.2)') RWTS (READ-WRITE TRACK SECTOR) READ ADDRESS MODULE. READS ADDRESSES ON THE SECTORS OF CURRENT TRACK UNTIL IT FINDS A SECTOR. THEN IT RETURNS PUTTING CHECKSUM INTO \$002C; SECTOR INTO \$002D; TRACK INTO \$002E; AND VOLUME INTO \$002F. CARRY IS SET ON ERROR

\$B9A0~\$B9FC (-18016~-17924) [SEEKABS (DOS 3.3)] \SB\DOS 3.3 - MOVES DISK ARM TO DESIRED TRACK. CALLS ARM MOVE DELAY SUBROUTINE (\$B9FD). ON ENTRY \$0478 CONTAINS CURRENT TRACK; X-REG CONTAINS SLOT*16; A-REG DESIRED TRACK. ON EXIT X-REG UNCHANGED; A-REG Y-REG CLOBBERED; \$0478 & \$002A: FINAL TRACK; \$27 PRIOR TRACK (IF SEEK NEEDED). USES \$0026; \$0027; \$002A; \$002B. EXITS TO CALLER

\$B9C1~\$BA1D [POSTNIBL (DOS 3.2)] \SB\ DOS 3.1~3.2~3.2.1 (SEE \$B8C2 FOR DOS 3.3) RWTS (READ-WRITE TRACK SECTOR) POSTNIBL (DOS 3.2) MODULE. CONVERTS A BUFFER OF 410 (\$19A) LEFT-JUSTIFIED 5-BIT NIBBLES TO 256 (\$100) REAL BYTES. \$003E~\$003F POINTS TO BUFFER TO PUT THEM INTO

\$B9A0 (-18016) [SEEKABS (DOS 3.2)] \SB\DOS 3.2 'SEEKABS'

\$B9EC (-17940) DOS 3.2 CODE TO IMPLEMENT INITIALIZATION WITH VOLUME NUMBER TO BE INITIALIZED IN \$002F

\$B9FD~\$BA1D (-17923~-17904) \SB\ DOS 3.3 ARM MOVE DELAY SUBROUTINE. DELAYS SPECIFIED NUMBER OF 100 MICROSEC INTERVALS. ON ENTRY A-REG CONTAINS NUMBER OF INTERVALS; 'MONTIME' (\$0046) SHOULD CONTAIN MOTOR-ON TIME (\$EF~\$D8) FROM DCT; \$0478 CONTAIN CURRENT TRACK; ON EXIT A-REG CURRENT X-REG CONTAIN \$00; Y-REG UNCHANGED CARRY SET. EXIT TO CALLER

\$BA00 (-17920) [MSWAIT] \SB\ DOS 3.3 RWTS OPERATION TIMER ROUTINE

\$BA11 (-17903) \SB\ DOS 3.3 RWTS OPERATION TIMER TABLE1

\$BA1E~\$BA8F (-17890~-17777) [SEEKABS] \SB\DOS 3.1~3.2~3.2.1 (SEE \$B9A0 FOR DOS 3.3) RWTS (READ-WRITE TRACK SECTOR) SEEKABS MODULE. MOVES HEAD TO TRACK SPECIFIED BY A-REG. \$0478 IS CURRENT. RWTS DOES PHASE OFF FOR ALL FOUR BEFORE CALL

\$BA29 (-17879) DOS 3.3 (48K) ROUTINE TO ENCODE NIBBLES(6 DATA BITS PER NIBBLE INSTEAD OF 5 AS IN DOS 3.1~3.2)

\$BA11~\$BA28 \SB\ DOS 3.3 ARM MOVE DELAY TABLE. CONTAINS VALUES OF 100 MICROSEC INTERVALS USED DURING PHASE-ON AND PHASE-OFF OF STEPPER MOTOR

\$BA29~\$BA68 (-17879~-17816) DOS 3.3 WRITE TRANSLATE TABLE. CONTAINS 6-BIT NIBBLES USED TO CONVERT 8-BIT BYTES. VALUES RANGE FROM \$96 TO \$FF AND CODES WITH MORE THAN ONE PAIR OF ADJACENT ZEROS OR NO ADJACENT ONES ARE EXCLUDED

\$BA69 (-17815) DOS 3.3 - UNUSED

\$BA96~\$BAFF (-17770~-17665) DOS 3.3 READ TRANSLATE TABLE. CONTAINS 8 BIT BYTES USED TO CONVERT 6-BIT NIBBLES. VALUES RANGE FROM \$96 TO \$FF. CODES WITH MORE THAN ONE PAIR OF ADJACENT ZEROS OR WITH NO ADJACENT ONES ARE EXCLUDED.

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$BCC4~\$BCDE (-17212~-17186) \SB\ DOS 3.3 WRITE DOUBLE BYTE SUBROUTINE. THIS IS TIMING CRITICAL CODE THAT ENCODES ADDRESS INFO INTO EVEN AND ODD BITS AND WRITES IT AT 32 CYCLE INTERVALS. EXIT TO CALLER

\$BCDF~\$BCFF (-17185~-17153) DOS 3.2 UNUSED

\$BD00~\$BD18 (-17152~-17128) DOS 3.3 MAIN ENTRY TO RWTS (READ-WRITE TRACK-SECTOR). UPON ENTRY STORE Y-REG AND A-REG AT \$0048 AND \$0049 AS POINTERS TO IOB. INITIALIZE NUMBER OF RECALLS AT 1 AND SEEKS AT 4. IF SLOT # HAS NOT CHANGED BRANCH TO 'SAMESLOT' (\$BD34)

\$BD19~\$BD33 (-17127~-17101) DOS 3.3 - UPDATE SLOT NUMBER IN IOB AND WAIT FOR OLD DRIVE TO TURN OFF

\$BEAE (-16722) DOS 3.2 START OF CODE TO INITIALIZE A SINGLE TRACK

\$BFA2 (-16478) DOS 3.2 - TESTS TO SEE IF ALL \$22 TRACKS HAVE BEEN INITIALIZED YET; IF SO EXITS RWTS AT \$BFB8

\$BA7B (-17797) [(TIMER DOS 3.2.1)] \SB\ DOS 3.2.1 RWTS OPERATION TIMER ROUTINE

\$BA7F (-17793) [(TIMER DOS 3.1~3.2)] \SB\ DOS 3.1~3.2 RWTS OPERATION TIMER ROUTINE

\$BA8C (-17780) [(TABLE1 DOS 3.2.1)] \SB\ DOS 3.2.1 RWTS OPERATION TIMER ROUTINE TABLE1

\$BA90~\$BA93 (-17776~-17765) \SB\ DOS 3.1~3.2 RWTS (READ-WRITE TRACK-SECTOR) TABLE OF PHASE-ON TIMES TO WAIT (LOCATED AT \$BA8C IN DOS 3.2.1 & AT \$BA11 IN DOS 3.3)

\$BA96~\$BAFF (-17772~-17665) DOS 3.3 NIBBLE ENCODE/DECODE TABLE

\$BA9C~\$BAA7 (-17764~-17753) \SB\ DOS 3.1~3.2 RWTS (READ-WRITE TRACK-SECTOR) TABLE OF PHASE-OFF TIMES TO WAIT (LOCATED AT \$BA98 IN DOS 3.2.1 & AT \$BA1D IN DOS 3.3)

\$BAA8~\$BAFF (-17752~-17665) \SB\ DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR) TABLE OF NIBBLES IN POSITION OF CORRESPONDING DISK BYTE OFFSET FROM \$BA00 USED FOR CONVERSION DISK BYTES->NIBBLES

\$BB00~\$BC99 (-17664~-17255) \BB\ BUFFER TO HOLD 410 5-BYTE NIBBLES CREATED FROM A PAGE OF 256 BYTES BY PRENIBL ROUTINE IN DOS 3.2 RWTS (READ-WRITE TRACK-SECTOR)

\$BB00~\$BBFF (-17664~-17409) DOS 3.3 RWTS PRIMARY BUFFER

\$BC00~\$BC55 (-17408~-17323) DOS 3.3 RWTS SECONDARY BUFFER

\$BC56~\$BCC3 (-17322~-17213) DOS 3.3 WRITE ADDRESS FIELD DURING INITIALIZATION. CALLS WRITE DOUBLE BYTE SUBROUTINE. WRITES # OF BYTES CONTAINED IN Y-REG; STARTING ADDRESS MARKS (\$D5/\$AA/\$96); ADDRESS INFO (VOL/TRACK/SECTOR/CHECKSUM); CLOSING ADDRESS MARKS (\$DE~\$AA~\$EB). ON ENTRY X-REG CONTAINS SLOT*16; Y-REG CONTAINS NUMBER OF AUTOSYNC TO WRITE; \$3E:\$AA;\$3F:\$SECTOR#;\$41:VOL#;\$44:TRACK#. ON EXIT: A-REG ?; X-REG UNCHANGED; Y-REG \$00; CARRY SET. EXIT TO CALLER

\$BC9A~\$BCB9 \PB\ CONVERSION TABLE TO CONVERT 5-BIT NIBBLES TO 8-BIT 'DISK BYTES' USED BY DOS 3.2

\$BCD0~\$BCDC RWTS (READ-WRITE TRACK-SECTOR) PACKAGE WRITE SUBROUTINE

\$BD00~\$BFFF (-17152~-16385) DOS 3.2 (48K) - 13 BYTES CONTAINING PERMUTATIONS OF 5 MOD 13 USED IN NYBBLE CONVERSION. NO SUCH TABLE IN DOS 3.3

\$BD00 (-17152) \SE\ DOS 3.2 (48K) - MAINLINE READ-WRITE TRACK-SECTOR (RWTS) CODE

\$BD34~\$BD53 (-17100~-17069) [SAMESLOT] \SB\ ENTER READ MODE AND READ WITH DELAYS TO SEE IF DISK IS SPINNING. SAVE RESULTS OF TEST AND TURN ON MOTOR ANYHOW

\$BD44 (-17084) ADDRESS OF DEVICE CHARACTERISTICS TABLE (DCT) AND BUFFER ARE MOVED FROM THE IOB INTO LOCNs \$003C~\$003D & \$003E~\$003F

\$BD54~\$BD73 (-17068~-17037) \SB\ DOS 3.3 - MOVE POINTER IN IOB TO ZERO PAGE. (SET DEVCTBL (\$003C~\$003D) AND BUFPTR (\$003E~\$003F) AND \$0047 WITH \$00D8 FROM DCT). CHECK IF DRIVE # HAS CHANGED. IF NOT BRANCH TO \$BD74

\$BD74~\$BD8F (-17036~-17009) \SB\ DOS 3.3 - SELECT APPROPRIATE DRIVE AND SAVE DRIVE BEING USED AS HIGH BIT OF 'DRIVEN0' (\$0035). 1=DRIVE 1; 0=DRIVE 2. IF DRIVE WAS ON BRANCH TO \$BD90. IF NOT CALL 'MSWAIT' AT \$BA00

\$BD90~\$BDAA (-17008~-16982) \SB\ DOS 3.3 - GET DESTINATION TRACK AND GO TO IT USING 'MYSEEK' (\$BESA)

\$BD90~\$BDAA (-17008~-16982) \SB\ DOS 3.3 - GET DESTINATION TRACK AND GO TO IT VIA 'MYSEEK' (\$BESA). CHECK TEST RESULT AGAIN AND IF DRIVE ON BRANCH TO 'TRYTRK' (\$BDAB)

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$BIDAB~\$BDB3 (-16981~-16965) [TRYTRK] \SB\DOS 3.3 - GET COMMAND CODE. IF NULL EXIT VIA 'ALLDONE' (\$BE46) TURNING OFF DRIVE & RETURNING TO CALLER. IF COMMAND CODE=4 BRANCH TO 'FORMDSK' (\$BED0); OTHERWISE MOVE LOW BIT INTO CARRY (SET=READ;CLEAR=WRITE) AND SAVE VALUE ON STATUS REG. IF WRITE OPN DATA IS PRENIBBILIZED VIA 'PRENIB16' (\$B800)

\$BIDBC~\$BDEC (-16964~-16916) [RDRIGHT] \SB\DOS 3.3 - INITIALIZE MAX RETRIES AT 48. READ ADDRESS FIELD VIA 'RDADR16' (\$B944). IF GOOD READ BRANCH TO 'RDRIGHT' (\$BDED). IF BAD TRY AGAIN DECREMENTING RETRIES. IF NONE LEFT PREPARE TO RECALIBRATE. DECREMENT RECAL COUNT. IF NO MORE THEN 'DRVERR' (\$BE04). OTHERWISE RESET RESEKES AT 4 AND RECALIBRATE ARM. TRY AGAIN

\$BDED~\$BE03 (-16915~-16893) [RDRIGHT] \SE\DOS 3.3 - VERIFY TRACK. IF CORRECT BRANCH TO 'RTTRK' (\$BE10) OTHERWISE GOTO 'SETTRK' (\$BE95) AND DECREMENT RESEK COUNT. IF ZERO RECAL OTHERWISE RESEK TRACK

\$BE04~\$BE0A (-16892~-16886) [DRVERR] \SE\DOS 3.3 - CLEAN UP STACK & STATUS REG; LOAD A-REG WITH \$40 (DRIVE ERROR) AND GOTO 'HNDLERR' (\$BE48)

\$BE0B~\$BE0C (-16885~-16884) DOS 3.3 - BRANCH TO 'ALLDONE' (\$BE46)

\$BED0~\$BFOF (-16883~-16625) [FORMDSK] DOS 3.3 - JUMP TO 'DSKFORM' (\$BEAF)

\$BE10~\$BE25 (-16880~-16859) [RTTRK] DOS 3.3 -CHECK VOL# FOUND VS VOL# WANTED. IF NO VOL SPECIFIED NO ERROR OTHERWISE IF MISMATCH LOAD A-REG WITH \$20 (VOLUME MISMATCH ERROR) AND EXIT VIA 'HNDLERR' (\$BE48)

\$BE26~\$BE45 (-16858~-16827) [CRCTVOL] DOS 3.3 - CHECK TO SEE IF SECTOR CORRECT. USE 'ILEAV' TABLE (\$BFB8) FOR SOFTWARE SECTOR INTERLEAVING. IF WRONG SECTOR TRY AGAIN AT 'TRYADR (\$BDC1). IF WRITE BRANCH TO 'WRIT' (\$BE51). OTHERWISE GOTO 'READ16' (\$B8DC). IF GOOD READ CALL 'POSTN316' (\$B8C2) AND RETURN TO CALLER WITH NO ERROR

\$BE46~\$BE47 (-16826~-16825) [ALLDONE] DOS 3.3 - SKIP OVER SET CARRY INSTRUCTION IN 'HNDLERR'

\$BE48~\$BE50 (-16824~-16816) [HNDLERR] DOS 3.3 - SET CARRY; STORE A-REG IN IOB AS RETURN CODE. TURN OFF MOTOR. RETURN TO CALLER

\$BE51~\$BE59 (-16815~-16807) [WRIT] DOS 3.3 - WRITE A SECTOR USING 'WRITE16' (\$B82A); IF GOOD WRITE EXIT VIA 'ALLDONE' (\$BE46) OTHERWISE LOAD A-REG WITH \$10 (WRITE PROTECT ERROR) AND EXIT VIA 'HNDLERR' (\$BE48)

\$BE5A~\$BE8D (-16806~-16755) [MYSEEK] DOS 3.3 - HOUSEKEEPING BEFORE 'SEEKABS'. DETERMINES NUMBER OF PHASES PER TRACK & STORES TRACK INFO IN APPROPRIATE SLOT-DEPENDENT LOCN

\$BE8E~\$BE94 (-16754~-16748) [XT0Y] DOS 3.3 - X-REG/16 =>Y-REG. USED TO PUT SLOT INTO Y-REG

\$BE95~\$BEAE (-16747~-16722) [SETTRK] DOS 3.3 - SET TRACK #

\$BEAF~\$BFOC (-16721~-16628) [DSKFORM] \SB\DOS 3.3 - INIT COMMAND HANDLER

\$BFOD~\$BF61 (-16627~-16543) \SB\ DOS 3.3 - TRACK WRITE ROUTINE

\$BF62~\$BF87 (-16542~-16505) \SB\ DOS 3.3 - VERIFY TRACK ROUTINE

\$BF88~\$BFA7 (-16504~-16473) \SB\ DOS 3.3 - SECTOR MAP ROUTINE - MARKS SECTOR INITIALIZATION MAP AS EACH SECTOR VERIFIED

\$BFA8~\$BFB7 DOS 3.3 - SECTOR INITIALIZATION MAP. CONTAINS \$30 PRIOR TO INITIALIZATION OF TRACK. VALUE CHANGED TO \$FF AS EACH SECTOR COMPLETED

\$BFB8~\$BFC7 (-16456~-16441) [ILEAV] DOS 3.3 - SECTOR TRANSLATE TABLE. SECTOR INTERLEAVING DONE WITH SOFTWARE

\$BFC8~\$BFFF (-16440~-16385) DOS 3.3 PATCH AREA

\$BFC8~\$BFD8 (-16440~-16424) DOS 3.3 PATCH TO ZERO LANGUAGE CARD DURING BOOT

\$BFD9~\$BFD9 (-16423~-16421) DOS 3.3 - UNUSED

\$BFD0~\$BFE5 (-16420~-16411) DOS 3.3 PATCH CALLED FROM \$A032 TO SET ADDITIONAL DEFAULTS

\$BFE6~\$BFEC (-16410~-16404) DOS 3.3 PATCH CALLED FROM ERROR HANDLER AT \$A6D5. CALLS \$A75B TO RESET STATE 0 AND SET WARMSTART FLAG. MARK RUN NOT INTERRUPTED. RETURN TO CALLER

\$BFED~\$BFFF (-16403~-16385) DOS 3.3 PATCH CALLED FROM DISK FULL ERROR EXIT (\$B377). CALLS \$AE7E TO SAVE FILE MANAGER WORK AREA; RESTORES STACK; CLOSSES ALL OPEN FILES; SAVES STACK AGAIN; EXITS THRU \$B385 ("DISK FULL ERROR")

\$BFFF (-16385) \H\ HIGHEST RAM MEMORY ADDRESS (FULL 48K APPLE) - NOTE: WITH LANGUAGE CARD SPECIAL RAM EXISTS HIGHER

\$B)AB - \$BFFF

Prof. Luebbert's "What's Where in the Apple"

NUMERIC ATLAS

HEX LOCN (DEC LOCN) [NAME] \USE=TYPE\ - DESCRIPTION

```

$BFFF (-16385)          DEFAULT INTEGER BASIC HIMEM (W/O DOS 3.2~ 48K MACHINE)
$C000~$CFFF (-16384~-12289) \HBI\ ENTRY ADDRESSES DEDICATED TO I/O FUNCTIONS
$C000~$C00F (-16384~-16369) [M] \H1\ EQUIVALENT ADDRESSES - ALL FOR KEYBOARD INPUT BYTE. WHEN KEY PRESSED ASCII VALUE
GOES THERE AND HIGH BIT SET
$C000~[KBD ~ IOADR] \H1\ MONITOR I/O - PEEK TO READ KEYBOARD. IF VAL>127 KEY HAS BEEN PRESSED SINCE LAST
STROBED AT $C010.
$C010~$C01F (-16368~-16353) \H1\ EQUIVALENT ADDRESSES - ALL CLEAR KEYBOARD STROBE I.E. SET FLAG (HIGH) BIT OF
$C000 TO 0 (VAL<128) AND REACTIVATE KEYBOARD
$C010 (-16368) [KBDSTB] \H1\ KEYBOARD STROBE- REACTIVATES KEYBOARD SO THAT VALUE OF PRESSED KEY GOES TO $C000.
SETS HIGH BIT TO ZERO..-4
$C020~$C02F (-16352~-16337) [TAPEOUT] \H1\CASSETTE OUTPUT TOGGLE FLIP FLOP. READ ONLY DO NOT WRITE TO THESE ADDRESSES
WHICH ARE DECODED AS SAME SINGLE BIT LOCN
$C020 (-16352) [TAPEOUT] \H1\ PEEK TO TOGGLE CASSETTE OUTPUT (CREATE A 'CLICK' ON RECORDING)
$C030~$C03F (-16336~-16321) [SPKR] \H1\ \SPEAKER TOGGLE FLIP FLOP. READ ONLY - DO NOT WRITE TO THES ADDRESSES WHICH ARE
DECODED AS SAME SINGLE BIT LOCN
$C030 (-16336) [SPKR] \H1\ PEEK TO TOGGLE SPEAKER (PRODUCES A 'CLICK')
$C040~$C04F (-16320~-16305) \H1\ UTILITY STROBE. IF READ PIN 5 ON GAME I/O CONNECTOR DROPS FROM 5 V TO 0 V FOR 1
MICROSECOND
$C040~$C04F (-16320~-16305) \H1\ ANY ONE OF THESE 16 LOCATIONS HAS SAME EFFECT IF POKED. IT OUTPUTS STROBE TO GAME
I/O CONNECTOR
$C050 (-16304) [TXTCLR] \H1\ POKE TO 0 TO SET FROM TEXT TO GRAPHICS MODE W/O CLEARING SCREEN
$C051 (-16303) [TXTSET] \H1\ POKE TO 0 TO SET FROM GRAPHICS TO TEXT MODE W/O RESETTNG SCROLLING WINDOW
$C052 (-16302) [MIXCLR] \H1\ POKE TO 0 TO RESET FROM MIXED GRAPHICS (W/4 LINES TEXT) TO FULL-SCREEN GRAPHICS
$C053 (-16301) [MIXSET] \H1\ POKE=0 TO SET TEXT/GRAPHICS MIX (BOTTOM 4 LINES TEXT)
$C054 (-16300) [LOWSCR] \H1\ POKE TO 0 TO DISPLAY PAGE 1 (DOES NOT CLEAR SCREEN)
$C055 (-16299) [HISCR] \H1\ POKE TO 0 TO DISPLAY PAGE 2 (DOES NOT CLEAR SCREEN)
$C056 (-16298) [LO-RES] \H1\ POKE TO 0 TO SET FROM HI-RES TO SAME PAGE # OF LO-RES OR TEXT
$C057 (-16297) [HI-RES] \H1\ POKE TO 0 TO SET TO HI-RES GRAPHICS FROM LO-RES OR TEXT (SAME PAGE)
$C058 (-16296) [SETANO] \FF\ VALUE<>0 WHEN GAME AND IS SET. POKE 0 TO CLEAR GAME I/O OUTPUT AND (3.5V AT PIN
15)
$C059 (-16295) [CLRANO] \FF\ VALUE <>0 WHEN GAME AND IS RESET (CLEARED). POKE 0 TO SET GAME I/O OUTPUT AND
(0.3V AT PIN 15)
$C05A (-16294) [SETAN1] \FF\ POKE 0 TO CLEAR GAME I/O OUTPUT AN1 (3.5V AT PIN 14)
$C05B (-16293) [CLRAN1] \FF\ POKE 0 TO SET GAME I/O OUTPUT AN1 (0.3V AT PIN 14)
$C05C (-16292) [SETAN2] \FF\ POKE 0 TO CLEAR GAME I/O OUTPUT AN2 (3.5V AT PIN 13)
$C05D (-16291) [CLRAN2] \FF\ POKE 0 TO SET GAME I/O OUTPUT AN2 (0.3V AT PIN 13)
$C05E (-16290) [SETAN3] \FF\ POKE 0 TO CLEAR GAME I/O OUTPUT AN3 (3.5V AT PIN 12)
$C05F (-16289) [CLRAN3] \FF\ POKE 0 TO SET GAME I/O OUTPUT AN3 0.3V AT PIN 12)
$C060 (-16288) [TAPEIN] MONITOR MEMORY LOCATION 'TAPEIN'
$C060/8 (-16288) [TAPEIN] \H1\ STATE OF 'CASSETTE DATA IN' APPEARS IN BIT 7
$C061 (-16287) \H1\ PEEK TO READ PDL(0) PUSH BUTTON SWITCH. IF >127 SWITCH ON
$C062 (-16286) \H1\ PEEK TO READ PDL(1) PUSH BUTTON SWITCH. IF >127 SWITCH ON
$C063 (-16285) \H1\ PEEK TO READ PDL(2) PUSH BUTTON SWITCH. IF >127 SWITCH ON
$C064 (-16284) [PADDL0] \H1\ MONITOR MEMORY LOCATION PADDL0; HARDWARE INDISTINGUISHABLE FROM $C06C; STATE OF
TIMER OUTPUT FOR PADDLE 0 APPEARS IN BIT 7 (NEGATIVE UNTIL TIMER EXPIRES)
$C065 (-16283) [PADDL1] \H1\ MONITOR MEMORY LOCATION PADDL1; HARDWARE INDISTINGUISHABLE FROM $C06D; STATE OF
TIMER OUTPUT FOR PADDLE 1 APPEARS IN BIT 7 (NEGATIVE UNTIL TIMER EXPIRES)
$C066 (-16282) [PADDL2] \H1\ MONITOR MEMORY LOCATION PADDL2; HARDWARE INDISTINGUISHABLE FROM $C06E; STATE OF
TIMER OUTPUT FOR PADDLE 2 APPEARS IN BIT 7 (NEGATIVE UNTIL TIMER EXPIRES)
$C067 (-16281) [PADDL3] \H1\ MONITOR MEMORY LOCATION PADDL3; HARDWARE INDISTINGUISHABLE FROM $C06F; STATE OF
TIMER OUTPUT FOR PADDLE 3 APPEARS IN BIT 7 (NEGATIVE UNTIL TIMER EXPIRES)

```


HIEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$C06C (-16276) [PADDL0] \H1\ MONITOR MEMORY LOCATION PADDL0; HARDWARE INDISTINGUISHABLE FROM \$C064; STATE OF
 TIMER OUTPUT FOR PADDLE 0 APPEARS IN BIT 7 (NEGATIVE UNTIL TIMER EXPIRES)
 \$C06D (-16275) [PADDL1] \H1\ MONITOR MEMORY LOCATION PADDL1; HARDWARE INDISTINGUISHABLE FROM \$C065; STATE OF
 TIMER OUTPUT FOR PADDLE 1 APPEARS IN BIT 7 (NEGATIVE UNTIL TIMER EXPIRES)
 \$C06E (-16274) [PADDL2] \H1\ MONITOR MEMORY LOCATION PADDL2; HARDWARE INDISTINGUISHABLE FROM \$C066; STATE OF
 TIMER OUTPUT FOR PADDLE 2 APPEARS IN BIT 7 (NEGATIVE UNTIL TIMER EXPIRES)
 \$C06F (-16273) [PADDL3] \H1\ MONITOR MEMORY LOCATION PADDL3; HARDWARE INDISTINGUISHABLE FROM \$C067; STATE OF
 TIMER OUTPUT FOR PADDLE 3 APPEARS IN BIT 7 (NEGATIVE UNTIL TIMER EXPIRES)
 \$C070-\$C07F (-16272-16257) [PTRIG] \H1\ GAME CONTROLLER STROBE. WHEN READ CAUSES FALG INPUTS OF GAME CONTROLLERS TO GO
 OFF & TIMING LOOPS RESTARTED
 \$C070-\$C07F (-16272-16257) [PTRIG] \H1\ ALL 16 ADDRESSES DECODE TO SINGLE SWITCH WHICH TRIGGERS PADDLE TIMERS DURING
 PHI-2
 \$C080-\$C08F (-16256-16241) [(DEV SELECT 0)] 16 MEMORY LOCNS ALLOCATED TO USE OF PERIPHERAL DEVICE IN SLOT #0. WHEN
 ADDRESSED PIN 41 TELLS DEVICE IT IS SELECTED. SINCE SLOT #0 IS COMMON AREA
 USED IN COMMON FOR PARAMETERS OF INTEREST TO ALL SLOTS
 \$C080 (-16256) \H1\ SELECT 2ND BANK OF \$D000-\$DFFF RAM IN LANGUAGE CARD. WRITE PROTECT RAM (\$C084
 DECODES TO SAME ADDRESS & EFFECT)
 \$C080-\$C081 (-16256-16255) [PHSOFF-PHSON] \P4\ DOS 3.2 READ\WRITE TRACK\SECTOR PACKAGE PARAMETER STATEMACHINE CONTROLS
 TABLE: LO LO=READ;HI LO=SENSE WRITE PROTECT;LO HI=WRITE;HI HI=WRITE LOAD
 \$C081 (-16255) \H1\ READ-DESELECT 2ND BANK OF \$D000-\$DFFF RAM IN LANG. CARD (ENABLE ROM). TWO
 SUCCESSIVE READS WRITE-ENABLES RAM
 \$C081 (-16255) [PHASON] \P1\ DOS 3.2 READ\WRITE TRACK\SECTOR (RWTS) PACKAGE PARAMETER 'PHASON'
 \$C082 (-16254) \H1\ READ-DESELECT 2ND BANK OF \$D000-\$DFFF RAM IN LANGUAGE CARD (ENABLE ROM). WRITE
 PROTECT RAM
 \$C082 (-16254) [PHSOFF] \P1\ DOS 3.2 READ\WRITE TRACK\SECTOR (RWTS) PACKAGE PARAMETER 'PHSOFF'
 \$C083 (-16253) \H1\ SELECT 2ND BANK OF \$D000-\$DFFF RAM IN LANG. CARD. TWO SUCCESSIVE READS TO THIS
 ADDR WRITE-ENABLES RAM
 \$C084 (-16252) \H1\ SELECT 2ND BANK OF \$D000-\$DFFF RAM IN LANGUAGE CARD. WRITE PROTECT RAM (\$C080
 DECODES TO SAME ADDRESS & EFFECT)
 \$C085 (-16251) \H1\ READ-DESELECT 2ND BANK OF \$D000-\$DFFF RAM IN LANG. CARD (ENABLE ROM). TWO
 SUCCESSIVE READS WRITE-ENABLES RAM
 \$C086 (-16250) \H1\ READ-DESELECT 2ND BANK OF \$D000-\$DFFF RAM IN LANGUAGE CARD (ENABLE ROM). WRITE
 PROTECT RAM
 \$C087 (-16249) \H1\ SELECT 2ND BANK OF \$D000-\$DFFF RAM IN LANG. CARD. TWO SUCCESSIVE READS TO THIS
 ADDR WRITE-ENABLES RAM
 \$C088 (-16248) \H1\ SELECT 1ST BANK OF \$D000-\$DFFF RAM IN LANGUAGE CARD. WRITE PROTECT RAM
 \$C088 (-16248) [MOTOROFF] \P1\ DOS 3.2 READ\WRITE TRACK\SECTOR (RWTS) PACKAGE PARAMETER 'MOTOROFF'
 \$C089 (-16247) \H1\ READ-DESELECT 1ST BANK OF \$D000-\$DFFF RAM IN LANG. CARD (ENABLE ROM). TWO
 SUCCESSIVE READS WRITE-ENABLES RAM
 \$C089 (-16247) [MOTORON] \P1\ DOS 3.2 READ\WRITE TRACK\SECTOR (RWTS) PACKAGE PARAMETER 'MOTORON'
 \$C08A (-16246) \H1\ READ-DESELECT 1ST BANK OF \$D000-\$DFFF RAM IN LANGUAGE CARD (ENABLE ROM). WRITE
 PROTECT RAM
 \$C08A (-16246) [DRVOEN] \P1\ DOS 3.2 READ\WRITE TRACK\SECTOR (RWTS) PACKAGE PARAMETER 'DRVOEN' (DRIVE 0 ENABLE)
 \$C08B (-16245) \H1\ SELECT 1ST BANK OF \$D000-\$DFFF RAM IN LANGUAGE CARD. TWO SUCCESSIVE READS TO THIS
 ADDR WRITE-ENABLES RAM
 \$C08B (-16245) [DRV1EN] \P1\ DOS 3.2 READ\WRITE TRACK\SECTOR (RWTS) PACKAGE PARAMETER 'DRV1EN' (DRIVE 1 ENABLE)
 \$C08C-\$C08D (-16244-16243) [Q6L\Q6H] \P2\ DOS 3.2 READ\WRITE TRACK\SECTOR PACKAGE PARAMETER 'Q6L\Q6H' (Q6 LOW CAUSES
 DOS 3.2 TO READ A BYTE)
 \$C08C (-16244) \H1\ SELECT 1ST BANK OF \$D000-\$DFFF RAM IN LANGUAGE CARD. WRITE PROTECT RAM
 \$C08D (-16243) \H1\ READ-DESELECT 1ST BANK OF \$D000-\$DFFF RAM IN LANG. CARD (ENABLE ROM). TWO
 SUCCESSIVE READS WRITE-ENABLES RAM

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$C08E~$C08F (-16242~-16241) [Q7L\Q7H] \P2\DOS 3.2 READ~WRITE TRACK\SECTOR PACKAGE PARAMETER 'Q7L~Q7H' (Q7 LOW SETS DOS
3.2 FOR READ MODE)
$C08E (-16242) \H1\ READ~DESELECT 1ST BANK OF $D000~$DFFF RAM IN LANGUAGE CARD (ENABLE ROM). WRITE
PROTECT RAM
$C08F (-16241) \H1\ SELECT 1ST BANK OF $D000~$DFFF RAM IN LANGUAGE CARD. TWO SUCCESSIVE READS TO THIS
ADD WRITE~ENABLES RAM
$C090~$C09F (-16240~-16225) [(DEV SELECT 1)] 16 MEMORY LOCATIONS ALLOCATED TO USE OF PERIPHERAL DEVICE IN SLOT #1. WHEN
ADDRESSED PIN 41 TELLS DEVICE IT IS SELECTED
$C0A0~$C0AF (-16224~-16209) [(DEV SELECT 2)] 16 MEMORY LOCATIONS ALLOCATED TO USE OF PERIPHERAL DEVICE IN SLOT #2. WHEN
ADDRESS PIN 41 TELLS DEVICE IT IS SELECTED
$C0B0~$C0BF (-16208~-16193) [(DEV SELECT 3)] 16 MEMORY LOCATIONS ALLOCATED TO USE OF PERIPHERAL DEVICE IN SLOT #3. WHEN
ADDRESSED PIN 41 TELLS DEVICE IT IS SELECTED
$C0C0~$C0CF (-16192~-16177) [(DEV SELECT 4)] 16 MEMORY LOCATIONS ALLOCATED TO USE OF PERIPHERAL DEVICE IN SLOT #4. WHEN
ADDRESSED PIN 41 TELLS DEVICE IT IS SELECTED
$C0D0~$C0DF (-16176~-16161) [(DEV SELECT 5)] 16 MEMORY LOCATIONS ALLOCATED TO USE OF PERIPHERAL DEVICE IN SLOT #5. WHEN
ADDRESSED PIN 41 TELLS DEVICE IT IS SELECTED
$C0E0~$C0EF (-16160~-16145) [(DEV SELECT 6)] 16 MEMORY LOCATIONS ALLOCATED TO USE OF PERIPHERAL DEVICE IN SLOT #6. WHEN
ADDRESSED PIN 41 TELLS DEVICE IT IS SELECTED
$C0E0~C0E7 EXAMPLE: DISK CONTROLLER IN SLOT 6 - ADDRESSES USED TO PULSE THE HEAD STEPPING
MOTOR. (SEE PGS 145-146 IN DOS MANUAL FOR INFO ABOUT 4 CONTROL LINES TO STEPPING
MOTOR) THESE ADDRESSES APPEAR IN 4 PAIRS WITH ODD ADDRESSES APPLYING VOLTAGE TO A
LINE AND EVEN TURNING IT OFF AGAIN. IF REFERENCED IN DESCENDING ORDER HEAD STEPS
TO A LOWER TRACK AND VICE-VERSA
$C0E8 (-16152) EXAMPLE: DISK CONTROLLER IN SLOT 6 - ENTRY ADDRESS TO POWER DOWN DISK
$C0E9 (-16151) EXAMPLE: DISK. NOTE: BASIC PROGRAMS CAN POKE TO THIS ADDRESS TO START THE MOTOR
BEFORE ISSUING A DOS COMMAND AND GAIN A SLIGHT DECREASE IN ACCESS TIME CONTROLLER
IN SLOT 6 - ENTRY ADDRESS TO POWER UP DISK. NOTE: BASIC PROGRAMS CAN POKE TO THIS
ADDRESS TO START THE MOTOR BEFORE ISSUING A DOS COMMAND AND GAIN A SLIGHT
DECREASE IN ACCESS TIME
$C0EA (-16150) EXAMPLE: DISK CONTROLLER IN SLOT 6 - SELECT DISK DRIVE #1
$C0EB (-16149) EXAMPLE: DISK CONTROLLER IN SLOT 6 - SELECT DISK DRIVE #2
$C0EC~$C0EF (-16148~-16145) EXAMPLE: DISK CONTROLLER IN SLOT 6 - 4 BYTES TO DETERMINE WHETHER DISK CONTROLLER
IS TO READ~ WRITE OR RETURN THE STATUS OF THE WRITE PROTECT MICROSWITCH. ALSO
USED FOR PASSING READ~WRITE DATA IN GROUPS OF 4-BIT NIBBLES
$C0F0~$C0FF (-16144~-16129) [(DEV SELECT 7)] 16 MEMORY LOCATIONS ALLOCATED TO USE OF PERIPHERAL DEVICE IN SLOT #7. WHEN
ADDRESSED PIN 41 TELLS DEVICE IT IS SELECTED
$CS00~$CSFF 256 BYTE PAGE OF MEMORY (USUALLY ROM) ALLOCATED TO PERIPHERAL DEVICE IN SLOT #S.
PIN 1 DROPS WHEN ADDRESS SELECTED
$CS00\SE\ EXAMPLE: CALL -16384+256*S TO TRANSMIT ASCII CHAR IN ACCUMULATOR OUT VIA APPLE
SERIAL INTERFACE IN SLOT S
$C100~$C1FF (-16128~-15873) 256 BYTE PAGE OF MEMORY (USUALLY ROM) ALLOCATED TO PERIPHERAL DEVICE #1. PIN 1
DROPS WHEN ADDRESS SELECTED
$C100 (-16128) \SE\ STANDARD CHARACTER I/O SUBROUTINE ENTRY POINT FOR SLOT #1
$C100 (-16128) \SE\ EXAMPLE: JSR $C100 OR CALL -16128 IS EQUIVALENT TO PR#1 FOR INITIALIZING APPLE
SERIAL INTERFACE IN SLOT #1
$C200~$C2FF (-15872~-15617) 256 BYTE PAGE OF MEMORY (USUALLY ROM) ALLOCATED TO PERIPHERAL DEVICE #2. PIN 1
DROPS WHEN ADDRESS SELECTED
$C200 (-15872) \SE\ STANDARD CHARACTER I/O SUBROUTINE ENTRY POINT FOR SLOT #2
$C300~$C3FF (-15616~-15361) 256 BYTE PAGE OF MEMORY (USUALLY ROM) ALLOCATED TO PERIPHERAL DEVICE #3. PIN 1
DROPS WHEN ADDRESS SELECTED
$C300 (-15616) \SE\ STANDARD CHARACTER I/O SUBROUTINE ENTRY POINT FOR SLOT #3

```

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$C400~\$C4FF (-15360~-15105)	256 BYTE PAGE OF MEMORY (USUALLY ROM) ALLOCATED TO PERIPHERAL DEVICE #4. PIN 1 DROPS WHEN ADDRESS SELECTED
\$C400 (-15360) \SE\	STANDARD CHARACTER I/O SUBROUTINE ENTRY POINT FOR SLOT #4
\$C500~\$C5FF (-15104~-14849)	256 BYTE PAGE OF MEMORY (USUALLY ROM) ALLOCATED TO PERIPHERAL DEVICE #5. PIN 1 DROPS WHEN ADDRESS SELECTED
\$C500 (-15104) \SE\	STANDARD CHARACTER I/O SUBROUTINE ENTRY POINT FOR SLOT #5
\$C600~\$C6FF (-14848~-14593)	256 BYTE PAGE OF MEMORY (USUALLY ROM) ALLOCATED TO PERIPHERAL DEVICE #6. PIN 1 DROPS WHEN ADDRESS SELECTED
\$C600~\$C6FF (-14848~-14593)	256 BYTE PAGE OF MEMORY USED BY DOS 3.2/3.3 IF DISK CONTROLLING IN STANDARD SLOT #6 (MEMORY PHYSICALLY ON CONTROLLER BOARD). PART OF THIS INFO IS TRANSFERED TO PAGE 3 (\$300) ON BOOTING
\$C600~\$C65B (-14848~-14757)	DOS 3.2/3.3 - THIS CODE FROM DISK II CONTROLLER ROM IS FIRST CODE EXECUTED WHEN A DISK IS TO BE BOOTED. DYNAMICALLY BUILDS A TRANSLATE TABLE FOR CONVERTING DISK CODES TO 6 BIT HEX AT \$0356~\$03FF AND DOES INITIAL HOUSEKEEPING AND SETS UP TO READ SECTOR ZERO TRACK ZERO TO \$0800 THEN FALLS THRU TO GENERAL SECTOR READ SR AT \$C65C
\$C600 (-14848) \SE\	STANDARD CHARACTER I/O SUBROUTINE ENTRY POINT FOR SLOT #6
\$C65C~\$C6FA (-14756~-14598)	DOS 3.3 GENERAL SECTOR READ ROUTINE. USES SECTOR # AT \$3D ON THE TRACK INDICATED BY \$0041. READS TO ADDRESS SPECIFIED AT \$0026~\$0027. IF D5/AA/AD FOUND ON SECTOR ADDRESS HEADER & SECTOR DATA WANTED GOTO \$C6A6
\$C683 (-14717)	DOS 3.3 S/R TO HANDLE SECTOR ADDRESS BLOCK. READS 3 DOUBLE BYTES AND COMBINE TO FORM VOLUME TRACK & SECTOR. STORE TRACK AT \$0040. IF DESIRED SECTOR FOUND GOTO \$C65D TO GET SECTOR DATA; OTHERWISE RETURN TO \$C65C
\$C6A6 (-14682)	DOS 3.3 SECTOR DATA HANDLING BLOCK. READS 85 BYTES OF SECONDARY DATA TO \$0300~\$0355 AND READS 256 BYTES OF PRIMARY DATA TO ADDRESS SPECIFIED BY \$0026~\$0027 & 'NIBBLIZE'. INCREMENT \$0027 & \$003D AND CHECK AGAINST \$0800 TO SEE IF ADDITIONAL SECTORS TO BE READ
\$C700~\$C7FF (-14592~-14337)	256 BYTE PAGE OF MEMORY (USUALLY ROM) ALLOCATED TO PERIPHERAL DEVICE #7. PIN 1 DROPS WHEN ADDRESS SELECTED
\$C700 (-14592) \SE\	STANDARD CHARACTER I/O SUBROUTINE ENTRY POINT FOR SLOT #7
\$C800~\$CFFF (-14336~-12289)	EXPANSION ROM MEMORY SPACE. RESERVED FOR 2K ROMS ON PERIPHERAL CARDS. ROM IS ACTIVE (ADRESSABLE) ONLY WHEN SLOT IS ACTIVE
\$C800~\$CFFF (-14336~-12289)	PIN 20 ON ALL PERIPH CONCTRS GOES LOW DURING PHIO ON READ OR WRITE TO THIS GP
\$C93D (-14019) \SE\	SERIAL INTERFACE BATCH INPUT ROUTINE. A1&A2 SPECIFY MEMORY RANGE
\$C941 (-14015) \SE\	SERIAL INTERFACE BATCH OUTPUT ROUTINE - A1 & A2 SPECIFY MEMORY RANGE
\$CFFF (-12289) [CLRROM] \H1\	SPECIAL LOCATION RECOGNIZED BY PERIPHERAL CARDS AS SIGNAL TO TURN OFF FLIP FLOPS WHICH DISABLE EXPANSION ROM
\$D000~\$DFFF (-12288~-8193) \HB\	LANGUAGE CARD CONTAINS TWO SWITCHABLE BANKS OF RAM MEMORY WHICH SHARE THIS ADDRESS SPACE
\$D000~\$D7FF (-12288~-10241) \HB\	ROM SOCKET D0
\$D000~\$D3FF (-12288~-11265) \HB\	PROGRAMMERS AID #1 (HI-RES GRAPHICS ROM)
\$D000 (-12288) [SETHRL] \SE\	HI-RES GRAPHICS INIT S/R CALL (ROM VERSION)
\$D00E (-12274) [HCLR] \SE\	HI-RES GRAPHICS CLEAR S/R CALL
\$D010 (-12272) [BKGND0]	HI-RES GRAPHICS 'BKGND0 (HCOLOR1 SET FOR BLACK BKGND)
\$D012 (-12270) [BKGND] \P1\	HI-RES GRAPHICS MEMORY LOCATION 'BKGND' (ROM)
\$D1FC (-11780) [HFIND] \SE\	HI-RES GRAPHICS FIND S/R CALL: PARAM=SHAPE~ROT~SCALE
\$D2F9 (-11527) [BPOSN] \SE\	HI-RES GRAPHICS POSN S/R CALL PARAM= X0~Y0~COLR
\$D30E (-11506) [BPLOT] \SE\	HI-RES GRAPHICS PLOT S/R CALL PARAM= X0~Y0~COLR
\$D314 (-11500) [BLIN1] \SE\	HI-RES GRAPHICS LINE S/R CALL PARAM= X0~Y0~COLR
\$D331 (-11471) [BGND] \SE\	HI-RES GRAPHICS BKGND S/R CALL PARAM= COLR
\$D337 (-11465) [BDRAW1] \SE\	HI-RES GRAPHICS LINE S/R CALL: PARAM=X0~Y0~COLR

\$C400 - \$D337

Prof. Luebbert's "What's Where in the Apple"

NUMERIC ATLAS

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$D33A (-11462) [BDRAW] \SE\	HI-RES GRAPHICS DRAW1 S/R CALL: PARAM= XO-YO-COLR-SHAPE-ROT-SCALE
\$D393 (-11373) [BLTU] \SE\	APPLESOFT BLOCK TRANSFER UTILITY. MAKES ROOM BY MOVING EVERYTHING FORWARD. Y-REG(MSB)&A-REG(LSB) AND HIGHDS=DEST OF HIGH ADR;LOWTR=LOWEST ADDR TO BE MOVED;HIGHTR=HIGHEST ADDR TO BE MOVED+1
\$D3E3 (-11293) [REASON] \SE\	CHECKS FOR ENOUGH ROOM IN MEMORY; CHECKS THAT ADDR Y-REG(MSB)&A-REG(LSB) LESS THAN FRETOP. MAY CAUSE GARBAGE COLLECTION. CAUSE OMERR IF NO ROOM
\$D3B9 (-11335) [SHLOAD] \SE\	HI-RES GRAPHICS SHLOAD S/R CALL
\$D410 (-11248) [(OUT OF MEM PRT)]	APPLESOFT - PRINT "OUT OF MEMORY" THEN HALT AT APPLESOFT (]) LEVEL
\$D412 (-11246) [ERROR] \SE\	APPLESOFT ERROR PROCESSING - CHECKS ERRFLG AND JUMPS TO HNDLERR IF ONERR IS ACTIVE OTHERWISE PRINTS ERROR MSG BASED ON CODE IN X-REG
\$D43C (-11204) \SE\	APPLESOFT LOCATION TO WHICH DOS 3.2 JUMPS TO MAKE A SOFT ENTRY TO ROM (OR LANGUAGE PACK) APPLESOFT
\$D4BC (-11076)	INTEGER BASIC PA#1 APPEND PROGRAM ENTRY
\$D4F2 (-11022) \SE\	APPLESOFT - SET (OR RESET) POINTERS & LINKAGES FOR FIRMWARE APPLESOFT (ROM) (OR LANGUAGE PACK LOCATED IN TOP 16K OF 64K MEMORY)
\$D4F2 (-11022) \SE\	APPLESOFT - TO CONVERT FROM RAM APPLESOFT STORED AT \$0800-\$3003 TO FIRMWARE APPLESOFT IN ROM OR TOP 16K RAM- CALL -11022"LIST"SAVE
\$D52C (-10964) [INLIN] \SE\	APPLESOFT - INPUT LINE OF TEXT FROM CURRENT INPUT DEVICE INTO INPUT BUFFER (BUF) & FALL INTO GDBUFS. NO PROMPT!
\$D52E (-10962) [INLIN+2] \SE\	APPLESOFT - INPUT LINE OF TEXT FROM CURRENT INPUT DEVICE INTO INPUT BUFFER (BUF) & FALL INTO GDBUFS. CHAR IN X-REG USED AS PROMPT
\$D535 (-10955)	INTEGER BASIC PA#1 TAPE VERIFY PROG ENTRY
\$D539 (-10951) [GDBUFS] \SE\	APPLESOFT - PUT ZERO AT END OF INPUT BUFFER (BUF) AND MASK OFF MOST SIGNIFICANT BIT ON ALL BYTES. ON ENTRY X-REG=END OF INPUT LINE (A- X- Y-REGS ALTERED)
\$D553 (-10925) [INCHR] \SE\	APPLESOFT - GET ONE CHAR FROM CURRENT INPUT DEVICE IN A-REG & MASK OF MSB. USES MAIN APPLE INPUT ROUTINES & SUPPORTS HANDSHAKING
\$D566 (-10906) [RUN] \SE\	APPLESOFT - RUN THE PROGRAM IN MEMORY. THIS ROUTINE DOES NOT RETURN
\$D61A (-10726) [FNDLIN] \SE\	APPLESOFT - SEARCHES PROGRAM FOR LINE WHOSE NUMBER IS IN LINNUM. ON EXIT IF CARRY SET LOWTR POINTS TO LINK FIELD OF DESIRED LINE; IF NOT LOWTR TO NEXT HIGHER LINE
\$D64B (-10677) [SCRATCH] \SE\	APPLESOFT INITIALIZATION - THE 'NEW' COMMAND. CLEARS PROGRAM VARIABLES & STACK
\$D66C (-10644) [CLEARC] \SE\	APPLESOFT INITIALIZATION - THE 'CLEAR' COMMAND. CLEARS VARIABLES & STACK
\$D683 (-10621) [STKINI] \SE\	APPLESOFT STACK INITIALIZATION - CLEARS THE STACK
\$D697 (-10601) [STXTPT] \SE\	APPLESOFT INITIALIZATION - SET TXTPTR TO BEGINNING OF PROGRAM
\$D6DD (-10531) \SE\	INTEGER BASIC PA#1 RENUMBER PROG ENTRY (WHOLE PROG)
\$D6E7 (-10521) \SE\	INTEGER BASIC PA#1 RENUMBER PROG ENTRY (PART PROG)
\$D717 (-10473) \SE\	INTEGER BASIC PA#1 MUSIC PROG ENTRY
\$D7D2 (-10286) [NEWSTT] \SE\	APPLESOFT - EXECUTE A NEW STATEMENT. ON ENTRY TXTPTR POINTS TO THE':' PRECEDING THE STMT OR ZERO AT END OF PREVIOUS LIN. USE NEWSTT TO RESTART THE PROGRAM WITH CONT. THIS ROUTINE DOES NOT RETURN
\$D800-\$DFFF (-10240-8193) \HB\	ROM SOCKET D8
\$D849 (-10167) [RESTOR] \SE\	APPLESOFT RESTORE FUNCTION - SET DATA POINTER (DATPTR) TO BEGINNING OF THE PROGRAM
\$D858 (-10152) [ISCONT] \SE\	APPLESOFT - CHECK KEYBOARD FOR CONTROL-C (\$83). EXECUTES BREAK ROUTINE IF THESE IS
\$D865 (-10139) \SE\	APPLESOFT - POINT TO WHICH DOS 3.2 JUMPS INTO ROM APPLESOFT WHEN PROCESSING ERRORS
\$D898 (-10088) [CONT] \SE\	APPLESOFT - MOVES OLDTXT & OLDLIN INTO TXTPTR & CURLIN
\$D8B0 (-10064) [SAVE] \SE\	APPLESOFT CASSETTE - SAVE THE PROGRAM IN MEMORY TO CASSETTE TAPE
\$D8C9 (-10039) [LOAD] \SE\	APPLESOFT CASSETTE - LOAD A PROGRAM FROM CASSETTE TAPE
\$D8FD (-10000) [VARTIO] \SE\	APPLESOFT CASSETTE - SET UP A1 & A2 TO SAVE 3 BYTES (\$0050-\$0052) FOR LENGTH
\$D901 (-9983) [PROGIO] \SE\	APPLESOFT CASSETTE - SET UP A1 & A2 TO SAVE PROGRAM TEXT ON CASSETTE
\$D93E (-9922) [GOTO] \SE\	APPLESOFT - USES LINGET & FNDLIN TO UPDATE TXTPTR. GOTO ASSUMES 6502 REGS HAVE BEEN SET UP BY CHRGET THAT FETCHED 1ST DIGIT
\$D979 (-9863) [(RET W/O GOSUB)]	APPLESOFT - PRINT "RETURN WITHOUT GOSUB" THEN HALT AT APPLESOFT (]) LEVEL

\$D33A - \$D979

Prof. Luebbert's "What's Where in the Apple"

NUMERIC ATLAS

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$D97C (-9860) [(UNDEF'D STMT PRT)] APPLESOFT - PRINT "UNDEF'D STATEMENT" THEN HALT AT APPLESOFT (J) LEVEL
 \$D995 (-9835) [DATA] \SE\ APPLESOFT - MOVE TXTPTR TO END OF STATEMENT; LOOKS FOR ':' OR EOL(0).
 \$D9A3 (-9821) [DATAN] \SE\ APPLESOFT - CALCULATE OFFSET IN Y-REG FROM TXTPTR TO NEXT ':' OR EOL(0)
 \$D9A6 (-9818) [REMN] \SE\ APPLESOFT - CALCULATE OFFSET IN Y-REG FROM TXTPTR TO NEXT COL(0)
 \$D998 (-9832) [ADDON] \SE\ APPLESOFT - ADD Y-REG TO TXTPTR
 \$DA0C (-9716) [LINGET] \SE\ READ 16BIT INTEGER LINE # FROM TXTPTR INTO LINNUM. SEE APPLE ORCHARD V1#1P13 FOR DETAILS
 \$DA46 (-9658) [LET] \SE\ APPLESOFT LET - USES CHRGET TO GET ADDRESS OF '=';EVALUATES FORMULA & STORES IT. ON ENTRY TXTPTR POINTS TO FIRST CHAR OF VARIABLE NAME
 \$DA65 (-9627) \SE\ APPLESOFT - PACK EXTENSION BYTE IN FAC AND CONVERT FAC (WHERE IFAC1<2^15) TO 2-BYTE INTEGER. STORE INTEGER IN FORPNT (\$0085-\$0086) (Y-REG=>1)
 \$DAFB (-9477) [CRDO] \SE\ APPLESOFT - PRINT A CARRIAGE RETURN
 \$DAB7 (-9545) [COPY] \SE\ APPLESOFT - FREE STRING POINTED TO BY Y-REG (MSB) & A-REG (LSB) & MOVE IT TO MEM LOC POINTED TO BY FORPNT
 \$DB3A (-9414) [STROUT] \SE\ APPLESOFT - PRINT STRING POINTED TO BY Y-REG (MSB) & A-REG (LSB). STRING MUST END WITH A ZERO OR QUOTE
 \$DB3D (-9411) [STRPRT] \SE\ APPLESOFT - PRINT A STRING WHOSE DESCRIPTOR IS POINTED TO BY FACMO~FACLO
 \$DB5C (-9380) [OUTDO] \SE\ APPLESOFT - PRINT THE CHARACTER IN A-REG. INVERSE~FLASH~NORMAL OPTIONS IN EFFECT
 \$DB57 (-9385) [OUTSPC] \SE\ APPLESOFT - PRINT A SPACE
 \$DB5A (-9382) [OUTQST] \SE\ APPLESOFT - PRINT A QUESTION MARK
 \$DD0B (-8949) [(NEXT W/O FOR PRT)] \SE\APPLESOFT - PRINT ERROR MESSAGE "NEXT WITHOUT FOR" THEN HALT AT APPLESOFT (J) LEVEL
 \$DD67 (-8857) [FRMNUM] \SE\ APPLESOFT - EVALUATE EXPRESSION POINTED TOBY TXTPTR (\$00B8-\$00B9) (POINTS TO 1ST CHAR OF FORMULA). PUT RESULT INTO FAC & MAKE SURE IT IS A NUMBER
 \$DD6A (-8854) [CHKNUM] \SE\ APPLESOFT - MAKE SURE FAC IS NUMERIC (SEE CHKVAL)
 \$DD6C (-8852) [CHKSTR] \SE\ APPLESOFT - MAKE SURE FAC IS STRING (SEE CHKVAL)
 \$DD6D (-8851) [CHKVAL] \SE\ APPLESOFT - IF C SET CHECK FOR STRINGS;C CLEAR CHECK FOR NUMRIC VBL. TYPE MISMATCH ERROR OCCURS IF C AND FAC DON'T AGREE
 \$DD76 (-8842) \SE\ APPLESOFT - PRINT "TYPE MISMATCH" THEN HALT AT APPLESOFT (J) LEVEL
 \$DD7B (-8837) [FRMEVL] \SE\ APPLESOFT - EVAL FORMULA AT TXTPTR USING CHRGET & LEAVE RESULT IN FAC. ON ENTRY TXTPTR POINTS TO 1ST CHAR OF FORMULA
 \$DD7B (-8837) [FRMEVL] \SE\ APPLESOFT - EVAL FORMULA AT TXTPTR USING CHRGET. IF FORMULA IS STRING LITERAL FRMEVL GOBBLES OPENING QUOTE AND EXECUTES STRLIT & ST2TXT
 \$DE10 (-8688) \SE\ APPLESOFT - PACK EXTENSION BYTE OF FAC INTO FAC & PUSH FAC ONTO STACK (6 BYTES). MODIFIES INDEX
 \$DE47 (-8633) \SE\ APPLESOFT - PULL ARG AND PUT EXCLUSIVE OR OF SIGNS OF FAC & ARG INTO (XORFPSGN) \$00AB. MUST BE EXECUTED BY JMP INSTRUCTION
 \$DE81 (-8575) [STRTXT] \SE\ APPLESOFT - SET Y-REG (MSB) & X-REG(LSB) TO TXTPTR + CARRY BIT AND FALL INTO STRLIT
 \$DE98 (-8552) [(NOTFAC)] \SE\ APPLESOFT - LET FAC = NOT(FAC); I.E. RETURNS FAC=1 IF FAC=0 OR FAC=0 IF FAC<>0
 \$DEB2 (-8526) [PARCHK] \SE\ APPLESOFT PARENTHESIS CHECK - CHECK FOR '(';EVALUATE FORMULA;CHECK FOR ')'. USES CHKOPN & FRMEVL THEN FALLS INTO CHKCLS
 \$DEB8 (-8520) [CHKCLS] \SE\ APPLESOFT CLOSE PARENTHESIS CHECK - CHECKS TXTPTR FOR ')'. USES SYNCHR.
 \$DEBB (-8517) [CHKCPN] \SE\ APPLESOFT OPEN PARENTHESIS CHECK - CHECKS TXTPTR FOR '('. USES SYNCHR.
 \$DEBE (-8514) [CHKCOM] \SE\ APPLESOFT COMMA CHECK - CHECKS TXTPTR FOR COMMA. USES SYNCHR.
 \$DEC0 (-8512) [SYNCHR] \SE\ APPLESOFT SYNTAX CHARACTER CHECK - CHECKS TO VERIFY TXTPTR POINTS TO SAME CHARACTER AS THAT IN A-REG. NORMAL EXIT THRU CHGET TO GET NEX CHAR FROM INPUT BUFFER OTHERWISE SYNTAX ERROR. TXTPTR NOT MODIFIED. (Y-REG RESET TO ZERO)
 \$DEC9 (-8503) \SE\ SNERR S/R. PRINTS "SYNTAX ERROR" AND HALTS PROG
 \$DEE9 (-8471) [(INT=>FP)] \SE\ APPLESOFT - PULL INTEGER (X) VARIABLE POINTED TO BY FACMO~FACLO (\$00A0-\$00A1) INTO A-REG & Y-REG AND CONVERT TO FP IN FAC. RESETS VALTYP (RESETS Y-REG TO 0)
 \$D4F (-8369) [(FAC/ARG OR)] \SE\ APPLESOFT - LET FAC = FAC 'OR' ARG; I.E. FAC=1 IF EITHER FAC OR ARG OR BOTH <>; FAC=0 ONLY IF BOTH FAC & ARG = 0

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$DF55 (-8363) [(FAC/ARG AND)] \SE\APPLESOFT - LET FAC = FAC 'AND' ARG; I.E. FAC=1 ONLY IF BOTH FAC & ARG <>0; IF EITHER FAC OR ARG OR BOTH =0 THEN FAC=0

\$DF6A (-8342) [(FAC/ARG COMPARE)] \SE\APPLESOFT - COMPARE FAC WITH ARG. TYPE OF COMPARISON CONTROLLED BY \$0016. IF CONDITION MET FAC SET TO ONE; ELSE FAC RESET TO ZERO

\$DFE3 (-8221) [PTRGET] \SE\APPLESOFT - READ VAR NAME FROM CHRGET AND FIND IT IN MEMORY (OR CREATE APPROPRIATE SIMPLE VARIABLE OR ARRAY). DOES MUCH HOUSEKEEPING

\$E000~\$E7FF (-8192~-6145) \HB\ ROM SOCKET EO (APPLE II (NOT II+) = INTEGER BASIC)

\$E000 (-8192) [BASIC] INTEGER BASIC - 'HARD' OR 'COLD' OR 'CONTROL-B' ENTRY POINT (COMPLETE REINITIALIZATION. START WITH A TOTALLY FRESH SLATE)

\$E000 (-8192) [BASIC] APPLESOFT - 'HARD' OR 'COLD' OR 'CONTROL-B' ENTRY POINT (COMPLETE REINITIALIZATION. START WITH A TOTALLY FRESH SLATE.)

\$E003 (-8189) [BASIC2] \SE\ INTEGER BASIC - 'SOFT' OR 'WARM' OR 'CONTROL-C' OR 'ENTRY2' ENTRY POINT (REENTRY WITHOUT REINITIALIZATION OF SYMBOL-TABLE VARIABLES OR DATA)

\$E006 (-8186) ["SETPRMPT"] \SE\ INTEGER BASIC ENTRY POINT TO SET UP '>' PROMPT

\$E02A (-8150) ["NXTBYTE"] \SE\ INTEGER BASIC ENTRY POINT TO GET NEXT BYTE 16-BIT POINTER

\$E04B (-8117) \SE\ INTEGER BASIC 'LIST' ROUTINE (LIST ALL THE PROGRAM)

\$E05D (-8099) \SE\ INTEGER BASIC ENTRY POINT TO LIST X~Y (LIST A RANGE OF THE PROGRAM)

\$E06D (-8083) ["UNPACK"] \SE\ INTEGER BASIC ENTRY POINT TO UNPACK TOKENED CODE TO MNEMONICS

\$E07D (-8067) [ISLETC (CHARCHEK)] \SE\APPLESOFT - CHECKS A-REG FOR ASCII LETTER OTHERWISE CLEAR IT TO ZERO ('A' TO 'Z'). SET C (CARRY FLAG) TO 1 IF A IS A LETTER OTHERWISE CLEAR IT TO ZERO (A- X- Y-REGS NOT ALTERED)

\$E0FE~\$E104 (-7938~-7932) [(-32K)] \PS\APPLESOFT FIVE-BYTE FLOATING POINT CONSTANT -32768 (-2~16)

\$E105 (-7931) [(EVAL EXPR =>INT)] \SE\APPLESOFT - EVALUATE EXPRESSION POINTED TO BY TXTPTR (\$00B8~\$00B9) AND CONVERT RESULT (WHICH MUST BE NON-NEGATIVE) TO A TWO-BYTE INTEGER IN FACMO~FACLO (\$00A0~\$00A1)

\$E108 (-7928) [(AYPOSINT +FP=>INT)] \SE\APPLESOFT - SAME AS AYINT (\$E10C) EXCEPT FAC MUST BE POSITIVE

\$E10C (-7924) [AYINT (FP=>INT)] \SE\APPLESOFT - IF FAC SUITABLE FOR CONVERSION TO INTEGER (FAC<32767 & FAC>-32768) THEN PERFORM QINT (RESET Y-REG=0)

\$E130 (-7888) ["DIMSTR"] \SE\ INTEGER BASIC ENTRY POINT TO DIMENSION A STRING FOR MEMORY

\$E171 (-7823) ["INPUTSTR"] \SE\ INTEGER BASIC ENTRY POINT TO 'INPUT A STRING' ROUTINE

\$E196 (-7786) [(BAD SUBSCRPT)] \SE\APPLESOFT - PRINT "BAD SUBSCRIPT" AND HALT AT APPLESOFT LEVEL (J)

\$E199 (-7783) [(ILLEGAL QTY PRT)] \SE\APPLESOFT - PRINT "ILLEGAL QUANTITY" AND HALT AT APPLESOFT LEVEL (J)

\$E222 (-7646) ["MULT"] \SE\ INTEGER BASIC ENTRY POINT TO MULTIPLY ROUTINE

\$E27A (-7558) ["MOD"] \SE\ INTEGER BASIC ENTRY POINT TO MODULO FUNCTION

\$E28A (-7542) ["SCRN"] \SE\ INTEGER BASIC ENTRY POINT TO SCREEN X~Y~ COLOR VALUE FUNCTION

\$E2B3 (-7501) ["MAINLINE"] \SE\ INTEGER BASIC ENTRY POINT TO MAIN LINE OF COMPILE/EXECUTE CODE

\$E2F2 (-7438) [GIVAYF (INT=>FP)] \SE\APPLESOFT - FLOAT THE SIGNED INTEGER W/ LSB IN A-REG MSB IN Y-REG INTO FAC. RESETS VALTYP. (RESETS Y-REG=0)

\$E301 (-7423) [SNGFLT] \SE\ APPLESOFT - FLOAT THE UNSIGNED INTEGER IN Y-REG INTO FAC. RESETS VALTYP. (RESET Y-REG=0)

\$E306 (-7418) [ERRDIR] \SE\ APPLESOFT - CAUSES ILLEGAL DIRECT ERROR IF PROGRAM NOT RUNNING (X-REG ALTERED)

\$E30B (-7413) [(ILLDIRPRT)] \SE\ PRINT "ILLEGAL DIRECT" THEN HALT AT APPLESOFT (J) LEVEL

\$E30E (-7410) \SE\ APPLESOFT - PRINT "UNDEFINED FUNCTION" THEN HALT AT APPLESOFT (J) LEVEL

\$E36B (-7317) [MEMFUL] \SE\ INTEGER BASIC MEMORY FULL ERROR

\$E36F (-7313) ["DELETE"] \SE\ INTEGER BASIC ENTRY POINT TO DELETE LINES OF TEXT X~Y

\$E3C0 (-7232) ["ERRORMESS*"] \SE\ INTEGER BASIC ENTRY POINT - INPUT ERROR MESSAGE

\$E3CE (-7218) ["GETCMD"] \SE\ INTEGER BASIC ENTRY POINT TO GET A COMMAND FROM THE KEYBOARD

\$E3D5 (-7211) [STRINI] \SE\ APPLESOFT - GET SPACE FOR CREATION OF A STRING & CREATE DISCRIPTOR FOR IT IN DSCTMP. ON ENTRY A-REG = LEN OF STRING.

\$E3DD (-7203) [STRSPA] \SE\ APPLESOFT - JSR TO GETSPA. STORE THE POINTER & LENGTH IN DSCTMP.

\$E3E0 (-7200) ["ERRORMESS"] \SE\ INTEGER BASIC ENTRY POINT TO PRINT ERROR MESSAGE AND GOTO MAINLINE

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$E3E3 (-7197) \SE\	INTEGER BASIC ENTRY POINT TO WHICH DOS 3.2 CHAINS WHEN PROCESSING ERRORS
\$E3E7 (-7193) [STRLIT] \SE\	APPLESOFT - STORE A QUOTE IN ENDCHR AND CHARAC SO THAT STRLT2 WILL STOP ON IT
\$E3ED (-7187) [STRLT2] \SE\	APPLESOFT - BUILD DESCRIPTOR FOR STRING LITERAL WHOSE 1ST CHAR POINTED TO BY Y-REG (MSB) & X-REG (LSB). PUT INTO TEMPORARY & POINTER TO IT IN FACMO-FACLO.
\$E42A (-7126) [PUTNEW] \SE\	APPLESOFT - STRING FUNCTION RETURNING WITH RESULT INDSCTMP. MOVE DSCTMP TO TEMP DESCRIPTOR & PUT POINTER TO DESCRIPTOR IN FACMO-FACLO & FLAG RESULT AS STRING
\$E430 (-7120) [(TOO COMPLEX)] \SE\	APPLESOFT - PRINT "FORMULA TOO COMPLEX" THEN HALT AT APPLESOFT (J) LEVEL
\$E452 (-7086) [GETSPA] \SE\	APPLESOFT - GET SPACE FOR CHARACTER STRING. MOVES FRESPC & FRETOP DOWN. A-REG = # OF CHARS. POINTER TO SPC IN Y-REG(MSB) & X-REG(LSB)
\$E484 (-7036) [GARBAG] \SE\	APPLESOFT GARBAGE COLLECTOR - MOVES ALL CURRENTLY USED STRINGS UP IN MEMORY AS FAR AS POSSIBLE
\$E51B (-6885) [HEX/DEC] \SE\	INTEGER BASIC - DECIMAL LPRINT (LINE NUMBER PRINT) S/R; CONVERTS 2-BYTE (16-BIT) BINARY/HEX TO UNSIGNED DECIMAL (0-65535)
\$E597 (-6761) [CAT] \SE\	APPLESOFT - CONCATENATE TWO STRINGS. FACMO (MSB) & FACLO (LSB) POINT TO FIRST STRING'S DESCRIPTOR & TXTPTR POINTS TO '+'
\$E5AD (-6739) [NEW] \SE\	INTEGER BASIC ENTRY POINT TO CLEAR OUT OLD PROGRAM AND RESET POINTERS FOR A NEW PROGRAM
\$E5B7 (-6729) [CLR] \SE\	INTEGER BASIC ENTRY POINT TO CLEAR OUT VARIABLE WORK SPACE
\$E5D4 (-6700) [MCVINS] \SE\	APPLESOFT - MOVE STRING WHOSE DESCRIPTOR IS POINTED TO BY STRNG1 TO MEM LOC POINTED TO BY FORPNT
\$E5E2 (-6686) [MOVSTR] \SE\	APPLESOFT - MOVE STRING POINTED TO BY Y-REG (MSB) & X-REG (LSB) WITH LENGH IN A-REG TO MEMORY POINTED TO BY FRESPA
\$E5FD (-6659) [FRESTR] \SE\	APPLESOFT - MAKE SURE THAT LAST FAC RESULT WAS A STRING & FALL INTO FREFAC
\$E604 (-6652) [FRETMP] \SE\	APPLESOFT - FREE A TEMPORARY STRING. ON ENTRY POINTER TO DESCRIPTOR IS IN Y-REG (MSB) & X-REG (LSB)
\$E635 (-6603) [FRETMS] \SE\	APPLESOFT - FREE TEMPORARY DESCRIPTOR W/O FREEING UP THE STRING. Y-REG (MSB) & X-REG(LSB) POINT TO DESCRIPTOR TO BE FREED. ON EXIT Z SET IF ANYTHING FREED
\$E6EC (-6420) [BRANCH] \SE\	INTEGER BASIC ENTRY POINT TO BRANCH (GET LO/HI THEN JSR)
\$E6F5 (-6411) [GTBYTC] \SE\	APPLESOFT - JSR TO CHRGET TO GOBBLE A CHARACTER AND FALL INTO GETBYT
\$E6F8 (-6408) [GETBYT] \SE\	GETBYT S/R. EVALS EXPRESSION (FORMULA) POINTED TO BY TXTPTR (\$00B8-\$00B9) & CONVTS TO 1-BYT VAL IN X-REG & FACLO(\$00A1). A-REG GETS EXPRESSION TERMINAL SIGN (RESETS Y-REG=0)
\$E6F8 (-6408) [GETBYT] \SE\	APPLESOFT - EVAL FORMULA AT TXTPTR. LEAVE RESULT IN FAC AND FALL INTO CONINT. AT ENTRY TXTPTR POINTS TO FIRST CHAR IN FORMULA FOR FIRST NUMBER PLOTENS PUTS FIRST NUMBER IN FIRST AND SECOND NUMBER IN H2 AND V2
\$E6FB (-6405) [CONINT] \SE\	APPLESOFT FP - CONVERT FAC INTO SINGLE BYTE IN X-REG & FACLO. NORMAL EXIT THRU CHRGET. IF FAC<0 OR FAC>255 ILLEGAL QUANT ERROR
\$E6FF (-6401) [GETVERB] \SE\	INTEGER BASIC ENTRY TO GET NEXT VERB TO USE
\$E715 (-6379) [GET16BIT] \SE\	INTEGER BASIC ENTRY TO GET A 16-BIT VALUE
\$E736 (-6346) [NOT] \SE\	INTEGER BASIC ENTRY TO 'NOT' (NOT A VALUE FUNCTION)
\$E746 (-6330) [GETNUM] \SE\	APPLESOFT FP - READ 2-BYTE NUM INTO LINNUM FROM TXTPTR. CHECK FOR COMMA. GET SINGLE BYTE NUMB IN X-REG.
\$E74A (-6326) [ABS] \SE\	INTEGER BASIC ENTRY TO GET ABSOLUTE VALUE OF A NUMBER
\$E74C (-6324) [COMBYTE] \SE\	APPLESOFT - CHECK FOR COMMA & GET A BYTE IN X-REG. USES CHKCOM& BETBYT. ON ENTRY TXTPTR POINTS TO COMMA
\$E752 (-6318) [GETADR] \SE\	APPLESOFT FP - CONVERT FAC (-65535 TO 65535) INTO 2-BYTE INTEGER (0-65535) IN LINNUM. 'WRAPAROUND' OCCURS IF VALUE IN FAC TOO BIG (A- Y-REGS ALTERED)
\$E75C (-6308) [SGN] \SE\	INTEGER BASIC ENTRY POINT TO GET SIGN OF A NUMBER
\$E782 (-6270) [SUBTRACTION] \SE\	INTEGER BASIC ENTRY POINT TO SUBTRACTION FUNCTION
\$E785 (-6267) [ADDITION] \SE\	INTEGER BASIC ENTRY POINT TO ADDITION FUNCTION
\$E7A0 (-6240) [FADDDH] \SE\	APPLESOFT FP - ADD 1/2 TO FAC (1/2 IN \$EE64)

\$E3E3 - \$E7A0

Prof. Luebbert's "What's Where in the Apple"

NUMERIC ATLAS

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$E7A4 (-6236) ["TAB"] \SE\INTEGER BASIC ENTRY POINT TO HORIZONTAL TAB FUNCTION
$E7A7 (-6233) [FSUB (FPSUB)] \SE\APPLESOFT - MOVE FP NUMBER IN MEMORY POINTED TO BY Y-REG & A-REG INTO ARG AND FALL INTO
FSUB (FPSUB)
$E7AA (-6230) [FSUBT] \SE\APPLESOFT - FP SUBTRACT FAC FROM ARG. ON ENTRY A-REG & 6502 ZERO FLAG REFLECT FACEXP. RESULT
TO FAC
$E7BE (-6210) [FADD (FPADD)] \SE\APPLESOFT FP - MOVE THE FP NUMBER IN MEMORY POINTED TO BY Y-REG & A-REG INTO ARG AND
FALL INTO FADDT (FPADD). MODIFIES INDEX & XORFPSGN
$E7C1 (-6207) ["COMMA"] \SE\INTEGER BASIC ENTRY POINT TO COMMA FUNCTION
$E7C1 (-6207) [FADDT] \SE\APPLESOFT FP - ADD FAC AND ARG. ON ENTRY A-REG AND ZERO FLAG REFLECT FACEXP. RESULT TO FAC
$E800-$EFFF (-6144-4097) \HB\ ROM SOCKET E8 (INTEGER BASIC)
$E7E2 (-6174) ["AUTO"] \SE\ INTEGER BASIC ENTRY TO AUTO LINE NUMBERING FUNCTION
$E828 (-6104) ["IF/THEN"] \SE\ INTEGER BASIC ENTRY TO IF/THEN ROUTINE
$E836 (-6090) \SE\ INTEGER BASIC 'RUN' - LOCATION INTO WHICH DOS CHAINS TO RUN AN INTEGER BASIC PROGRAM
$E83C (-6084) ["GOSUB"] \SE\ INTEGER BASIC ENTRY TO GOSUB HANDLER
$E84E (-6066) [(RESET)] \SE\ RESET FACEXP($009D) AND $00A2 (FACSIGN) & A-REG TO ZERO (A-REG=>0;X- Y-REG NOT
ALTERED)
$E85B (-6053) ["GOTO"] \SE\ INTEGER BASIC ENTRY TO 'GOTO' HANDLER
$E875 (-6027) ["GETNEXT"] \SE\ INTEGER BASIC ENTRY TO 'GETNEXT' (FETCH NEXT STATEMENT FROM TEXT SOURCE)
$E8A5 (-5979) ["RETURN"] \SE\ INTEGER BASIC ENTRY TO ROUTINE FOR RETURN FROM GOSUB
$E8C3 (-5949) ["STOPPED AT"] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO PRINT 'STOPPED AT LINE #'
$E8D5 (-5931) [(OVERFLOWPRT)] \SE\ PRINT "OVERFLOW" THEN HALT AT THE APPLESOFT (J) LEVEL
$E8D6 (-5930) ["NEXT"] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO HANDLE 'NEXT' LOOP END
$E913-$E917 (-5869-5865) [(ONE)] \P5\APPLESOFT FP CONSTANT ONE = 1.
$E92D-$E931 (-5843-5839) [(SQR(.5))] \P5\APPLESOFT FP CONSTANT SQR(.5) = .707..
$E932-$E936 (-5838-5834) [(SQR(2))] \P5\APPLESOFT FP CONSTANT SQR(2) = 1.414...
$E937-$E943 (-5833-5813) [(MINUS.ONE.HALF)] \P5\APPLESOFT FP CONSTANT MINUS ONE HALF (-1/2)
$E93A (-5830) ["FOR"] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO HANDLE 'FOR' LOOP INITIALIZATION
$E93C-$E940 (-5828-5824) [(LN(2))] \P5\APPLESOFT FP CONSTANT (LN(2) = .30103...
$E950 (-5808) ["TO/FOR"] \SE\ INTEGER BASIC ENTRY POINT TO ROUTINE TO HANDLE LOOP COUNTER # TO # STEP #
$E97F (-5761) [FMULT (FPMULT)] \SE\ APPLESOFT FP - MOVE THE FP NUMBER IN MEMORY POINTED TO BY Y-REG & A-REG INTO ARG
AND FALL INTO FMULTT (FPMULT). ALTERS INDEX XORFPSGN
$E982 (-5758) [FMULTT] \SE\ APPLESOFT FP - MULTIPLY FAC BY ARG. ON ENTRY A-REG & ZERO FLAG REFLECT FACEXP.
RESULT TO FAC. XORFPSGN MUST BE COMPUTED BEFORE CALL
$E9E3 (-5661) [CONUPK] \SE\ APPLESOFT FP - LOAD ARG FROM MEMORY POINTED TO BY Y-REG & A-REG. ON EXIT A & Z
REFLECT FACEXP. MODIFIES INDEX & XORFPSGN. (RESET Y-REG=0)
$E9E7 (-5657) \SE\ APPLESOFT FP - SAME AS $E9E3 EXCEPT USE MEMORY LOCATION POINTED TO BY INDEX
($005E-$005F)
$EA10-$EA87 (-5616-5497) ["VERBADL"] \PB\INTEGER BASIC VERB DISPATCH TABLE LOW BYTE
$EA39 (-5575) [MUL10] \SE\ APPLESOFT FP - MULTIPLY FAC BY 10. WORKS FOR BOTH POSITIVE & NEGATIVE NUMBERS
$EA55 (-5547) [DIV10] \SE\ APPLESOFT FP - DIVIDE FAC BY 10. RETURNS POSITIVE NUMBERS ONLY
$EA66 (-5530) [FDIV (FPDIV)] \SE\ APPLESOFT FP - MOVE THE FP NUMBER IN MEMORY POINTED TO BY R-REG & A-REG INTO ARG
AND FALL INTO FDIVT. ALTERS INDEX & XORFPSGN
$EA69 (-5527) [FDIVT (FPDIV2)] \SE\ APPLESOFT FP - DIVIDE ARG BY FAC. ON ENTRY A-REG AND Z REFLECT FACEXP. RESULT IN
FAC. XORFPSGN SHOULD BE COMPUTED BEFORE CALL
$EA88 (-5496) ["VERBADRH"] \PB\ INTEGER BASIC VERB DISPATCH TABLE HI BYTE
$EAE1 (-5407) [(DIVZEROPT)] \SE\ APPLESOFT - PRINT "DIVISION BY ZERO" THEN HALT AT APPLESOFT (J) LEVEL
$EAF9 (-5383) [MOVFM (FPLOAD)] \SE\ APPLESOFT FP MOVE MEMORY POINTED TO BY Y-REG & A-REG INTO FAC. ON EXIT A-REG & ZERO
FLAG REFLECT FACEXP. RESET EXTENSION BYTE=0 (RESET Y-REG=0)
$EAFD (-5379) \SE\ APPLESOFT FP - PULL MEMORY POINTED TO BY INDEX ($005E-$005F) INTO FAC & RESET
EXTENSION BYTE = 0 (RESET Y-REG=0)
$EB00-$EB99 (-5376-5223) \PB\ INTEGER BASIC ERROR TABLE OF CANNED ERROR MESSAGES

```


HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$EB1E (-5346) [MOV2F] \SE\ APPLESOFT FP - PACK FAC AND MOVE IT INTO TEMP2 (\$0098~\$009C). USES MOVMF. ON EXIT A-REG & Z FLAG REFLECT FACEXP (RESET Y-REG=0)
 \$EB21 (-5343) [MOV1F] \SE\ APPLESOFT FP - PACK FAC AND MOVE IT INTO TEMP1 (\$0093~\$0097). USES MOVMF. ON EXIT A-REG & Z FLAG REFLECT FACEXP. MODIFIES INDEX (\$005E~\$005F) (RESET Y-REG=0)
 \$EB23 (-5341) [MOVML] \SE\ APPLESOFT FP - PACK FAC AND MOVE IT INTO ZERO PAGE AREA POINTED TO BY X-REG. USES MOVMF. ON EXIT A-REG & Z FLAG REFLECT FACEXP
 \$EB27 (-5337) \SE\ APPLESOFT FP - PAC FAC AND STORE IT INTO MEMORY POINTED TO BY FORPNT (\$0085~\$0086). MODIFIES INDEX (\$005E~\$005F) (RESET Y-REG=0)
 \$EB2B (-5333) [MOVMF (FPSTR)] \SE\ APPLESOFT FP - PACK FAC AND MOVE IT INTO MEMORY POINTED TO BY Y-REG (MSB) & X-REG (LSB). ON EXIT A-REG & ZERO FLAG REFLECT FACEXP. MODIFIES INDEX (\$005E~\$005F)
 \$EB36 (-5322) \SE\ INTEGER BASIC CONTINUE RUN ROUTINE (W/O DELETING VARIABLES)
 \$EB53 (-5293) [MOVFA (TR2=>1)] \SE\ APPLESOFT FP - MOVE ARG INTO FAC. ON EXIT A-REG = FACEXP AND ZERO FLAG IS SET
 \$EB63 (-5277) [MOVAF (TR1=>2)] \SE\ APPLESOFT FP - PACK EXTENSION BYTE INTO FAC & MOVE FAC INTO ARG. ON EXIT A-REG = FACEXP AND ZERO FLAG IS SET. RESET EXTENSION BYTE = 0 (RESET X-REG=0)
 \$EB66 (-5274) \SE\ APPLESOFT FP - SAME AS \$EB63 BUT EXTENSION BYTE NOT ALTERED
 \$EB82 (-5246) [SIGN] \SE\ APPLESOFT FP - SETS A-REG ACCORDING TO VALUE OF FAC. ON EXIT A-REG=1 IF FAC +;A-REG=0 IF FAC=0;A-REG=\$FF IF FAC - {X- Y-REGS NOT ALTERED}
 \$EB90 (-5232) [SGN (FPSGN)] \SE\ APPLESOFT FP - CALLS SIGN AND FLOATS THE RESULT IN THE FAC. FAC=+1 IF FAC WAS +;=0 IF FAC WAS 0;=-1 IF FAC WAS -
 \$EB93 (-5229) [FLOAT] \SE\ APPLESOFT FP - FLOAT THE SIGNED INTEGER IN A-REG INTO FAC
 \$EBAA (-5206) [~INPUT~] \SE\ INTEGER BASIC ENTRY TO INPUT ROUTINE
 \$EBAF (-5201) [ABS (FPABS)] \SE\ APPLESOFT FP - TAKES ABSOLUTE VALUE OF NUMBER IN FAC & LEAVES RESULT IN FAC
 \$EBB2 (-5198) [FCOMP] \SE\ APPLESOFT FP - COMPARE FAC AND PACKED NUMBER IN MEMORY POINTED TO BY Y-REG & A-REG. ON EXIT A=1 IF MEM<FAC;A=0 IF MEM=FAC;A=\$FF IF MEM>FAC
 \$EBF2 (-5134) [QINT] \SE\ APPLESOFT QUICK GREATEST INTEGER FUNCTION. LEAVE INT(FAC)IN FAC MANTISSA (HO~MO~LO SIGNED). ASSUMES FAC<2^23 (RESET Y-REG=0)
 \$EC00~\$EDFF (-5120~-4609) [~SYNTAB~] \PB\INTEGER BASIC SYNTAX TABLE
 \$EC23 (-5085) [INT (FPINT)] \SE\ APPLESOFT FP - COMPUTES GREATEST INT (FPINT)EGER VALUE OF FAC. MODIFIES CHARAC (\$000D). USES QINT (FPINT). RESULT TO FAC. MODIFIES CHARAC (\$000D)
 \$EC40 (-5056) [(INITFACMANT)] \SE\ APPLESOFT FP - INITIALIZED MANTISSA OF FAC (EXCEPT EXTENSION BYTE) TO VALUE IN A-REGISTER
 \$EC4A (-5046) [FIN] \SE\ APPLESOFT - INPUT FP NUMB INTO FAC FROM CHRGET. ASSUMES 6502 REGS HAVE BEEN SET UP BY CHRGET THAT FETCHED 1ST DIGIT
 \$ED14~\$ED18[(ONE.BILLION)] \P5\ APPLESOFT 5-BYTE FLOATING POINT CONSTANT 1000000000 (1E9)
 \$ED19 (-4839) [INPT] \SE\ APPLESOFT - PRINT 'IN' & CURRENT LINE # FROM CURLIN. USES LPRINT
 \$ED24 (-4828) [LINPT] \SE\ APPLESOFT - PRINTS 2-BYTE UNSIGNED NUMBER IN X-REG (MSB) & A-REG (LSB)
 \$ED2E (-4818) [PRNTFAC] \SE\ APPLESOFT - PRINTS & DESTROYS CURRENT VALUE OF FAC. USES FOUT & STROUT
 \$ED34 (-4812) [FOUT] \SE\ CREATES A STRING IN FBUFFR EQUIVALENT IN VALUE TO FAC. ON EXITY-REG &A-REG POINT TO THE STRING. FAC SCRAMBLED
 \$EE03 (-4605) [~PRNTSTR~] \SE\ INTEGER BASIC ENTRY TO FUNCTION WHICH PRINTS A STRING
 \$EE22 (-4574) [~LEN~] \SE\ INTEGER BASIC ENTRY TO FUNCTION TO OBTAIN LENGTH OF A STRING
 \$EE34 (-4556) [~GETVAL~] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO GET A VALUE WHICH WILL FIT INTO A SINGLE BYTE (VAL<=255)
 \$EE3F (-4545) [~PLOT~] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO DO A LO~RES PLOT (I.E. PLOT A COLORED SQUARE ON LO-RES SCREEN)
 \$EE4E (-4530) [~COLOR~] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO SET COLOR VALUE FOR LO-RES
 \$EE54 (-4524) [~MAN~] \SE\ INTEGER BASIC ENTRY TO MANUAL LINE NUMBER FUNCTION
 \$EE57 (-4521) [~VTAB~] \SE\ INTEGER BASIC ENTRY TO VERTICAL TAB FUNCTION
 \$EE64~\$EE68 (-4508~-4504) [(ONE.HALF)] \P5\APPLESOFT 5-BYTE FP CONSTANT ONE HALF (1/2)
 \$EE68 (-4504) [RNGERR] \P1\ INTEGER BASIC RANGE ERROR
 \$EE8D (-4457) [SQR (FPSQR)] \SE\ APPLESOFT FP - TAKE SQUARE ROOT OF FAC. RESULT TO FAC. MODIFIES CHARAC INDEX AND MANY OTHER FP LOCNS

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$EE97 (-4457) [FPWRT (FPEXP)] \SE\ APPLESOFT FP EXPONENTATION (ARG TO FAC POWER) ON ENTRY A-REG & ZERO FLAG SHOULD
REFLECT VALUE OF FACEXP. RESULT TO FAC. MODIFIES MANY FP LOCNS
$EEA0 (-4448) [CALL] \SE\ INTEGER BASIC ENTRY POINT TO CALL A SUB/ROT FUNCTION
$EEB0 (-4432) [HLIN] \SE\ INTEGER BASIC ENTRY POINT TO DRAW A LO-RES HORIZONTAL LINE
$EEC6 (-4410) [VLIN] \SE\ INTEGER BASIC ENTRY POINT TO DRAW A LO-RES VERTICAL LINE
$EED0 (-4400) [NEGOP] \SE\ APPLESOFT FP - LET FAC = -FAC (X- Y-REGS NOT ALTERED)
$EED3 (-4397) [PRINT] \SE\ INTEGER BASIC ENTRY POINT TO PRINT ERROR MESSAGE/BELL
$EEDB-$EEDF (-4389-4385) [(LOG(E)2)] \PS\APPLESOFT FP CONSTANT LOG(E)2
$EEF6 (-4362) [PEEK] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO 'PEEK' AT THE CONTENTS OF A MEMORY LOCATION
$EF00 (-4352) [GETVAL255] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO GET A ONE-BYTE VALUE
$EF09 (-4343) [EXP] \SE\ APPLESOFT FP - RAISE E TO THE FAC POWER. RESULT TO FAC. MODIFIES INDEX CHARAC
COMPRTP XORFPSGN AND MANY OTHER FP LOCNS
$EF10 (-4336) [DIVIDE] \SE\ INTEGER BASIC ENTRY TO DIVIDE FUNCTION
$EF1E (-4322) [DIMVARB] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO DIMENSION A VARIABLE
$EF4E (-4274) [RND] \SE\ INTEGER BASIC ENTRY TO RANDOM NUMBER GENERATOR
$EFAE (-4178) [RND] \SE\ APPLESOFT FP - FORM A 'RANDOM' NUMBER IN FAC USING ORIGINAL VALUE IN FAC AS
PARAMETER 'KEY' OR 'SEED'. MODIFIES MANY FP LOCNS
$FEFA (-4118) [COS] \SE\ APPLESOFT FP - COMPUTE THE COSINE OF THE NUMBER IN FAC. RESULT TO FAC. MODIFIES
INDEX CHARAC COMPRTP XORFPSGN AND MANY OTHER FP LOCNS
$FEFC (-4116) [RUN] \SE\ APPLE INTEGER BASIC RUN ROUTINE (RUN FROM BEGINNING)
$EFF2 (-4110) [RUN #N] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO RUN FROM LINE #N
$EFF1 (-4111) [SIN] \SE\ APPLESOFT FP - COMPUTE THE SINE OF THE NUMBER IN FAC. RESULT TO FAC. MODIFIES INDEX
CHARAC COMPRTP XORFPSGN & MANY OTHER FP LOCNS
$F000-$F7FF (-4096-2049) \HB\ ROM SOCKET FD (1K INTEGER BASIC 1 K MONITOR IN APPLE II (NOT II+))
$F000 (-4096) [SCRATCH] \SE\ INTEGER BASIC ENTRY TO SCRATCH EVERYTHING ROUTINE
$F03A (-4038) [TAN] \SE\ APPLESOFT FP - COMPUTE THE TANGENT OF THE NUMBER IN FAC. RESULT TO FAC. MODIFIES
CHARAC INDEX XORFPSGN AND MANY OTHER FP LOCNS
$F04D (-4019) [HIMEM] \SE\ INTEGER BASIC ENTRY TO THE HIMEM FUNCTION
$F063-$F067 (-3997-3993) [(PI/2)] \PS\APPLESOFT 5-BYTE FLOATING POINT CONSTANT PI/2 = 1.508...
$F06B-$F06F (-3989-3985) [(TWO PI)] \PS\APPLESOFT 5-BYTE FLOATING POINT CONSTANT 2*PI = 6.2832...
$F070-$F075 (-3984-3979) [(ONE-QUARTER)] \PS\APPLESOFT 5-BYTE FLOATING POINT CONSTANT 1/4 (0.25)
$F078 (-3976) INTEGER BASIC 'LOAD' (CASSETTE TAPE)
$F09E (-3938) [ATN] \SE\ APPLESOFT FP COMPUTE THE ARCTANGENT OF NUMBER IN FAC. RESULT TO FAC. MODIFIES INDEX
XORFPSGN AND MANY OTHER FP LOCNS
$F0C9 (-3895) [LOMEM] \SE\ INTEGER BASIC ENTRY TO LOMEM ROUTINE
$F0DF (-3873) [LOAD] \SE\ INTEGER BASIC ENTRY TO LOAD SUBROUTINE (LOAD A PROGRAM FROM CASSETTE TAPE)
$F11E (-3810) [SETHDR] \SE\ INTEGER BASIC ENTRY TO SET UP HEADER FOR SAVE/LOAD PARAMETERS
$F11E (-3810) [ACADR] HI-RES GRAPHICS 2-BYTE TAPE READ SETUP
$F12C (-3796) [SETBUF] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO SET UP PROGRAM SAVE/LOAD PARAMETERS
$F140 (-3776) [SAVE] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO SAVE A PROGRAM TO CASSETTE TAPE
$F161 (-3743) [PRERR] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO PRINT AN ERROR MESSAGE
$F167 (-3737) [POP] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO POP THE RETURN STACK FOR GOSUB
$F171 (-3727) [TRACE] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO SET TRACE MODE FOR EXECUTION
$F176 (-3722) [NOTRACE] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO TURN OFF TRACE MODE
$F17D (-3715) [TRACEIT] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO EXECUTE THE TRACE FUNCTION
$F1EC (-3604) [PLOTFSN] \SE\ APPLESOFT - GET 2 LO-RES PLOTTING COORDS SEPARATED BY COMMA FM TXTPTR. PUT FIRST #
IN FIRST AND SECOND # IN H2 & V2
$F279 (-3463) [STEP] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO HANDLE STEP FUNCTION FOR FOR/NEXT LOOP
$F2E0 (-3360) [NODSP] \SE\ INTEGER BASIC ENTRY TO ROUTINE TO TURN OFF DISPLAY FUNCTION
$F2E9 (-3351) [HANDLERR] \SE\ APPLESOFT ERROR PROC - SAVE CURLIN IN ERRLIN;TXTPTR IN ERRPOS;X-REG IN ERRNUM;
REMSTK IN ERRSTK

```

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$F304 (-3324) ["DSP"] \SE\	INTEGER BASIC ENTRY TO ROUTINE TO DISPLAY A VARIABLE SET
\$F30A (-3318) ["CON"] \SE\	INTEGER BASIC ENTRY TO ROUTINE TO CONTINUE EXECUTION
\$F317 (-3305) [RESUME] \SE\	APPLESOFT ERROR PROC - RESTORE CURLIN FROM ERRLIN & TXTPTR FROM ERRPOS. TRANSFER ERRSTK INTO 6502 STACK POINTER
\$F31D (-3299) ["ASC"] \SE\	INTEGER BASIC ENTRY TO ROUTINE TO PERFORM THE ASC (ASCII) FUNCTION
\$F33B (-3269) ["PDL"] \SE\	INTEGER BASIC ENTRY TO ROUTINE TO READ A PADDLE
\$F351 (-3247) ["RDKEY"] \SE\	INTEGER BASIC ENTRY TO ROUTINE TO READ AN INPUT FOR BASIC FROM KEYBOARD
\$F371 (-3215) ["EXP"] \SE\	INTEGER BASIC ENTRY TO ROUTINE TO EXPONENTIATE (RAISE TO A POWER)
\$F3C9 (-3127) ["PR#S"] \SE\	INTEGER BASIC ENTRY TO ROUTINE TO SET OUTPUT PORT
\$F3D4 (-3116) [HGR2] \SE\	APPLESOFT HI-RES - INITIALIZE & CLEAR PAGE 2 HI-RES REGARDLESS OF SCREEN BEING DISPLAYED
\$F3DE (-3106) [HGR] \SE\	APPLESOFT HI-RES - INITIALIZE & CLEAR PAGE 1 HI-RES REGARDLESS OF SCREEN BEING DISPLAYED
\$F3EE (-3090) [HCLR] \SE\	APPLESOFT HI-RES - CLEAR HI-RES SCREEN TO BLACK
\$F3F2 (-3086) [BKGD] \SE\	APPLESOFT HI-RES - CLEAR HI-RES SCREEN TO LAST PLOTTED COLOR
\$F40D (-3059) [HPOSN] \SE\	APPLESOFT HI-RES - POSN HI-RES CURSOR W/O PLOTTING. HPAG DETERMINES WHICH PAGE; HORIZ = Y-REG(MSB)&X-REG(LSB);VERT= A-REG
\$F41A (-3046) ["IN#S"] \SE\	INTEGER BASIC ENTRY TO ROUTINE TO SET INPUT PORT
\$F425-\$F65D (-3035-2467)	APPLE II FLOATING POINT PACKAGE (NOT USED IN APPLESOFT)
\$F453 (-2989) [HPLOT] \SE\	APPLESOFT HI-RES - CALL HPOSN THEN PLOT DOT THERE. NO DOT MAY BE PLOTTED IS PLOTTING NON-WHITE AT COMPLEMENTARY COLOR X COORD
\$F425 (-3035) [ADD] \SE\	ADD 3-BYTE M1 TO 3-BYTE M2 AND LEAVE RESULT IN M1 (NOT FP ADD BUT USED IN FP PKG) (A- X-REGS ALTERED)
\$F437 (-3017) [ABSWAP] \SE\	TAKE ABSOLUTE VALUE OF FP1; THEN SWAP FP1 WITH FP2 (FP1=\$00F8;\$FP2=\$00F4) (A- X-REGS ALTERED)
\$F451 (-2991) [FLOAT] \SE\	CONVERT INTEGER (HIGH BYTE IN M1;LOW BYTE IN M1+1;M1+2 CLEARED) TO NORMALIZED FL POINT EQUIV IN FP1 (A-REG ALTERED)
\$F463 (-2973) [NORM] \SE\	NORMALIZE FLOATING POINT NUMBER IN FP1 (A-REG ALTERED)
\$F4A4 (-2908) [FCOMPL] \SE\	VALUE OF FLOATING POINT NUMBER IN FP1 IS NEGATED THEN NORMALIZED (A- X-REGS ALTERED)
\$F468 (-2968) [FSUB] \SE\	FLOATING POINT SUBTRACTION MINUEND IN FP1;SUBTRAHEND IN FP2;NORMALIZED DIFFERENCE TO FP1 (A- X-REGS ALTERED)
\$F46E (-2962) [FADD] \SE\	FLOATING POINT NUMBER IN FP1 ADDED TO THAT IN FP2. NORMALIZED RESULT LEFT IN FP1 (A- X-REGS ALTERED)
\$F47D (-2947) [RTAR] \SE\	DENORMALIZE FP1 BY SHIFTING M1(&E) RIGHT 1 BIT POSN & INCREMENTING X1 (A- X-REGS ALTERED)
\$F48C (-2932) [FMUL] \SE\	FLOATING POINT MULTIPLY S/R: MUTIPLICAND IN FP1; MULTIPLIER IN FP2; SIGNED NORMALIZED PRODUCT IN FP1 (A- X- Y-REGS ALTERED)
\$F4B2 (-2894) [FMUL] \SE\	FL PT DIVIDE S/R: NORM DIVIDEND IN FP2;NORM DIVIDER IN FP1;SIGNED NORM FP QUOTIENT TO FP1 (A- X- Y-REGS ALTERED)
\$F500-\$F666 (-2816-2458)	APPLE II MINIASSEMBLER SOFTWARE PACKAGE
\$F500 (-2816) [REL]	MINIASSEMBLER MEMORY LOCATION 'REL'
\$F50C (-2804) [REL2]	MINIASSEMBLER MEMORY LOCATION 'REL2'
\$F516 (-2794) [REL3]	MINIASSEMBLER MEMORY LOCATION 'REL3'
\$F519 (-2791) [ERR3]	MINIASSEMBLER MEMORY LOCATION 'ERR3'
\$F51B (-2789) [FINDOP]	MINIASSEMBLER MEMORY LOCATION 'FINDOP'
\$F51D (-2787) [FNDOP2]	MINIASSEMBLER MEMORY LOCATION 'FNDOP2'
\$F53D (-2768) [HLIN] \SE\	APPLESOFT HI-RES HORIZ LINE DRAWING FROM LAST POINT PLOTTED TOX-COORD = X-REG(MSB)&A-REG(LSB);Y-COORD=Y-REG
\$F538 (-2760) [FAKEMON3]	MINIASSEMBLER MEMORY LOCATION 'FAKEMON3'
\$F53D (-2755) [FAKEMON]	MINIASSEMBLER MEMORY LOCATION 'FAKEMON'
\$F544 (-2748) [FAKEMON2]	MINIASSEMBLER MEMORY LOCATION 'FAKEMON2'

\$F55C (-2724)	[TRYNEXT]	MINIASSEMBLER MEMORY LOCATION 'TRYNEXT'
\$F578 (-2696)	[NREL]	MINIASSEMBLER MEMORY LOCATION 'NREL'
\$F57C (-2692)	[NEXTOP]	MINIASSEMBLER MEMORY LOCATION 'NEXTOP'
\$F586 (-2682)	[ERR]	MINIASSEMBLER MEMORY LOCATION 'ERR'
\$F588 (-2680)	[ERR2]	MINIASSEMBLER MEMORY LOCATION 'ERR2'
\$F592 (-2670)	[RESET2]	MINIASSEMBLER MEMORY LOCATION 'RESET2'
\$F595 (-2667)	[NXTLINE]	MINIASSEMBLER MEMORY LOCATION 'NXTLINE'
\$F5B1 (-2639)	[ERR4]	MINIASSEMBLER MEMORY LOCATION 'ERR4'
\$F5B9 (-2631)	[SPACE]	MINIASSEMBLER MEMORY LOCATION 'SPACE'
\$F5BD (-2627)	[NXTMN]	MINIASSEMBLER MEMORY LOCATION 'NXTMN'
\$F5C0 (-2624)	[NXTM]	MINIASSEMBLER MEMORY LOCATION 'NXTM'
\$F5CB (-2613)	[HFIND] \SE\	APPLESOFT HI-RES HFIND. CONVERT HI-RES CURSOR POSN TO X-Y COORDS. ON EXIT \$00E0=HORIZ LSB;\$00E1=HORIZ MSB;\$00E2=VERT
\$F5CB (-2613)	[NXTM2]	MINIASSEMBLER MEMORY LOCATION 'NXTM2'
\$F5D9 (-2599)	[FORM1]	MINIASSEMBLER MEMORY LOCATION 'FORM1'
\$F5DB (-2597)	[FORM2]	MINIASSEMBLER MEMORY LOCATION 'FORM2'
\$F5F8 (-2568)	[FORM3]	MINIASSEMBLER MEMORY LOCATION 'FORM3'
\$F5F9 (-2567)	[FORM4]	MINIASSEMBLER MEMORY LOCATION 'FORM4'
\$F5FA (-2566)	[FORM5]	MINIASSEMBLER MEMORY LOCATION 'FORM5'
\$F601 (-2559)	[DRAW] \SE\	APPLESOFT HI-RES - DRAW SHAPE POINTED TO BY Y-REG(MSB)&X-REG(LSB) BY INVERTING EXISTING COLOR OF DOTS THE SHAPE DRAWS OVER. A-REG=ROTATION FACTOR
\$F608 (-2552)	[FORM6]	MINIASSEMBLER MEMORY LOCATION 'FORM6'
\$F60D (-2547)	[FORM7]	MINIASSEMBLER MEMORY LOCATION 'FORM7'
\$F622 (-2526)	[FORM8]	MINIASSEMBLER MEMORY LOCATION 'FORM8'
\$F631 (-2511)	[FORM9]	MINIASSEMBLER MEMORY LOCATION 'FORM9'
\$F634 (-2508)	[GETNSP]	MINIASSEMBLER MEMORY LOCATION 'GETNSP'
\$F640 (-2496)	[FIX] \SE\	FROMFLOATING POINT NUMBER IN FP1 EXTRACT INTEGER. PUT HIGH-ORDER BYTE IN M1;LOW-ORDER IN M1+1 (A- X-REGS ALTERED)
\$F65D (-2467)	[XDRAW] \SE\	APPLESOFT HI-RES - DRAW SHAPE POINTED TO BY Y-REG(MSB)&X-REG(LSB) BY INVERTING EXISTING COLOR OF DOTS SHAPE DRAWS OVER. A-REG = ROT FACTOR
\$F666 (-2458)	[MINASM]	TURN ON MINIASSEMBLER (KEYBOARD INPUT WILL BE INTERPRETED AS A SEMBLY-LANGUAGE INSTRUCTION)
\$F689~\$F7FA (-2423~-2054)	\SB\	'SWEET-16' 16-BIT PSEUDO-MACHINE INTERPRETER
\$F689 (-2423)	\SE\	SWEET-16 INTERPRETER ENTRY
\$F6B9 (-2375)	[HFNS] \SE\	APPLESOFT - GET HI-RES PLOTTING COORDINATE FROM TXTPTR SETS UP 6502 REGISTERS FOR HPOSN: A-REG=VERT COORD;X-REG LSB OF HORIZ;Y-REG MSB OF HORIZ (A- X- Y-REGS ALTERED)
\$F6EC (-2324)	[SETHCOL] \SE\	APPLESOFT HI-RES - SET COLOR TO CONTENTS OF X-REG (MUST BE LESS THAN 8)
\$F775 (-2187)	[SHLOAD] \SE\	APPLESOFT HI-RES. LOADS SHAPE TABLE INTO MEMORY FROM TAPE ABOVE MEMSIZ (HMEM) AND SETS POINTER AT \$00E8
\$F7D9 (-2087)	[GETARYPT] \SE\	APPLESOFT - READ VAR NAME FROM CHRGET & FIND IT IN MEMORY.ON EXIT VAL OF VAR IN VARPNT AND Y-REG(MSB)&A-REG(LSB)
\$F800~\$FFFF (-2048~-1)	\HB\	ROM SOCKET F8 (MONITOR) NOTE: WHEN LANGUAGE CARD RAM DESELECTED MONITOR ON CARD ACTIVE
\$F800~\$FFFF (-2048~-1)	\SB\	APPLE II SYSTEM MONITOR (MAIN BODY)
\$F800~\$FFFF (-2048~-1)	\HB\	APPLE LANGUAGE CARD ADDITIONAL ROM/RAM
\$F800 (-2048)	[PLOT] \SE\	LO-RES PLOT POINT AT X-COORD=(Y-REG) Y-COORD=(A-REG) LEAVING GBASL^H AND MASK SET (SEE CALL-APPLE DEC 78) (A-REG ALTERED)
\$F80C (-2036)	[RTMASK]	MONITOR MEMORY LOCATION 'RTMASK'
\$F80E (-2034)	[PLOT1] \SE\	LO-RES PLOT A POINT X-COORD=(Y-REG) Y-COORD PER GBASL^H & MASK (A-REG ALTERED)
\$F819 (-2023)	\SE\	HLINE S/R (SEE CALL-APPLE NOV/DEC 78 PG4)
\$F819 (-2023)	[HLINE] \SE\	LO-RES S/R TO DRAW HORIZONTAL LINE AT Y-COORD = (A-REG) WITH X-COORDS FROM (A-REG) THRU (H2)(\$002C) (A- Y-REGS ALTERED)

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$F81C (-2020)	[HLINE1] \SE\	LO-RES S/R. DRAW HORZ LINE AT Y-COORD ESTAB BY GBASL'H & MASK. X-CORDS FROM (Y-REG) THRU (\$002C) (A- Y-REGS ALTERED)
\$F826 (-2010)	[VLINZ] \SE\	LO-RES PLOT VERTICAL LINE AT X-COORD = (Y-REG) AND Y-COORD FROM (A-REG)+1+CARRY THRU (\$002D) (A-REG ALTERED)
\$F828 (-2008)	[VLIN] \SE\	LO-RES PLOT VERT LINE AT X-COORD = (Y-REG) AND Y-COORD FROM (A-REG) THRU (\$002D) (A-REG ALTERED)
\$F831 (-1999)	[RTS1]	MONITOR MEMORY LOCATION 'RTS1'
\$F832 (-1998)	[CLRSCR] \SE\	MONITOR S/R TO CLEAR SCREEN - GRAPHICS MODE FULL SCREEN) (A- Y-REGS ALTERED)
\$F832 (-1998)	[CLRSCR] \SE\	CLEAR LO-RES GRAPHICS SCREEN1 TO BLACK (INVERSE @ IN TEXT MODE) MIXED GRAPHICS AREA ONLY (A- Y-REGS ALTERED)
\$F836 (-1994)	[CLRTOP] \SE\	CLEAR TOP 20 LINES PAGE1 TO INVERSE @ IN TEXT; BLACK IN LO-RES GRAPHICS (40 LO-RES GRAPHIC 'LINES') (A- Y-REGS ALTERED)
\$F838 (-1992)	[CLRSC2] \SE\	CLEAR LINES 0 THRU (Y-REG) 40 COLUMNS WIDE TO BLACK IN LO-RES GRAPHICS OR INVERSE @ IN TEXT PAGE 1 (A- Y-REGS ALTERED)
\$F83C (-1988)	[CLRSC3] \SE\	CLEAR LO-RES GRAPHICS PARTIAL TOP LEFT; X-COORD 0 THRU (Y-REG); Y-COORD 0 THRU (\$002D) (A- Y-REGS ALTERED)
\$F847 (-1977)	[GBASCALC] \SE\	COMPUTE GRAPHICS BASE MEMORY ADDRESS FOR LINE IN A-REG (NOTE: 2 LO-RES GRAPHICS LINES PER TEXT LINE SO (A)= LINE/2); SET GBASL'H (A-REG ALTERED)
\$F856 (-1962)	[GBCALC]	MONITOR MEMORY LOCATION 'GBCALC'
\$F85F (-1953)	[NXTCOL] \SE\	MONITOR LO-RES S/R. CHANGE COLOR TO (COLOR)+3 (A-REG ALTERED)
\$F864 (-1948)	[SETCOL] \SE\	SET LO-RES COLOR TO COLOR CODE SPECIFIED BY A-REG FOR FUTURE PLOTTING (A-REG ALTERED)
\$F871 (-1935)	[SCRN] \SE\	GET (LOAD TO A-REG) LO-RES GRAPHICS COLOR OF POINT Y-COORD = (A-REG); X-COORD = (X-REG) (A-REG ALTERED)
\$F879 (-1927)	[SCRN2]	MONITOR MEMORY LOCATION 'SCRN2'
\$F87F (-1921)	[RTMSK2]	MONITOR MEMORY LOCATION 'RTMSK2'
\$F882 (-1918)	[INSDS1]	MONITOR MEMORY LOCATION 'INSDS1'
\$F88E (-1906)	[INSDS2]	MONITOR S/R - DISASSEMBLER ENTRY
\$F89B (-1893)	[IEVEN]	MONITOR MEMORY LOCATION 'IEVEN'
\$F8A5 (-1883)	[ERR]	MONITOR MEMORY LOCATION 'ERR'
\$F8A9 (-1879)	[GETFMT]	MONITOR MEMORY LOCATION GETFMT
\$F8BE (-1858)	[MNNDX1]	MONITOR MEMORY LOCATION 'MNNDX1'
\$F8C2 (-1854)	[MNNDX2]	MONITOR MEMORY LOCATION 'MNNDX2'
\$F8C9 (-1847)	[MNNDX3]	MONITOR MEMORY LOCATION 'MNNDX3'
\$F8D0 (-1840)	[INSTDSP]	MONITOR & MINIASSEMBLER MEMORY LOCATION 'INSTDSP' (INSTRUCTION DISPLAY)
\$F8D4 (-1836)	[PRNTOP]	MONITOR MEMORY LOCATION 'PRNTOP' (PRINT OPERATION CODE)
\$F8DB (-1829)	[PRNTBL]	MONITOR MEMORY LOCATION 'PRNTBL'
\$F8F5 (-1803)	[PRMN1]	MONITOR MEMORY LOCATION 'PRMN1' (PRINT MNEMONIC)
\$F8F5 (-1803)	[NXTCOL]	AUTOSTART MONITOR MEMORY LOCATION 'NXTCOL'
\$F8F9 (-1799)	[PRMN2]	MONITOR MEMORY LOCATION 'PRMN2'
\$F910 (-1776)	[PRADR1]	MONITOR MEMORY LOCATION 'PRADR1' (PRINT ADDRESS)
\$F914 (-1772)	[PRADR2]	MONITOR MEMORY LOCATION 'PRADR2'
\$F926 (-1754)	[PRADR3]	MONITOR MEMORY LOCATION 'PRADR3'
\$F92A (-1750)	[PRADR4]	MONITOR MEMORY LOCATION 'PRADR4'
\$F930 (-1744)	[PRADR5]	MONITOR MEMORY LOCATION 'PRADR5'
\$F938 (-1736)	[RELADR]	MONITOR MEMORY LOCATION 'RELADR' (RELATIVE ADDRESS)
\$F940 (-1728)	[PRNTYX] \SE\	MONITOR S/R- PRINT CONTENTS OF Y AND X AS 4 HEX DIGITS (A- X-REGS ALTERED)
\$F941 (-1727)	[PRNTAX] \SE\	MONITOR S/R-PRINT CONTENTS OF A-REG & X-REG AS HEX DIGITS (A- X-REGS ALTERED)
\$F944 (-1724)	[PRNTX] \SE\	PRINT CONTENTS OF X-REG AS HEX DIGITS (A- X-REGS ALTERED)
\$F948 (-1720)	[PRBLNK] \SE\	PRINT THREE BLANKS THROUGH COUT (A- X-REGS ALTERED)
\$F94C (-1716)	[PRBL2] \SE\	MONITOR S/R- PRINT BLANKS: X REG CONTAINS NUMBER TO PRINT. CLO3BERS AC~X (A- X-REGS ALTERED)

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$F94C (-1716) [PRBL3] \SE\PRINT A-REG FOLLOWED BY (X-REG)-1 BLANKS (A- X-REGS ALTERED)
$F953 (-1709) [PCADJ] MINIASSEMBLER MEMORY LOCATION 'PCADJ' (PROGRAM COUNTER ADJUST: 0=1 BYTE; 1=2 BYTES; 2=3 BYTES)
$F954 (-1708) [PCADJ2] MONITOR & MINIASSEMBLER MEMORY LOCATION 'PCADJ2'
$F956 (-1706) [PCADJ3] MONITOR MEMORY LOCATION 'PCADJ3'
$F95C (-1700) [PCADJ4] MONITOR MEMORY LOCATION 'PCADJ4'
$F961 (-1695) [RTS2] MONITOR MEMORY LOCATION 'RTS2'
$F962 (-1694) [FMT1] MONITOR MEMORY LOCATION 'FMT1'
$F9A6 (-1626) [FMT2] MONITOR MEMORY LOCATION 'FMT2'
$F9B4 (-1612) [CHAR1] MONITOR & MINIASSEMBLER MEMORY LOCATION 'CHAR1'
$F9BA (-1606) [CHAR2] MONITOR & MINIASSEMBLER MEMORY LOCATION 'CHAR2'
$F9C0 (-1600) [MNEML] MONITOR & MINIASSEMBLER MEMORY LOCATION 'MNEML'
$FA00 (-1536) [MNEMR] MONITOR & MINIASSEMBLER MEMORY LOCATION 'MNEMR'
$FA40-$FA85 (-1472~-1403) SINGLE-STEP SIMULATOR SUBROUTINE (NOT IN AUTOSTART ROM)
$FA40 (-1472) [IRQ] \SE\ AUTOSTART ROM MONITOR S/R - IRQ HANDLER
$FA43 (-1469) [STEP] MONITOR S/R- PERFORM A SINGLE STEP (NOT AVAILABLE WITH AUTOSTART ROM). EXECUTES ONE
INSTRUCTION AT (PCL'H) WITH REGISTER RESTORE BEFORE; REGISTER SAVE AFTER; UPDATE OF
PCL'H; DISPLAY OF INSTRUCTION & DISPLAY OF RESULT REGISTERS
$FA4E (-1458) [XQINIT] MONITOR MEMORY LOCATION 'XQINIT'
$FA59 (-1447) [OLDBRK] AUTOSTART MONITOR MEMORY LOCATION 'OLDBRK'
$FA62 (-1438) [RESET] AUTOSTART MONITOR MEMORY LOCATION 'RESET'
$FA6F (-1425) [INITAN] AUTOSTART MONITOR MEMORY LOCATION 'INITAN'
$FA78 (-1416) [XQ1] MONITOR MEMORY LOCATION 'XQ1'
$FA7A (-1414) [XQ2] MONITOR MEMORY LOCATION 'XQ2'
$FA81 (-1407) [NEWMON] AUTOSTART MONITOR MEMORY LOCATION 'NEWMON'
$FA86 (-1402) [IRQ] \SE\ MONITOR S/R- IRQ HANDLER. NOTE: MOVED TO $FA40 IN AUTOSTART ROM
$FA92 (-1390) [BREAK] \SE\ MONITOR S/R - BREAK HANDLER
$FA9B (-1381) AUTOSTART MONITOR MEMORY LOCATION 'FIXSEV'
$FA9C (-1380) [XBRK] MONITOR MEMORY LOCATION 'XBRK'
$FAA5-$FAD6 (-1371~-1322) BLOCK OF CODE ASSOCIATED WITH SINGLE-STEP SIMULATOR IN NORMAL MONITOR REMOVED FROM
AUTOSTART ROM
$FAA5 (-1371) [XRTI] MONITOR MEMORY LOCATION 'XRTI'
$FAA6 (-1370) [PWRUP] AUTOSTART MONITOR MEMORY LOCATION 'PWRUP'
$FAA9 (-1367) [SETPG3] AUTOSTART MONITOR MEMORY LOCATION 'SETPG3'
$FAA9 (-1367) [XRTS] MONITOR MEMORY LOCATION 'XRTS'
$FAAD (-1363) [PCINC2] MONITOR MEMORY LOCATION 'PCINC2'
$FAAF (-1361) [PCINC3] MONITOR MEMORY LOCATION 'PCINC3'
$FAB9 (-1351) [XJSR] MONITOR MEMORY LOCATION 'XJSR'
$FAB9 (-1351) [SLOOP] AUTOSTART MONITOR MEMORY LOCATION 'SLOOP'
$FAC4 (-1340) [XJMP] MONITOR MEMORY LOCATION 'XJMP'
$FAC5 (-1339) [XJMPAT] MONITOR MEMORY LOCATION 'XJMPAT'
$FAC7 (-1337) [NXTBYT] AUTOSTART MONITOR MEMORY LOCATION 'NXTBYT'
$FACD (-1331) [NEWPC] MONITOR MEMORY LOCATION 'NEWPC'
$FAD1 (-1327) [RTNJMP] MONITOR MEMORY LOCATION 'RTNJMP'
$FAD7 (-1321) [REGDSP] \SE\ DISPLAY SAVED REGISTER CONTENTS FROM MEMORY LOCNS $0045-$0049 WITH PRECEDING
CARRIAGE RETURN (SEE 'SAVE' ROUTINE AT $FF4A) (A- X-REGS ALTERED)
$FADA (-1318) [RGDSP1] \SE\ DISPLAY SAVED REGISTER CONTENTS FROM MEMORY LOCNS $0045-$0049 WITHOUT PRECEDING
CARRIAGE RETURN (SEE 'SAVE' ROUTINE AT $FF4A) (A- X-REGS ALTERED)
$FAE4 (-1308) [RDSP1] MONITOR MEMORY LOCATION 'RDSP1'
$FAFD-$FB18 (-1283~-1256) BLOCK OF CODE ASSOCIATED WITH SINGLE-STEP SIMULATOR IN NORMAL MONITOR REMOVED FROM
AUTOSTART ROM
$FAFD (-1283) [BRANCH] MONITOR MEMORY LOCATION 'BRANCH'

```

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$FAFD (-1283) [PWRCON] AUTOSTART MONITOR MEMORY LOCATION 'PWRCON'
 \$FB05 (-1275) [DISKID] AUTOSTART MONITOR MEMORY LOCATION 'DISKID'
 \$FB09 (-1271) [TITLE] AUTOSTART MONITOR MEMORY LOCATION 'TITLE'
 \$FB0B (-1269) [NBRNCH] MONITOR MEMORY LOCATION 'NBRNCH'
 \$FB11 (-1263) [INITBL] MONITOR MEMORY LOCATION 'INITBL'
 \$FB11 (-1263) AUTOSTART MONITOR MEMORY LOCATION 'XLTBL'
 \$FB19 (-1255) [RTBL] MONITOR MEMORY LOCATION 'RTBL'
 \$FB1E (-1250) [PREAD] \SE\ MONITOR S/R TO READ PADDLE. X-REG CONTAINS PADDLE NUMBER (0-3) OF PADDLE TO BE READ. PADDLE VALUE TO Y-REG (A- Y-REGS ALTERED)
 \$FB25 (-1243) [PREAD2] MONITOR MEMORY LOCATION 'PREAD2'
 \$FB2E (-1234) [RTS2D] MONITOR MEMORY LOCATION 'RTS2D'
 \$FB2F (-1233) [INIT] \SE\ MONITOR S/R- SCREEN INITIALIZATION (RESET TEXT MODE)
 \$FB39 (-1223) [SETTXT] \SE\ MONITOR S/R- SET SCREEN TO TEXT MODE. CLOBBERS ACCUMULATOR (A-REG ALTERED)
 \$FB40 (-1216) [SETGR] \SE\ MONITOR S/R- SET GRAPHIC MODE (GR). THIS INCLUDES SETTING TO MIXED MODE; CLEARING GRAPHICS PART OF SCREEN; AND RESETTNG WNDTOP-WNDLFT-WNDWDTH-WNDBTM & TABV (A-REG ALTERED)
 \$FB43 (-1213) \SE\ MONITOR S/R - ALL OF SETGR EXCEPT SETTING COLOR GRAPHICS DISPLAY MODE
 \$FB46 (-1210) \SE\ MONITOR S/R - ALL OF SETGR EXCEPT SETTING COLOR GRAPHICS DISPLAY MODE & CLEARING GRAPHICS PART OF SCREEN; I.E. WINDOW & TAB SETTING ONLY
 \$FB4B (-1205) [SETWND] \SE\ MONITOR S/R- SET NORMAL LOW-RESOLUTION GRAPHICS WINDOW
 \$FB5B (-1189) [TABV] \SE\ PLACE CURSOR AT LINE (A-REG) COLUMN (CH) SETTING CV AND BASL-H FROM A-REG (A-REG ALTERED)
 \$FB60-\$FB80 (-1184-1152) [MULPM] \SB\ MONITOR 16-BIT MULTIPLY S/R (NOT IN AUTOSTART ROM). MULTIPLIER IN AUXL-AUXH (\$0054-\$0055); MULTIPLICAND IN ACL-ACH (\$0050-\$0051); XTNDL-XTNDH (\$0052-\$0053) CLEARED TO ZEROS; RESULT GOES TO EXTENDED AC (\$0050-\$0053). ALSO SEE 'SIGN' AT \$002F. (A- X-REGS-Y-REG ALTERED)
 \$FB60 (-1184) [MULPM] \SE\ MONITOR - SIGNED 16-BIT MULTIPLY LEAVING SIGN IN LSB OF 'SIGN' (A- X- Y-REGS ALTERED)
 \$FB60 (-1184) [APPLEII] \SE\ CLEAR SCREEN AND POKE 'APPLE II' INTO FIRST LINE OF TEXT BUFFER (AUTOSTART ROM ONLY) (A- Y-REGS ALTERED)
 \$FB63 (-1181) [MUL] \SE\ MONITOR - UNSIGNED 16-BIT MULTIPLY S/R (NOT AVAILABLE WITH AUTOSTART ROM). SAME AS MULPM (\$FB60) EXCEPT UNSIGNED. SEE 'SIGN' AT \$002F (A- X- Y-REGS ALTERED)
 \$FB65 (-1179) [MUL2] MONITOR MEMORY LOCATION 'MUL2'
 \$FB65 (-1179) [STITLE] AUTOSTART MONITOR MEMORY LOCATION 'STITLE'
 \$FB6D (-1171) [MUL3] MONITOR MEMORY LOCATION 'MUL3'
 \$FB6F (-1159) [SETPWRC] \SE\ SET POWER CONDITION (AUTOSTART ROM ONLY)
 \$FB76 (-1162) [MUL4] MONITOR MEMORY LOCATION 'MUL4'
 \$FB78 (-1160) [MUL5] MONITOR MEMORY LOCATION 'MUL5'
 \$FB78 (-1160) [VIDWAIT] AUTOSTART MONITOR MEMORY LOCATION 'VIDWAIT'
 \$FB81-\$FBCD (-1151-1088) MONITOR 16-BIT DIVIDE ROUTINE (NOT IN AUTOSTART ROM)
 \$FB81 (-1151) [DIVPM] MONITOR SIGNED DIVISION - DIVIDES NUMBER IN EXTENDED AC (\$0050-\$0053) BY NUMBER IN AUXL-AUXH (\$0054-\$0055) LEAVING QUOTIENT IN ACL-ACH (\$0050-\$0051) AND REMAINDER IN \$0053. BE CAREFUL OF SIGNS SCALING & OVERFLOW. IF (XTNDL-XTNDH (\$0052-\$0053)) > (AUXL-AUXH (\$0054-\$0055)) OVERFLOW WILL RESULT
 \$FB84 (-1148) [DIV] \SE\ MONITOR S/R- UNSIGNED DIVIDE ROUTINE - SAME AS \$FB81 (DIVPM) EXCEPT NO SIGNS USED.
 \$FB86 (-1146) [DIV2] MONITOR MEMORY LOCATION 'DIV2'
 \$FB88 (-1144) AUTOSTART MONITOR MEMORY LOCATION 'KBDWAIT'
 \$FBA0 (-1120) [DIV3] MONITOR MEMORY LOCATION 'DIV3'
 \$FBA4 (-1116) [MD1] MONITOR 16-BIT MULTIPLY/DIVIDE SIGN-PROCESSOR. SETS ABSOLUTE VALUES OF ACL-H MEMORY LOCATION 'MD1' AUXL-H LEAVING RESULTING SIGN IN LSB OF SIGN (\$002F)
 \$FBAF (-1105) [MD2] MONITOR MEMORY LOCATION 'MD2'

\$FBB4 (-1100)	[MD3]	MONITOR MEMORY LOCATION 'MD3'
\$FBC0 (-1088)	[MDRTS]	MONITOR MEMORY LOCATION 'MDRTS'
\$FBC1 (-1087)	[BASCALC] \SE\	MONITOR S/R- CALCULATE TEXT BASE ADDRESS. SET BASL'H TO LEFT END OF SCREEN LINE (NOT WINDOW LINE) IN A-REG (A-REG ALTERED)
\$FBD0 (-1072)	[BSCLC2]	MONITOR MEMORY LOCATION 'BSCLC2'
\$FBD9 (-1063)	[BELL1]	MONITOR MEMORY LOCATION 'BELL1'
\$FBD0 (-1059)		SOUNDS BELL IN APPLE REGARDLESS OF OUTPUT DEVICE IN USE (A- Y-REGS ALTERED)
\$FBE4 (-1052)	[BELL2] \SE\	MONITOR S/R- SOUND BELL (BEEPER)
\$FBEF (-1041)	[RTS2B]	MONITOR MEMORY LOCATION 'RTS2B'
\$FBF0 (-1040)	[STOADV] \SE\	MONITOR - LOAD Y FROM CH; STORE A-REG TO SCREEN AT (BASL)'Y; AND GOTO ADVANCE (\$FBF4) (A- Y-REG ALTERED)
\$FBF4 (-1036)	[ADVANCE] \SE\	MONITOR S/R- MOVE CURSOR RIGHT; I.E. INCREMENT (CH); COMPARE (CH) WITH (WNDWDTH) GO TO CR IF CH NOT LESS ELSE RETURN (RTS) (A-REG ALTERED)
\$FBF6 (-1034)	\SE\	COMPARE (CH) WITH (WNDWDTH) GO TO CR IF CH NOT LESS ELSE RETURN (RTS) (A-REG ALTERED)
\$FBFC (-1028)	[RTS3]	MONITOR MEMORY LOCATION 'RTS3'
\$FBFD (-1027)	[VIDOUT] \SE\	MONITOR S/R- OUTPUT A-REGISTER AS ASCII ON TEXT SCREEN OR PROCESS CONTROL CHARACTER. IF (A)<\$80 GOTO STOADV; =\$87 SOUND BELL; =\$88 GOTO BS; =\$8A GOTO LF; =\$8D GOTO CR; >\$9F GOTO STOADV; OTHERWISE IGNORE ENTRY SCREEN RTS 1
\$FC10 (-1008)	[BS] \SE\	MONITOR S/R TO MOVE CURSOR LEFT (BACKSPACE); IF AT START OF LINE MOVE UP TO RIGHT END OF LINE ABOVE IF POSSIBLE (A-REG ALTERED)
\$FC1A (-998)	[UP ~ CURSUP] \SE\	MONITOR S/R TO MOVE CURSOR UPWARD (IF POSSIBLE) (A-REG ALTERED)
\$FC22 (-990)	[VTAB] \SE\	PERFORM A VERTICAL TAB TO ROW SPECIFIED IN A-REG (\$0-\$17). SET BASL'H FROM CV (AND WNDLFT) (A-REG ALTERED)
\$FC24 (-988)	[VTABZ] \SE\	SET BASL'H FROM (A-REG) AND WNDLFT WITHOUT REGARD TO CV (A-REG ALTERED)
\$FC2B (-981)	[RTS4]	MONITOR MEMORY LOCATION 'RTS4'
\$FC2C (-980)	[ESC1] \SE\	ROUTINE (IF A=@ GO TO HOME; =A GO TO ADVANCE; =B GO TO BS (BACKSPACE); =C GO TO LF (LINEFEED); =D GO TO UP (INVERSE LINEFEED); =E GOTO CLREOL; =F GOTO CLREOP; =ANYTHING ELSE RTS & IGNORE ENTRY) CALLED BY 'RDCHAR' IF ESCAPE KEY IS INPUTTED. CALLS APPROPRIATE SCROLL WINDOW SERVICE ROUTINE (IF A=@ GO TO HOME; =A GO TO ADVANCE; =B GO TO BS (BACKSPACE); =C GO TO LF (LINEFEED); =D GO TO UP (INVERSE LINEFEED); =E GOTO CLREOL; =F GOTO CLREOP; =ANYTHING ELSE RTS & IGNORE ENTRY) (USES A-REG)
\$FC42 (-958)	[CLREOP] \SE\	MONITOR S/R TO CLEAR FROM CURSOR TO END OF PAGE. (A- Y-REGS ALTERED)
\$FC46 (-954)	[CLEOP1]	MONITOR MEMORY LOCATION 'CLEOP1'
\$FC58 (-936)	[HOME] \SE\	CLEAR SCROLL WINDOW TO BLANKS. SET CURSOR TO TOP LEFT CORNER (A- Y-REGS ALTERED)
\$FC5A (-934)	\SE\	SET CV (CURSOR VERTICAL POSN) FROM A-REG. CLEAR WINDOW TO END OF WINDOW; SET CH=0 (A- Y-REGS ALTERED)
\$FC62 (-926)	[CR] \SE\	MONITOR S/R TO PERFORM A CARRIAGE RETURN; I.E. LOAD ZERO TO A-REG & CH (A-REG ALTERED)
\$FC66 (-922)	[LF] \SE\	MONITOR S/R TO TO PERFORM A LINE FEED; I.E. INCREMENT CV; COMPARE CV TO WNDBTM IF CV<WNBDM GOTO VTABZ TO SET BASL'H AND RETURN ELSE DECREMENT CV AND DO SCROLL (A-REG ALTERED)
\$FC70 (-912)	[SCROLL] \SE\	MONITOR S/R TO SCROLL UP 1 LINE. (A- Y-REGS ALTERED)
\$FC76 (-906)	[SCRL1]	MONITOR MEMORY LOCATION 'SCRL1'
\$FC8C (-884)	[SCRL2]	MONITOR MEMORY LOCATION 'SCRL2'
\$FC95 (-875)	[SCRL3]	MONITOR - CLEAR LINE (BASL'H) (WHOLE LINE) THEN SET NEW BASL'H FROM CV & WNDLFT
\$FC9C (-868)	[CLREOL] \SE\	MONITOR S/R TO CLEAR TO END OF LINE (A- Y-REGS ALTERED)
\$FC9E (-866)	[CLEOLZ]	MONITOR MEMORY LOCATION 'CLEOLZ'
\$FCA0 (-864)	[CLEOL2]	MONITOR MEMORY LOCATION 'CLEOL2'
\$FCA8 (-856)	[WAIT] \SE\	CALL FOR WAIT LOOP. WAIT ESTIMATED AT 2.5A^2+13.5A+13 WAIT CYCLES OF 1.02 MICROSECONDS WHERE A IS CONTENTS OF A-REG WHEN S/R CALLED

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$FCA9 (-855) [WAIT2] MONITOR MEMORY LOCATION 'WAIT2'
 \$FCAA (-854) [WAIT3] MONITOR MEMORY LOCATION 'WAIT3'
 \$FCB4 (-844) [NXTA4] \SE\MONITOR S/R TO INCREMENT A4 (16 BITS) THEN DO NXTA1 (A-REG ALTERED)
 \$FCBA (-838) [NXTA1] \SE\MONITOR S/R TO INCREMENT A1 (16 BITS). SET CARRY IF RESULT >=A2. (A-REG ALTERED)
 \$FCC8 (-824) [RTS4B] MONITOR MEMORY LOCATION 'RTS4B'
 \$FCC9 (-823) [HEADR] MONITOR - WRITES SYNCHRONIZATION MONOTONE WHICH IS FIRST PART OF EVERY CASSETTE TAPE RECORD
 \$FCD6 (-810) [WRBIT] MONITOR - WRITES A BIT TO CASSETTE TAPE (CALLED BY WRBYTE AND HEADR)
 \$FCD8 (-805) [ZERDLY] MONITOR MEMORY LOCATION 'ZERDLY'
 \$FCE2 (-798) [ONEDLY] MONITOR MEMORY LOCATION 'ONEDLY'
 \$FCE5 (-795) [WRTAPE] MONITOR MEMORY LOCATION 'WRTAPE'
 \$FCEC (-788) [RDBYTE] MONITOR - READS BITS FROM CASSETTE TAPE UNTIL BYTE ACCUMULATED (CALLED BY MONITOR READ MEMORY LOCATION 'RDBYTE' SHAPE TABLE LOAD)
 \$FCEE (-786) [RDBYT2] MONITOR MEMORY LOCATION 'RDBYT2'
 \$FCFA (-774) [RD2BIT] MONITOR TWO-EDGE TAPE SENSE; I.E. LOOPS DECREMENTING Y-REG UNTIL HARDWARE HAS INDICATED TWO TRANSITIONS OF TAPE INPUT REGISTER. CONTENTS OF Y-REG ON RETURN COMPARED WITH CONTENTS ON ENTRY MEASURE TIME REQUIRED FOR TRANSITIONS. CALLS RDBIT
 \$FCFD (-771) [RDBIT] MONITOR - LOOPS DECREMENTING Y-REG UNTIL CASSETTE TAPE INPUT REGISTER CHANGES (EITHER 0=>1 OR 1=>0). BIT VALUE RETURNED IS DETERMINED FROM RESIDUAL COUNT OF Y-REG. CALLED BY RD2BIT AND READ
 \$FD0C (-756) [RDKEY] \SE\SAME AS RDCHAR EXCEPT BYPASSES ESCAPE KEY MONITOR SUPPORT; PICKS UP AND SAVE THE CHARACTER IN THE SCREEN AREA AT BASL^H CH (LEAVING Y-REG CONTAINING CONTENTS OF CH) IT THEN CHANGES THAT CHARACTER TO BLINKING TO INDICATE CURRENT CURSOR POSN; ASKS FOR NEXT INPUT CHAR TO BE PLACED IN A-REG BY DOING AN INDIRECT JUMP VIA KSWL^H WHICH IS NORMALLY POINTING AT KEYIN. RETURN IS THEREFORE TO THE CALLER OF RDKEY - NOT TO RDKEY ROUTINE ITSELF. SET-UP: A- X- Y-REGS NOT SIGNIFICANT; CV AND BASL^H SHOULD BE COMPATABLE POINTING IN THE SCROLL WINDOW; CH INDICATES HORIZONTAL POSITION WHERE CURSOR WILL BLINK. RESULTS: A-REG CONTAINS THE INPUT CHARACTER (WHICH MAY BE ANY CHARACTER INCLUDING ANY CONTROL KEY OR ESCAPE KEY); X-REG IS UNCHANGED; Y-REG CONTAINS CONTENTS OF CH; CV CH BASL^H REMAIN UNCHANGED (A- X- Y-REGS ALTERED)
 \$FD1B (-741) [KEYIN] \SE\GETS NEXT KEY INPUT FROM KEYBOARD HARDWARE. REQUIRES LOOP TO TEST THAT KEY HAS INDEED BEEN READ; BY PRESENCE OF \$80 BIT. ALSO REQUIRES KEYBOARD STROBE TO BE HIT BEFORE NEXT KEYBOARD INPUT. AUXILLIARY ACTIONS TAKEN BY KEYIN INCLUDE RESTORING TO THE SCREEN AREA THE CHARACTER MODIFIED BY RDKEY TO REMOVE BLINK INSERTED BY RDKEY AND COUNTING UP THE RANDOM NUMBER FIELD - IGNORING OVERFLOW. SET-UP: X-REG NOT SIGNIFICANT & NOT AFFECTED; A-REG INPUT TO THIS ROUTINE STORED AT (BASL)^Y WHEN A KEY IS PRESSED BEFORE THE A-REG IS FILLED FROM THE KEYBOARD REGISTER; Y-REG USED FOR STORING A-REG IN SCREEN AREA TO (BASL)^Y; CH AND CV NOT REFERENCE; BASL^H ARE USED AS INDICATED IN RDKEY. RESULT: A-REG CONTAINS INPUT FROM KEYBOARD REGISTER; IT IS ONLY ITEM CHANGED (A-REG ALTERED)
 \$FD21 (-735) [KEYIN2] MONITOR MEMORY LOCATION KEYIN2
 \$FD2F (-721) [ESC] MONITOR MEMORY LOCATION 'ESC'
 \$FD35 (-715) [RDCHAR] \SE\CALLS RDKEY TO GET NEXT CHAR PLACED INTO A-REG. IF ESCAPE KEY PRESSED CALLS 'ESC1' FOR ESCAPE KEY PROCESSING; AFTER ESCAPE KEY AND KEY FOLLOWING HAVE BEEN READ & PROCESSED CONTROL RETURNS TO RDCHAR ROUTINE AS IF IT WERE JUST BEING ENTERED (A- X- Y-REGS ALTERED)
 \$FD3D (-707) [NOTCR] MONITOR MEMORY LOCATION 'NOTCR'
 \$FD5F (-673) [NOTCR1] MONITOR MEMORY LOCATION 'NOTCR1'
 \$FD62 (-670) [CANCEL] \SE\MONITOR S/R TO PERFORM A LINE CANCEL (\)
 \$FD67 (-665) [GETLNZ] \SE\OUTPUT A C/R (THROUGH COUT). GO TO GETLN TO WRITE PROMPT & GET A LINE OF DATA (USUALLY FROM KEYBOARD); ON SET-UP A- X- Y-REGS CH AND BASL^H NOT SIGNIFICANT. CV SHOULD POINT TO A LINE IN SCROLL WINDOW; ON OUTPUT KEYED IN INFO IS IN \$200 THRU \$200^X WHERE \$200^X CONTAINS A CARRIAGE RETURN; A-REG CONTAINS CARRIAGE RETURN; X-REG CONTAINS NUMBER OF CHARACTERS READ EXCLUDING TERMINATING CARRIAGE RETURN; Y-REG CONTAINS CONTENTS OF WNDWTH; CH CONTAINS ZERO; CV CONTAINS LINE POINTER (CURRENT VALUE); BASL^H CONTAINS MEMORY ADDRESS CORRESPONDING TO CV AND WNDLFT; SCREEN LINE IS BLANKS TO THE RIGHT OF THE END OF ECHOED INPUT (A- X- Y-REGS ALTERED)

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

\$FD6A (-662) [GETLN] \SE\ PROMPT & GET LINE OF TEXT. ON CALLING A- X- Y-REGS NOT SIGNIFICANT. CV AND BASL~H SHOULD BE COMPATIBLE POINTING IN THE SCROLL WINDOW. CH INDICATES WHERE ON LINE THE PROMPT CHARACTER IS TO BE PLACED TO BE FOLLOWED BY ECHOED KEYBOARD INPUT; OUTPUT AS FOR GETLNZ (X-REG GETS #CHARS READ. DATA TO \$200~\$200~X (MAX \$2FF) \$200~X & Y-REG GET C/R (USES NXTCHAR)) (A- X- Y-REGS ALTERED)

\$FD6F (-657) \SE\ MONITOR S/R TO GET LINE OF TEXT FM KEYBD (SAME AS GETLN EXCEPT NO PROMPT!) (A- X- Y-REGS ALTERED)

\$FD71 (-655) [BCKSPC] MONITOR MEMORY LOCATION 'BCKSPC'

\$FD75 (-651) [NXTCHAR] \SE\ TOP POINT IN CHAR INPUT LOOP. SAME EFFECT AS GETLN EXCEPT BYPASS PRINT OF PROMPT CHARACTER; ON SET-UP X-REG SHOULD BE SET TO ZERO TO BEGIN STORING OF INPUT AT \$200; A- Y-REGS NOT SIGNIFICANT; CV AND BASL~H SHOULD BE COMPATIBLE POINTING IN THE SCROLL WINDOW; CH INDICATES WHERE ECHOING OF KEYBOARD INPUT IS TO START & SHOULD BE LESS THAN WNDWDTH; RESULTS SAME AS FOR GETLNZ (A- X- Y-REGS ALTERED)

\$FD7E (-642) [CAPTST] MONITOR MEMORY LOCATION 'CAPTST'

\$FD80 (-640) [INSTDSP] MONITOR S/R TO DISASSEMBLE INSTRUCTION AT PCH/PCL (A- X- Y-REGS ALTERED)

\$FD84 (-636) [ADDINP] MONITOR MEMORY LOCATION 'ADDINP'

\$FD8E (-626) [CROUT] \SE\ MONITOR S/R TO PRINT A CARRIAGE RETURN THROUGH COUT (A- Y-REGS ALTERED)

\$FD92 (-622) [PRA1] \SE\ PRINT CARRIAGE RET; THEN HEX OF A1H~A1L; THEN MINUS SIGN (A- X- Y-REGS ALTERED)

\$FD96 (-618) [PRYX2] \SE\ MONITOR S/R TO PRINT CAR RET THEN HEX OF Y-REG & X-REG THEN A DASH (A-REG ALTERED)

\$FD99 (-615) \SE\ PRINT HEX OF Y-REG & X-REG THEN MINUS SIGN (A-REG ALTERED)

\$FDA3 (-605) [XAM8] \SE\ MONITOR S/R TO EXAMINE 8 MEM LOCNS. PRINTS HEX OF MEMORY FROM XXXX TO XXX7 WHERE XXXX IS CONTENTS OF A1L~A1H; Y-REG MUST =0 ON ENTRY (A-REG ALTERED)

\$FDAD (-595) [MOD8CHK] MONITOR MEMORY LOCATION 'MOD8CHK'

\$FDB3 (-589) [XAM] \SE\ MONITOR S/R TO EXAMINE CONTENTS OF MEMORY FROM (A1L~A1H) TO (A2L~A2H). Y-REG=0 BEFORE CALL (A-REG ALTERED)

\$FDB6 (-586) [DATAOUT] MONITOR MEMORY LOCATION 'DATAOUT'

\$FDC5 (-571) [RTS4C] MONITOR MEMORY LOCATION 'RTS4C'

\$FDC6 (-570) [XAMPM] MONITOR MEMORY LOCATION 'XAMPM'

\$FDD1 (-559) [ADD] MONITOR MEMORY LOCATION 'ADD'

\$FDDA (-550) [PREYTE] \SE\ MONITOR S/R TO PRINT CONTENTS OF A-REG AS 2 HEX DIGITS (A-REG ALTERED)

\$FDE3 (-541) [PRHEX] \SE\ MONITOR S/R TO PRINT RIGHT NIBBLE OF A-REG AS A SINGLE HEX DIGIT (A-REG ALTERED)

\$FDE5 (-539) [PRHEX2] MONITOR MEMORY LOCATION 'PRHEX2'

\$FDED (-531) [COUT] \SE\ PRINT BYTE IN A-REG TO OUTPUT DEVICE SPECIFIED BY 'CSWL' (NORMALLY 'COUT1') (A-REG ALTERED)

\$FDF0 (-528) [COUT1] \SE\ WRITE BYTE IN A-REG TO SCREEN AT CURSOR POSN (CV)~(CH) USING 'INVFLG' & SUPPORTING CURSOR MOVE

\$FDF6 (-522) [COUT2] \SE\ WRITE BYTE FROM A-REG TO SCREEN AT (CV)~(CH) WITH CURSOR MOVE BUT NOT 'INVFLG' (NONE ALTERED)

\$FE00 (-512) [BL1] MONITOR & MINIASSEMBLER MEMORY LOCATION 'BL1'

\$FE04 (-508) [BLANK] MONITOR MEMORY LOCATION 'BLANK'

\$FE0B (-501) [STOR] MONITOR MEMORY LOCATION 'STOR'

\$FE17 (-489) [RTS5] MONITOR MEMORY LOCATION 'RTS5'

\$FE18 (-488) [SETMODE] MONITOR MEMORY LOCATION 'SETMODE'

\$FE1D (-483) [SETMDZ] MONITOR MEMORY LOCATION 'SETMDZ'

\$FE20 (-480) [LT] MONITOR MEMORY LOCATION 'LT'

\$FE22 (-478) [LT2] MONITOR MEMORY LOCATION 'LT2'

\$FE2C (-468) [MOVE] \SE\ MONITOR S/R TO PERFORM A MEMORY MOVE (A1-A2 TO A4) (Y-REG MUST =0 AT CALL) (A-REG ALTERED)

\$FE36 (-458) [VFY] \SE\ MONITOR S/R TO PERFORM A MEMORY VERIFY (A1-A2 TO A4)

\$FE58 (-424) [VFYOK] MONITOR MEMORY LOCATION 'VFYOK'

\$FE5E (-418) [LIST] \SE\ CALL TO DISASSEMBLE 20 INSTRUCTIONS

\$FE63 (-413) [LIST2] MONITOR MEMORY LOCATION 'LIST2'

\$FE78 (-392) [A1PCLP] MONITOR & MINIASSEMBLER MEMORY LOCATION 'A1PCLP'

\$FE7F (-385) [A1PCRTS] MONITOR MEMORY LOCATION 'A1PCRTS'

\$FE80 (-384) [SETINV] \SE\ MONITOR S/R TO SET VIDEO OUTPUT TO INVERSE

\$FE84 (-380) [SETNORM] \SE\ MONITOR S/R TO SET VIDEO OUTPUT TO NORMAL (NOT INVERSE)

HEX LOCN (DEC LOCN) [NAME] \USE-TYPE\ - DESCRIPTION

```

$FE86 (-378) [SETIFLG] MONITOR MEMORY LOCATION 'SETIFLG'
$FE89 (-375) [SETKBD] MONITOR MEMORY LOCATION 'SETKBD'
$FE8B (-373) [INPORT] MONITOR MEMORY LOCATION 'INPORT'
$FE8D (-371) [INPRT] MONITOR MEMORY LOCATION 'INPRT'
$FE93 (-365) [SETVID] MONITOR MEMORY LOCATION 'SETVID'
$FE95 (-363) [OUTPORT] MONITOR MEMORY LOCATION 'OUTPORT'
$FE97 (-361) [OUTPRT] MONITOR MEMORY LOCATION 'OUTPRT'
$FE9B (-357) [IOPRT] MONITOR MEMORY LOCATION 'IOPRT'
$FEA7 (-345) [IOPRT1] MONITOR MEMORY LOCATION 'IOPRT1'
$FEA9 (-343) [IOPRT2] MONITOR MEMORY LOCATION 'IOPRT2'
$FEB0 (-336) [XBASIC] \SE\MONITOR S/R TO JUMP TO BASIC
$FEB3 (-333) [BASCONT] \SE\MONITOR S/R TO CONTINUE BASIC
$FEB6 (-330) [GO] \SE\ MONITOR MEMORY LOCATION 'GO'
$FEB9 (-327) \SE\ RESTORE REGISTERS (CALL RESTORE) THEN JMP (PCL) TO CONTINUE EXECUTION (A- X- Y- P-REGS ALTERED)
$FEBF (-321) [REGZ] \SE\MONITOR S/R TO DISPLAY REGISTERS
$FEC2 (-318) [TRACE] \SE\CALL TO PERFORM MONITOR TRACE
$FEC4 (-316) [STEPZ] MONITOR MEMORY LOCATION 'STEPZ'
$FECA (-310) [USR] MONITOR MEMORY LOCATION 'USR'
$FECF (-307) [WRITE] \SE\MONITOR S/R TO WRITE DATA FROM MEMORY TO CASSETTE TAPE - FIRST MEMORY LOCATION POINTED TO BY
A1L'H ($003C-$003D); LAST BY A2L'H ($003E-$003F). CASSETTE TAPE GETS 10 SECONDS OF TONE
HEADER THEN THE DESIGNATED DATA BITS AND ONE CHECKSUM BYTE
$FED4 (-300) [WR1] MONITOR MEMORY LOCATION 'WR1'
$FEED (-275) [WRBYTE] MONITOR - USES WRBIT TO WRITE 10 BITS TO CASSETTE TAPE
$FEF (-273) [WRBYT2] MONITOR MEMORY LOCATION 'WRBYT2'
$FEF6 (-266) [CRMON] MONITOR MEMORY LOCATION 'CRMON'
$FEFD (-259) [READ] \SE\READS DATA FROM CASSETTE TAPE PUTTING FIRST DATA READ INTO LOCATION POINTED TO BY A1L'H
($003C-$003D) AND CONTINUING TO READ UNTIL DATA GOES TO LOCATION POINTED TO BY A2L'H
($003E-$003F). ALSO COMPUTES A RUNNING EXCLUSIVE OR CHECKSUM IN 'CHECKSUM' ($002E)
$FF02 (-254) [READX1] HI-RES GRAPHICS - READ WITHOUT HEADER
$FF0A (-246) [RD2] MONITOR MEMORY LOCATION 'RD2'
$FF16 (-234) [RD3] MONITOR MEMORY LOCATION 'RD3'
$FF2D (-211) [PRERR] \SE\MONITOR S/R TO PRINT "ERR" AND SOUND BELL. (A- Y-REGS(?) ALTERED)
$FF3A (-198) [BELL] \SE\MONITOR S/R TO SOUND BELL IN CURRENT OUTPUT DEVICE (WHETHER IT IS APPLE OR EXTERNAL PRINTER)
(A--REG ALTERED)
$FF3F (-193) [RESTORE] \SE\RESTORE 6502 REGISTERS: ($0045)=>A-Reg; ($0046)=>X-Reg; ($0047)=>Y-Reg; ($0048)=>P-Reg;
(A- X- Y- P-REGS ALTERED)
$FF44 (-188) [RESTR1] MONITOR MEMORY LOCATION 'RESTR1'
$FF4A (-182) [SAVE] \SE\MONITOR S/R TO SAVE 6502 REGISTERS: (A-REG)=>$0045; (X-REG)=>$0046; (Y-REG)=>$0047;
(P-REG)=>$0048; (S-REG)=>$0049 (NONE)
$FF4C (-180) [SAV1] MONITOR MEMORY LOCATION 'SAV1'
$FF58 (-168) [IORTS] JSR HERE TO FIND OUT WHERE ONE IS. SETS OVERFLOW FLAG
$FF59 (-167) [RESET] \SE\CALL HERE HAS SAME EFFECT AS PUSHING RESET BUTTON
$FF65 (-155) [MON] \SE\MONITOR S/R- NORMAL ENTRY TO 'TOP' OF MONITOR WHEN RUNNING (BEEPS!)
$FF69 (-151) [MONZ] \SE\MONITOR S/R TO RESET AND ENTER MONITOR (NO BEEP)
$FF70 (-144) \SE\ MONITOR S/R TO SCAN INPUT BUFFER
$FF73 (-141) [NXTITM] MONITOR MEMORY LOCATION 'NXTITM'
$FF7A (-134) [CHRSRCH] MONITOR MEMORY LOCATION 'CHRSRCH'
$FF7C (-132) [ZMODE] MONITOR & MINIASSEMBLER MEMORY LOCATION 'ZMODE'
$FF8A (-118) [DIG] MONITOR MEMORY LOCATION 'DIG'
$FF90 (-112) [NXTBIT] MONITOR MEMORY LOCATION 'NXTBIT'
$FF98 (-104) [NXTBAS] MONITOR MEMORY LOCATION 'NXTBAS'

```

\$FE86 - \$FF98

Prof. Luebbert's "What's Where in the Apple"

NUMERIC ATLAS

\$FFA2 (-94)	[NXTBS2]	MONITOR MEMORY LOCATION 'NXTBS2'
\$FFA7 (-89)	[GETNUM]	MONITOR & MINIASSEMBLER MEMORY LOCATION 'GETNUM'
\$FFAD (-83)	[NXTCHR]	MONITOR - TOP POINT IN GETLN CHARACTER INPUT LOOP; RDCHAR CALLED TO GET CHAR INTO A-REG; ON RETURN A-REG TESTED FOR PRESENCE OF CTRL-U (RIGHT ARROW); IF SO A-REG LOADED FROM SC/REEN MEMORY ASSUMING Y-REG CONTAINS SAME VALUE AS CH; IF A-REG VAL > \$DF LOWER-CASE LETTER CONVERTED TO UPPER CASE; IF CHAR IS A C/R IT IS PRINTED THROUGH COUT AND RTS EXIT OF COUT WILL GIVE CONTROL BACK TO CALLING PROGRAM W/ X-REG INDICATING INPUT CHAR COUNT +1; THAT IS INPUT IS IN LOCNS \$200 THRU \$200~X WHERE \$200~X CONTAINS A C/R; ON SET-UP A- X- Y-REGS NOT SIGNIFICANT; CV & BASL~H SHOULD BE COMPATIBLE (POINTING IN THE SCROLL WINDOW); CH INDICATES HORIZ POSN IN SCROLL WINDOW WHERE CURSOR WILL BE INDICATED BY BLINKING. ON RETURN CALLER A-REG WILL CONTAIN KEY VALUE; Y-REG WILL CONTAIN CONTENTS OF CH; X-REG WILL CONTAIN SAME VALUE AS INPUT; CV CH & BASL~H WILL HAVE CHANGE ONLY IF AN ESCAPE KEY SEQUENCE HAS BEEN PERFORMED
\$FFBE (-66)	[TOSUB]	MONITOR & MINIASSEMBLER MEMORY LOCATION 'TOSUB'
\$FFC7 (-57)	[ZMODE]	MONITOR MEMORY LOCATION 'ZMODE'
\$FFCC (-52)	[CHRTBL]	MONITOR & MINIASSEMBLER MEMORY LOCATION 'CHRTBL' (TABLE USED TO DECODE MONITOR KEYBOARD INPUT)
\$FFE3~\$FFE9 (-29~-23)	[SUBTBL]	\PB\TABLE OF SUBROUTINE ADDRESSES -1 (INDEX PC WITH TBL ITEM FOR S/R ENTRY): (ADDRESS MSB = \$FE; LSB = TABLE ENTRY +1)
\$FFE3 (-29)	[SUBTBL]	'SUBTBL' L.S.B. ADDRESS-1 OF BASCONT SUBROUTINE
\$FFE4 (-28)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF USR SUBROUTINE (M.S.B.= \$FE)
\$FFE5 (-27)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF REGZ SUBROUTINE (M.S.B.= \$FE)
\$FFE6 (-26)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF TRACE SUBROUTINE (M.S.B.= \$FE)
\$FFE7 (-25)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF VFY SUBROUTINE (M.S.B.= \$FE)
\$FFE8 (-24)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF INPRT SUBROUTINE (M.S.B.= \$FE)
\$FFE9 (-23)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF STEPZ SUBROUTINE (M.S.B.= \$FE)
\$FFEA (-22)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF OUTPRT SUBROUTINE (M.S.B.= \$FE)
\$FFEB (-21)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF XBASIC SUBROUTINE (M.S.B.= \$FE)
\$FFEC (-20)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF SETMODE SUBROUTINE (M.S.B.= \$FE)
\$FFED (-19)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF SETMODE SUBROUTINE (M.S.B.= \$FE)
\$FFEE (-18)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF MOVE SUBROUTINE (M.S.B.= \$FE)
\$FFEF (-17)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF LT SUBROUTINE (M.S.B.= \$FE)
\$FFF0 (-16)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF SETNORM SUBROUTINE (M.S.B.= \$FE)
\$FFF1 (-15)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF SETINV SUBROUTINE (M.S.B.= \$FE)
\$FFF2 (-14)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF LIST SUBROUTINE (M.S.B.= \$FE)
\$FFF3 (-13)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF WRITE SUBROUTINE (M.S.B.= \$FE)
\$FFF5 (-11)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF READ SUBROUTINE (M.S.B.= \$FE)
\$FFF6 (-10)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF SETMODE SUBROUTINE (M.S.B.= \$FE)
\$FFF7 (-9)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF SETMODE SUBROUTINE (M.S.B.= \$FE)
\$FFF8 (-8)	\P1\	'SUBTBL' L.S.B. ADDRESS-1 OF CRMON SUBROUTINE (M.S.B.= \$FE)
\$FFFA~\$FFFB (-6~-5)	\P2\	FULL (16-BIT) ADDRESS OF NMI (NON-MASKABLE INTERRUPT) VECTOR
\$FFFC~\$FFFD (-4~-3)	\P2\	FULL (16-BIT) ADDRESS OF RESET VECTOR
\$FFFE~\$FFFF (-2~-1)	\P2\	FULL (16-BIT) ADDRESS OF IRQ (INTERUPT REQUEST) VECTOR

