

START UP CARD (APPLE IIGS)

IMPORTANT!

All First Byte products require 768K of memory. Please follow these easy steps to check the RAM memory settings for your Apple IIGS.

CONTROL PANEL

1. Place the First Byte diskette in the disk drive and turn on your Apple IIGS.
2. After turning on the IIGS, press the **OPTION** key in conjunction with the **CONTROL** and **RESET** keys. (Press all three keys together and then release with the **RESET** key first).
3. Press 1 to enter the Control Panel.
4. Use Arrow keys to select submenu and press return.
5. The three important submenus are the RAM Disk, System Speed, and Sound.

RAM Disk

Minimum RAM Disk Size: 0K
Maximum RAM Disk Size: 0K

-RAM Status-

Total RAM in Use: 85K
Total Free RAM: 683K or More
(If Total RAM in Use and Total Free RAM do not total 768K or more then you need additional memory).

System Speed

Set to **FAST** and press return.

Sound

Move **VOLUME** towards the right side and press return.

6. Quit from the Control Panel and wait for the Apple IIGS Program Launcher screen to display.

(. . . over)

APPLE IIGS PROGRAM LAUNCHER

1. The Program will boot up to the Apple IIGS Program Launcher screen.
2. Select the program and click on **OPEN**.

SmoothTalker
KidTalk
MathTalk
MathTalk FRACTIONS
Speller Bee
First Letter and Words
First Shapes

Select **TALKER**
Select **KID**
Select **MATHTALK**
Select **FRACTIONS**
Select **SPELL**
Select **FIRST.LETTERS**
Select **FIRST.SHAPES**

3. After clicking on **OPEN** the program will begin.
4. If you have any questions, please write or call First Byte.

First Byte
3333 East Spring Street (#302)
Long Beach, CA. 90806

(213) 595-7006