

- Languages 234
  - Assembly language 234
  - Applesoft BASIC 235
  - Integer BASIC 235
  - Pascal language 235
  - Fortran 235

## **Appendix E Conversion Tables 236**

- Bits and bytes 236
- Hexadecimal and decimal 238
- Hexadecimal and negative decimal 239
- Graphics bits and pieces 241
- Eight-bit code conversions 243

## **Appendix F Frequently Used Tables 252**

## **Appendix G Using an 80-Column Text Card 267**

- Starting up with Pascal or CP/M 267
- Starting up with ProDOS or DOS 3.3 268
- Using the GET command 269
- When to switch modes versus when to deactivate 269
- Display features with the text card 270
- INVERSE, FLASH, NORMAL, HOME 270
- Tabbing with the original Apple IIe 271
  - Comma tabbing with the original Apple IIe 271
  - HTAB and POKE 1403 271
- Using control characters with the card 272
  - Control characters and their functions 272
  - How to use control-character codes in programs 275
  - A word of caution to Pascal programmers 275

## **Appendix H Programming With the Super Serial Card 276**

- Locating the card 276
- Operating modes 277
- Operating commands 277
  - The command character 278
  - Baud rate, nB 279
  - Data format, nD 279
  - Parity, nP 279
  - Set time delay, nC, nL, and nF 280
  - Echo characters to the screen, E\_E/D 280